

User's Guide

Part I

Life Scope *TR*

Bedside Monitor

BSM-6301/BSM-6501/BSM-6701

BSM-6000 series
BSM-6301A
BSM-6301K
BSM-6501A
BSM-6501K
BSM-6701A
BSM-6701K

If you have any comments or suggestions on this manual, please contact us at: www.nihonkohden.com

Copyright Notice

The entire contents of this manual are copyrighted by Nihon Kohden. All rights are reserved. No part of this document may be reproduced, stored, or transmitted in any form or by any means (electronic, mechanical, photocopied, recorded, or otherwise) without the prior written permission of Nihon Kohden.

Trademark



The mark printed on the SD card that is used in this instrument is a trademark. The company name and model name are trademarks and registered trademarks of each company.

Contents

GENERAL HANDLING PRECAUTIONS	i
WARRANTY POLICY	ii
EMC RELATED CAUTION	iii
Conventions Used in this Manual and Instrument	vi
Warnings, Cautions and Notes	vi
Text Conventions in this Manual	vi
Explanations of the Symbols in this Manual and Instrument	vii
Related Documentation	xi
Safety Standards	xi
Safety Information	xi

Section 1 **General..... 1.1**

Introduction	1.3
General	1.3
Applications	1.4
Features	1.4
Measurement Parameters, and Applicable Units	1.6
Composition	1.8
Network Composition	1.9
Panel Description	1.10
MU-631R Main Unit	1.10
Front Panel	1.10
Left Side Panel	1.11
Right Side Panel	1.11
Rear Panel	1.12
MU-651R/MU-671R Main Unit	1.13
Front Panel	1.13
Left Side Panel	1.14
Right Side Panel	1.14
Rear Panel	1.15
AY-631P/633P/651P/653P/660P/661P/663P/671P/673P Input Unit	1.16
Front Panel	1.16
Using MULTI Sockets for CO Monitoring	1.16
Using the Output Signal from the ECG/BP OUT Socket	1.17
Left Side Panel	1.18
Right Side Panel	1.18
Rear Panel	1.19
AA-672P/AA-674P Smart Expansion Unit	1.19
Front Panel	1.19
Using MULTI Sockets for CO Monitoring	1.20
Right Side Panel	1.20
QF series Interface and IF series Communication Cable	1.21
RY-910PA Remote Controller	1.22
Basic Operating Concepts	1.23

Screen Displays.....	1.23
Using Touch Screen Keys	1.29
Keys on the Bedside Monitor	1.30
Using the Remote Control	1.31
Using the Mouse.....	1.31
Using the Data Acquisition Unit	1.32
Using the MENU Window	1.33
Transport Function	1.34
Overview.....	1.34
Requirements	1.34
Necessary Settings Before Use.....	1.34
Transported Data and Settings	1.35
Sending Data to a CNS-9701 Central Monitor.....	1.36
Patient Authentication	1.37
Preparing for Removing the Input Unit	1.41
Enabling the Input Unit	1.42
When the Input Unit is Disabled	1.42
Enabling the Input Unit	1.42

Section 2 *Preparation* 2.1

Preparation Flowchart.....	2.2
Installation Conditions.....	2.3
Inserting and Removing the Battery Pack	2.5
Battery Handling and Operation	2.5
Safety Information	2.5
Battery Pack Handling Procedures.....	2.6
When Not Using the Monitor or Battery Pack.....	2.6
Inserting and Removing the Battery Packs	2.6
Inserting the Battery Pack	2.7
Removing the Battery Pack	2.8
Inserting and Removing the Input Unit	2.9
Inserting the Input Unit	2.9
Removing the Input Unit	2.9
When the Transport Function is Enabled.....	2.10
Preparing the Optional Recorder	2.11
Installing the Recorder Module.....	2.11
Loading Recording Paper.....	2.11
Preparing the Remote Control	2.13
Installing the Batteries	2.13
Setting the Remote Control Channel.....	2.14
Attaching the Remote Control Channel Label to the Bedside Monitor	2.14
Assigning Functions to the Customized Keys.....	2.14
Power.....	2.15
Connecting the Power Cord and Grounding the Monitor.....	2.15
Connecting the Power Cord.....	2.15
Grounding the Monitor.....	2.16
Turning the Power On	2.16
Check Before Turning On the Power	2.16

Turning the Power On	2.17	1
AUTO ADMIT Setting	2.18	
Check After Turning On the Power and During Monitoring	2.18	2
Power and Battery Status Indications	2.19	
When the “BATTERY WEAK” Message Appears	2.20	3
Charging the Battery Pack	2.20	
Monitor Status on Power Interruption	2.21	4
Turning the Power Off	2.22	
Check After/Before Turning the Power Off	2.22	5
		6
Section 3 Necessary Settings Before Monitoring	3.1	7
Changing Date and Time	3.2	
Changing Sound Volume Settings	3.3	8
Changing the Screen Brightness	3.4	
Changing Waveform Display Settings	3.5	9
Entering Patient Information	3.7	
Displaying the PATIENT INFO Page	3.8	10
Closing the PATIENT INFO Page	3.8	
Entering the Patient Information	3.9	11
Entering the Patient ID	3.9	
Entering the Patient Name	3.10	
Entering the Date of Birth and Age	3.11	
Entering the Height and Weight	3.13	
Entering the Gender	3.13	
Entering the Pacemaker Use	3.14	
Deleting Data	3.16	
Suspended Alarms after Deleting Data	3.18	
Section 4 Home Screen	4.1	
Safety Precautions for Monitoring	4.3	
Using an Electrosurgical Unit	4.3	
Using a Defibrillator	4.3	
Overview	4.4	
Home Screen	4.4	
Review Windows	4.4	
Sync Sound	4.4	
Adjusting the Sync and Alarm Sound Volume	4.4	
Changing Settings and Performing Other Tasks During Monitoring	4.4	
Site Mode	4.5	
Recording/Printing on the Home Screen	4.5	
Interbed Monitoring	4.5	
Home Screen	4.6	
Settings for the Home Screen	4.7	
Waveform Sweep Mode and Speed	4.7	
Waveform Display on the Home Screen	4.7	
Pacing Mark Position on the ECG Waveform	4.7	

ST Waveform and Reference ST Recall Waveform Display on the Home Screen On or Off.....	4.7
Blood Pressure Waveform Display Mode	4.7
PPV or SPV Display on the Home Screen	4.8
Pulse Rate Display on the Home Screen	4.8
Current Average CO and PCWP Values Display on the Home Screen	4.8
Trendgraph/PWTT Trendgraph/OCRG Display on the Home Screen On or Off	4.8
Scale Setting for the Trendgraph on the Home Screen	4.9
Parameter Colors	4.9
Waveform Sensitivity	4.9
Displaying Other Windows from the Home Screen.....	4.10
Displaying PWTT Trendgraph	4.11
Displaying OCRG.....	4.13
Freezing Waveforms	4.14
Using Sleep Mode	4.15
Turning Sleep Mode On.....	4.15
Turning Sleep Mode Off.....	4.16
Displaying the LARGE NUMERICS Screen.....	4.17

Section 5 Alarm Function..... 5.1

Overview of Alarms.....	5.4
What is an Alarm	5.4
Alarm Level.....	5.5
Alarm Priority	5.5
Alarm Sound/Alarm Indicator	5.5
Alarm Messages on the Screen	5.5
Silencing/Suspending Alarms.....	5.5
Alarm Master	5.6
Automatic Recording	5.7
Alarm Setting	5.7
Canceling the Technical Alarm	5.8
Adjusting Alarm Sound Volume	5.8
Alarm Activation after Power On.....	5.8
ALARM HISTORY Window	5.8
Interbed Alarm	5.9
Alarm Types	5.10
Vital Signs Alarms	5.10
Arrhythmia Alarms	5.10
Technical Alarms	5.11
ECG Related Alarms	5.11
Respiration Related Alarms.....	5.11
CO ₂ Related Alarms	5.12
Microcap [®] Related Alarms.....	5.12
SpO ₂ Related Alarms	5.12
NIBP Related Alarms	5.13
IBP Related Alarms	5.13
Temperature Related Alarms.....	5.13

BIS Related Alarms	5.13	1
CO Related Alarms	5.14	
Gas Related Alarms	5.14	2
O ₂ Related Alarms	5.15	
VENT Related Alarms	5.15	3
TOF Related Alarms	5.15	
CCO Related Alarms	5.15	4
PiCCO Related Alarms	5.16	
FLOW/Paw Related Alarms	5.16	5
EEG Related Alarms	5.16	
tcPO ₂ /tcPCO ₂ Related Alarms	5.17	6
Other Alarms	5.17	7
Messages	5.18	
ECG Related Messages	5.18	8
Respiration Related Messages	5.18	
CO ₂ Related Messages	5.18	9
SpO ₂ Related Messages	5.19	
NIBP Related Messages	5.19	10
IBP Related Message	5.19	
BIS Related Messages	5.20	11
O ₂ Related Messages	5.20	
CO Related Messages	5.20	
Gas Related Messages	5.21	
FLOW/Paw Related Messages	5.21	
EEG Related Messages	5.21	
Microcap [®] Related Messages	5.22	
Other Messages	5.22	
Alarm Indications	5.23	
Overview	5.23	
Individual Alarm Indications	5.24	
Vital Signs Alarms	5.25	
Arrhythmia Alarms	5.29	
Technical Alarms	5.30	
Other Alarms	5.37	
Interbed Alarms	5.37	
Alarm Control Marks	5.37	
Individual Vital Signs Alarm Off Marks	5.38	
Flow of Alarm Function	5.39	
Silencing and Suspending Alarms	5.40	
Overview	5.40	
Silencing an Alarm	5.40	
Suspending Alarms	5.40	
Silencing Alarms After Alarm Occurrence	5.43	
Silencing an Alarm	5.43	
Canceling Alarm Silence	5.44	
Suspending Alarms Before Alarm Occurrence	5.44	
Suspending Alarms	5.44	
Suspending All Alarms Indefinitely	5.44	

Suspending All Alarms and NIBP STAT and Auto Measurement	
Indefinitely	5.47
Turning Automatic Alarm Recording On/Off.....	5.49
Setting Alarms	5.50
Overview.....	5.50
Alarm Limits Ranges	5.50
Vital Signs Alarms	5.51
Arrhythmia Alarms	5.56
Setting Vital Signs Alarms Individually.....	5.57
Setting All Vital Signs Alarms to a Preset Pattern (Alarm Master).....	5.58
Setting Arrhythmia Alarms Individually	5.59
Setting All Arrhythmia Alarms to a Preset Pattern (Alarm Master)	5.60

Section 6 *Review Windows* 6.1

General	6.3
Transport.....	6.4
Review Recording.....	6.5
Event Bar	6.6
Selecting the Event Display Position on the Event Bar.....	6.6
Changing the Event Bar Time Interval.....	6.7
Scrolling the Event Bar	6.7
Trend Window	6.8
GRAPH 1, GRAPH 2, GRAPH 3 Page	6.8
Displaying the GRAPH 1, GRAPH 2 or GRAPH 3 Page	6.10
Selecting Parameters for the Trendgraph Display.....	6.11
Changing the Trendgraph Scale	6.12
Changing the Trendgraph Display Format	6.13
Recording the Trendgraph	6.14
Printing the Trendgraph	6.15
TABLE 1, TABLE 2, TABLE 3 Page	6.17
Displaying the TABLE 1, TABLE 2 or TABLE 3 Page	6.18
Scrolling the Trend Table.....	6.19
Selecting Parameters for the Trend Table Display	6.19
Selecting the Measurement Interval	6.20
Recording a Trend Table	6.21
Printing a Trend Table	6.21
NIBP TREND Page.....	6.23
Displaying the NIBP TREND Page	6.24
Scrolling the NIBP Trend Table	6.25
Selecting Parameters for the NIBP Trend Display	6.25
Recording a NIBP Trend Table.....	6.26
Printing a NIBP Trend Table.....	6.27
HEMO Page.....	6.29
Displaying the HEMO Page	6.29
Scrolling the Hemodynamics Table.....	6.30
Explanation of the Hemodynamics Table.....	6.31
Recording a Hemodynamics Table	6.32
Printing a Hemodynamics Table	6.33

LUNG TREND Page	6.34	1
Displaying the LUNG TREND Page.....	6.34	
Explanation of the Lung Trend Table.....	6.35	2
Recording the Lung Trend Table	6.36	
Printing a Lung Trend Table	6.37	3
Arrhythmia Recall Window	6.38	
General	6.38	4
Arrhythmia List.....	6.38	
Displaying the Arrhythmia Recall Window	6.40	5
Selecting the Arrhythmia Types to be Saved as a Recall File.....	6.41	
Scrolling the Arrhythmia Recall Files	6.41	6
Displaying the Actual Size Waveform of the Selected Arrhythmia Recall File	6.42	
Arrhythmia Waveform Annotation	6.42	7
Recording or Printing the Arrhythmia Recall Waveform.....	6.42	
Recording on the ARRHYTH HISTORY Window	6.42	8
Printing on the ARRHYTH HISTORY Window.....	6.44	
Recording on the Actual Size ECG Waveform Window	6.45	
Printing on the Actual Size ECG Waveform Window	6.46	10
Alarm History Window	6.47	
Displaying the ALARM HISTORY Window.....	6.47	11
Scrolling the Alarm History Files	6.48	
Recording the Alarm History File.....	6.48	
Full Disclosure Window.....	6.50	
Displaying the FULL DISC Window	6.50	
Scrolling the Full Disclosure Waveform	6.52	
Selecting the Parameters to be Saved for Full Disclosure.....	6.53	
Recording or Printing the Full Disclosure Waveform	6.54	
Recording the Full Disclosure Waveform.....	6.54	
Printing the Full Disclosure Waveform.....	6.55	
Recording or Printing the Enlarged ECG Waveform.....	6.57	
Recording the Enlarged ECG Waveform	6.57	
Printing the Enlarged ECG Waveform	6.58	
ST Level Recall Window	6.60	
Displaying the ST Window	6.61	
Scrolling the ST Level Recall File	6.62	
Displaying the ST Point.....	6.62	
Displaying the ST Recall Waveform on the Home Screen.....	6.63	
Saving as Reference ST Recall File	6.64	
Displaying the Reference ST Recall Waveform on the Home Screen	6.65	
Printing the ST Level Recall File.....	6.66	
OCRG Window	6.68	
Displaying the OCRG Window.....	6.68	
Selecting the OCRG Trendgraph Type.....	6.69	
Changing the Trendgraph Scale for Heart Rate and SpO ₂	6.70	
Recording or Printing the OCRG Trend	6.71	
Recording the OCRG Trend	6.71	
Printing the OCRG Trend.....	6.72	

Section 7 12 Lead Analysis/12 Lead Windows 7.1

12 Lead Analysis Window	7.2
Preparation Flowchart	7.2
Displaying the 12 LEAD ANALYSIS Window	7.3
Entering the Patient's Date of Birth and Gender.....	7.4
Displaying the PATIENT INFO Window	7.4
Entering the Date of Birth and Age	7.4
Entering the Gender.....	7.4
Performing 12 Lead ECG Interpretation	7.5
Recording or Printing the 12 Lead ECG Waveform	7.6
Recording the 12 Lead ECG Waveforms.....	7.6
Printing the 12 Lead ECG Waveforms.....	7.7
12 LEAD Window	7.9
Displaying the 12 LEAD Window	7.9
12 LEAD Page	7.10
Scrolling the 12 Lead Data File	7.10
Recording the 12 Lead Data	7.10
ANALYSIS WAVE Page	7.11
Recording or Printing the 12 Lead Waveform.....	7.12
Recording the 12 Lead Waveform	7.12
Printing the 12 Lead Waveform	7.13
REPORT Page.....	7.14
Recording or Printing the 12 Lead Interpretation Results.....	7.14
Recording the 12 Lead Interpretation Results.....	7.14
Printing the 12 Lead Interpretation Results.....	7.15
AVERAGE WAVE Page	7.16
Printing the Averaged ECGs	7.16

Section 8 Drug/Lung Function Windows 8.1

DRUG Window.....	8.2
Drug Titration Initial Settings.....	8.3
Flow Rate Equations.....	8.4
Displaying the DRUG Window	8.6
Selecting the Drug	8.9
Assigning a Drug Name and Dosage Unit to DRUG A to D.....	8.10
Changing the Settings	8.12
Changing the Drug Amount, Solution Amount, Dosage, Flow Rate and Weight.....	8.12
Changing the Dose Step	8.13
Unit and Setting Range	8.13
Drug Amount, Dosage and Step	8.13
Solution Amount, Flow Rate and Weight.....	8.14
LUNG FUNCTION Window.....	8.15
Displaying the LUNG FUNCTION Window	8.15
Entering the Data.....	8.17
Explanation of the DATA ENTRY Items	8.17
Checking the Calculation Results	8.18
Explanation of the CALCULATION RESULTS.....	8.18

Adding the Calculation Results to the LUNG TREND Table	8.18	1
Displaying the LUNG TREND Table	8.19	
Recording the Calculation Results and Entered Data	8.20	2
Section 9 Interbed Window	9.1	3
Registering Interbed Beds	9.3	4
Removing an Interbed Bed	9.3	5
Displaying the Numeric Data of All Interbed Beds	9.4	6
Displaying the Interbed Bed Data	9.5	7
Interbed Alarm	9.7	
Settings Related to Interbed Alarm	9.8	8
Section 10 Recording	10.1	9
Overview of Recording	10.2	10
Recording Modes	10.3	11
Manual Waveform Recording/Printing	10.5	
Recording/Printing on the 12 LEAD ANALYSIS Window	10.5	
Recording/Printing on the Review Windows other than 12 Lead Window	10.5	
Recording/Printing on the 12 LEAD Window	10.5	
Recording on the LUNG FUNCTION Window	10.5	
Recording/Printing PWTT Trendgraph	10.6	
Recording/Printing OCRG	10.6	
Recording on the CO Window	10.6	
Recording on the TOF Window	10.6	
Recording on the CCO Window	10.6	
Recording on the FLOW Window	10.6	
Recording on the EEG Window	10.7	
Periodic Recording	10.8	
Alarm Recording	10.9	
Recording Mode Annotations	10.11	
Recording Priority	10.12	
Recording Sensitivity	10.12	
Recording Speed	10.12	
Recording Related Message	10.12	
Recorded/Printed Data	10.13	
Changing the Recording Speed	10.14	
Changing the Recording Pattern	10.15	
Manually Recording/Printing Waveforms	10.16	
Recording Waveforms on the Optional Recorder	10.16	
Recording Waveforms on the Bedside Monitor with No Recorder	10.17	
Manual Printing on the Network Printer	10.17	
Setting Periodic Recording	10.18	
Changing Settings for Automatic Periodic Recording	10.19	
Printing on a Network Printer	10.20	

Section 11 *Reference*..... 11.1

 Clock Accuracy 11.2

 Periodical Replacement Schedule 11.3

 Repair Parts Availability Policy..... 11.3

GENERAL HANDLING PRECAUTIONS

This device is intended for use only by qualified medical personnel.

Use only Nihon Kohden approved products with this device. Use of non-approved products or in a non-approved manner may affect the performance specifications of the device. This includes, but is not limited to, batteries, recording paper, pens, extension cables, electrode leads, input boxes and AC power.

Please read these precautions thoroughly before attempting to operate the instrument.

1. To safely and effectively use the instrument, its operation must be fully understood.

2. When installing or storing the instrument, take the following precautions:

- (1) Avoid moisture or contact with water, extreme atmospheric pressure, excessive humidity and temperatures, poorly ventilated areas, and dust, saline or sulphuric air.
- (2) Place the instrument on an even, level floor. Avoid vibration and mechanical shock, even during transport.
- (3) Avoid placing in an area where chemicals are stored or where there is danger of gas leakage.
- (4) The power line source to be applied to the instrument must correspond in frequency and voltage to product specifications, and have sufficient current capacity.
- (5) Choose a room where a proper grounding facility is available.

3. Before Operation

- (1) Check that the instrument is in perfect operating order.
- (2) Check that the instrument is grounded properly.
- (3) Check that all cords are connected properly.
- (4) Pay extra attention when the instrument is combined with other instruments to avoid misdiagnosis or other problems.
- (5) All circuitry used for direct patient connection must be doubly checked.
- (6) Check that battery level is acceptable and battery condition is good when using battery-operated models.

4. During Operation

- (1) Both the instrument and the patient must receive continual, careful attention.
- (2) Turn power off or remove electrodes and/or transducers when necessary to assure the patient's safety.
- (3) Avoid direct contact between the instrument housing and the patient.

5. To Shutdown After Use

- (1) Turn power off with all controls returned to their original positions.
- (2) Remove the cords gently; do not use force to remove them.
- (3) Clean the instrument together with all accessories for their next use.

6. The instrument must receive expert, professional attention for maintenance and repairs. When the instrument is not functioning properly, it should be clearly marked to avoid operation while it is out of order.

7. The instrument must not be altered or modified in any way.

8. Maintenance and Inspection

- (1) The instrument and parts must undergo regular maintenance inspection at least every 6 months.
- (2) If stored for extended periods without being used, make sure prior to operation that the instrument is in perfect operating condition.

- (3) Technical information such as parts list, descriptions, calibration instructions or other information is available for qualified user technical personnel upon request from your Nihon Kohden representative.
- 9. When the instrument is used with an electrosurgical instrument, pay careful attention to the application and/or location of electrodes and/or transducers to avoid possible burn to the patient.**
- 10. When the instrument is used with a defibrillator, make sure that the instrument is protected against defibrillator discharge. If not, remove patient cables and/or transducers from the instrument to avoid possible damage.**

WARRANTY POLICY

Nihon Kohden Corporation (NKC) shall warrant its products against all defects in materials and workmanship for one year from the date of delivery. However, consumable materials such as recording paper, ink, stylus and battery are excluded from the warranty.

NKC or its authorized agents will repair or replace any products which prove to be defective during the warranty period, provided these products are used as prescribed by the operating instructions given in the operator's and service manuals.

No other party is authorized to make any warranty or assume liability for NKC's products. NKC will not recognize any other warranty, either implied or in writing. In addition, service, technical modification or any other product change performed by someone other than NKC or its authorized agents without prior consent of NKC may be cause for voiding this warranty.

Defective products or parts must be returned to NKC or its authorized agents, along with an explanation of the failure. Shipping costs must be pre-paid.

This warranty does not apply to products that have been modified, disassembled, reinstalled or repaired without Nihon Kohden approval or which have been subjected to neglect or accident, damage due to accident, fire, lightning, vandalism, water or other casualty, improper installation or application, or on which the original identification marks have been removed.

In the USA and Canada other warranty policies may apply.

CAUTION

United States law restricts this product to sale by or on the order of a physician.

EMC RELATED CAUTION

This equipment and/or system complies with IEC 60601-1-2 International Standard for electromagnetic compatibility for medical electrical equipment and/or system. However, an electromagnetic environment that exceeds the limits or levels stipulated in IEC 60601-1-2, can cause harmful interference to the equipment and/or system or cause the equipment and/or system to fail to perform its intended function or degrade its intended performance. Therefore, during the operation of the equipment and/or system, if there is any undesired deviation from its intended operational performance, you must avoid, identify and resolve the adverse electromagnetic effect before continuing to use the equipment and/or system.

The following describes some common interference sources and remedial actions:

1. Strong electromagnetic interference from a nearby emitter source such as an authorized radio station or cellular phone:
Install the equipment and/or system at another location. Keep the emitter source such as cellular phone away from the equipment and/or system, or turn off the cellular phone.
2. Radio-frequency interference from other equipment through the AC power supply of the equipment and/or system:
Identify the cause of this interference and if possible remove this interference source. If this is not possible, use a different power supply.
3. Effect of direct or indirect electrostatic discharge:
Make sure all users and patients in contact with the equipment and/or system are free from direct or indirect electrostatic energy before using it. A humid room can help lessen this problem.
4. Electromagnetic interference with any radio wave receiver such as radio or television:
If the equipment and/or system interferes with any radio wave receiver, locate the equipment and/or system as far as possible from the radio wave receiver.
5. Interference of lightning:
When lightning occurs near the location where the equipment and/or system is installed, it may induce an excessive voltage in the equipment and/or system. In such a case, disconnect the AC power cord from the equipment and/or system and operate the equipment and/or system by battery power, or use an uninterruptible power supply.
6. Use with other equipment:
When the equipment and/or system is adjacent to or stacked with other equipment, the equipment and/or system may affect the other equipment. Before use, check that the equipment and/or system operates normally with the other equipment.
7. Use of unspecified accessory, transducer and/or cable:
When an unspecified accessory, transducer and/or cable is connected to this equipment and/or system, it may cause increased electromagnetic emission or decreased electromagnetic immunity. The specified configuration of this equipment and/or system complies with the electromagnetic requirements with the specified configuration. Only use this equipment and/or system with the specified configuration.

Caution - continued

8. Use of unspecified configuration:

When the equipment and/or system is used with the unspecified system configuration different than the configuration of EMC testing, it may cause increased electromagnetic emission or decreased electromagnetic immunity. Only use this equipment and/or system with the specified configuration.

9. Measurement with excessive sensitivity:

The equipment and/or system is designed to measure bioelectrical signals with a specified sensitivity. If the equipment and/or system is used with excessive sensitivity, artifact may appear by electromagnetic interference and this may cause mis-diagnosis. When unexpected artifact appears, inspect the surrounding electromagnetic conditions and remove this artifact source.

If the above suggested remedial actions do not solve the problem, consult your Nihon Kohden representative for additional suggestions.

In IEC 60601-1-2 Medical Electronic Equipment, Part 1: General Requirements for Safety, 2. Collateral Standard: Electromagnetic compatibility-Requirements and test. Section 36. 202. 2 Radiated radio-frequency electromagnetic fields, PATIENT COUPLED EQUIPMENT and/or SYSTEMS applicable IMMUNITY test methods are under consideration at SC62A/WG13. The 3 V/m IMMUNITY level may be inappropriate especially when measuring SpO₂ because physiological signals can be much smaller than those induced by a 3 V/m electromagnetic field.

When measuring SpO₂, various interference may produce false waveforms which look like pulse waveforms. SpO₂ value and pulse rate may be measured from these false waveforms, causing the alarm to function improperly.

When installing the monitor, avoid locations where the monitor may receive strong electromagnetic interference such as radio or TV stations, cellular phone or mobile two-way radios.

BSM-6301 and BSM-6501 (JA-690PA/JA-694PA data acquisition unit, QE-910P BIS processor and QI-320PA wireless LAN station are not connected) comply with International Standard IEC 60601-1-2: 2001 and Amendment 1: 2004 which requires CISPR11, Group 1, Class B. Class B EQUIPMENT is equipment suitable for use in domestic establishments and in establishments directly connected to a low voltage power supply network which supplies buildings used for domestic purposes.

BSM-6301, BSM-6501 (JA-690PA/JA-694PA data acquisition unit, QE-910P BIS processor and QI-320PA wireless LAN station are connected) and BSM-6701 comply with International Standard IEC 60601-1-2: 2001 and Amendment 1: 2004 which requires CISPR11, Group 1, Class A. Class A EQUIPMENT is equipment suitable for use in industrial or light industrial establishments and commercial environment.

BSM-6301 and BSM-6501 (when QE-910P and ZS-900P are connected) are CLASS A equipment if the equipment complies with IEC 60601-1-2: 2001 36 201.1.5 in the countries which do not have national wireless rule.

WARNING

Interaction Between Minute Ventilation Rate-Adaptive Pacemakers and Cardiac Monitoring and Diagnostic Equipment*

The bioelectric impedance measurement sensor of a minute ventilation rate-adaptive implantable pacemaker may be affected by cardiac monitoring and diagnostic equipment which is connected to the same patient. If this occurs, the pacemaker may pace at its maximum rate and give incorrect data to the monitor or diagnostic equipment. If this occurs, disconnect the monitor or diagnostic equipment from the patient or change the setting on the pacemaker by referring to the pacemaker's manual. For more details, contact your pacemaker representative or Nihon Kohden representative.

* Minute ventilation is sensed in rate-adaptive pacemakers by a technology known as bioelectric impedance measurement (BIM). Many medical devices in addition to pacemakers use this technology. When one of these devices is used on a patient with an active, minute ventilation rate-adaptive pacemaker, the pacemaker may erroneously interpret the mixture of BIM signals created in the patient, resulting in an elevated pacing rate.

For more information, see the FDA web site.

<http://www.fda.gov/cdrh/safety.html>

Conventions Used in this Manual and Instrument

Warnings, Cautions and Notes

Warnings, cautions and notes are used in this manual to alert or signal the reader to specific information.

WARNING

A warning alerts the user to possible injury or death associated with the use or misuse of the instrument.

CAUTION

A caution alerts the user to possible injury or problems with the instrument associated with its use or misuse such as instrument malfunction, instrument failure, damage to the instrument, or damage to other property.

NOTE

A note provides specific information, in the form of recommendations, prerequisites, alternative methods or supplemental information.

Text Conventions in this Manual

- Names of hard keys on the main unit are enclosed in square brackets: [Menu]
- Messages that are displayed on the screen are enclosed in quotation marks: "CHECK ELECTRODES"
- Names of items that are displayed on the screen are enclosed in angle brackets: <SENSITIVITY>

Explanations of the Symbols in this Manual and Instrument

The following symbols found in this manual/instrument bear the respective descriptions as given.

MU-631R/MU-651R/MU-671R Main Unit

Symbol	Description	Symbol	Description
	“On” only for a part of instrument		Network socket
	“Off” only for a part of instrument		Output terminal
	Alternating current		Equipotential terminal
	Battery charging		Attention, consult operator’s manual
	Out of paper		Serial number
	Record		Date of manufacture
	Alarm silence		BIS processor/BISx
	Attention, consult operator’s manual		Battery slot 1/Battery slot 2 (MU-631R only)
	NIBP		ZS socket
	NIBP interval		CSA mark*
	NIBP start		MR unsafe*
	NIBP stop		The CE mark** is a protected conformity mark of the European Community. Products marked with this symbol comply with the requirements of the Medical Device Directive 93/42/EEC.
	Menu		
	Home		Products marked with this symbol** comply with the European WEEE directive 2002/96/EEC and require separate waste collection. For Nihon Kohden products marked with this symbol, contact your Nihon Kohden representative for disposal.
	Data input/output		
	SD card slot		

* The CSA mark and MR unsafe mark only apply to the MU-631RA/MU-651RA/MU-671RA.

** The CE mark and WEEE mark only apply to the MU-631RK/MU-651RK/MU-671RK.

AY Series Input Unit

Symbol	Description	Symbol	Description
	Defibrillation-proof type CF applied part		Serial number
	Output terminal		Date of manufacture
	The CE mark is a protected conformity mark of the European Community. Products marked with this symbol comply with the requirements of the Medical Device Directive 93/42/EEC.		Attention, consult operator's manual

AA-672P/AA-674P Smart Expansion Unit

Symbol	Description	Symbol	Description
	Defibrillation-proof type CF applied part		Date of manufacture
	Attention, consult operator's manual		The CE mark is a protected conformity mark of the European Community. Products marked with this symbol comply with the requirements of the Medical Device Directive 93/42/EEC.
	Serial number		

QI-631P Interface

Symbol	Description	Symbol	Description
	Serial interface (RS-232C socket)		Attention, consult operator's manual
	External display (RGB socket)		

QI-632P Interface

Symbol	Description	Symbol	Description
	Input/output terminal (USB socket and Multi-link socket)		Attention, consult operator's manual
	Output terminal (Alarm socket)		

QI-634P Interface

Symbol	Description	Symbol	Description
	Input/output terminal (USB socket and Multi-link socket)		Attention, consult operator's manual

QI-671P Interface

Symbol	Description	Symbol	Description
	Input/output terminal (Multi-link socket)		External display (RGB socket)
	Serial interface (RS-232C socket)		Attention, consult operator's manual
	Output (Alarm socket)		

QI-672P Interface

Symbol	Description	Symbol	Description
	Input/output terminal (USB socket and Multi-link socket)		Attention, consult operator's manual

WS-671P Recorder Module

Symbol	Description	Symbol	Description
	Attention, consult operator's manual		The CE mark is a protected conformity mark of the European Community. Products marked with this symbol comply with the requirements of the Medical Device Directive 93/42/EEC.
	Serial number		
	Date of manufacture		

SB-671P Battery Pack

Symbol	Description	Symbol	Description
	Date of manufacture		Recycle mark
	Products marked with this symbol comply with the European WEEE directive 2002/96/EEC and require separate waste collection. For Nihon Kohden products marked with this symbol, contact your Nihon Kohden representative for disposal.		Environmental protection use period: 10 years
			The CE mark is a protected conformity mark of the European Community. Products marked with this symbol comply with the requirements of the Medical Device Directive 93/42/EEC.

On screen

Symbol	Description	Symbol	Description
	Alarm silence		Accessing to SD card
	Alarm suspended		Checking SD card
	All alarms off or vital sign alarm limit off		SD card failure
	Non-paced		Adjust setting/Scroll data

Symbol	Description	Symbol	Description
	QRS/pulse sync mark		Zoom in/Zoom out
	Respiration sync mark		Left end/Right end
	Battery status	@	Touch panel calibration

Related Documentation

The BSM-6301A/K, BSM-6501A/K and BSM-6701A/K bedside monitors come with the following manuals in addition to the operator's manual.

Administrator's Guide

Describes how to install the bedside monitor. It also explains about the password protected settings on the SYSTEM SETUP window and SYSTEM CONFIGURATION screen which only an administrator can change.

User's Guide, Part I

Gives supplemental information on the operation of the bedside monitor.

User's Guide, Part II

Describes the features and settings of the monitoring parameters.

Service Manual

Describes information on servicing the bedside monitor. Only qualified service personnel can service the bedside monitor.

Safety Standards

The safety standard of this bedside monitor is classified as follows:

Type of protection against electrical shock: CLASS I EQUIPMENT (AC Powered)

Internally Powered EQUIPMENT (BATTERY Powered)

Degree of protection against electrical shock

Degree of protection against electrical shock

Defibrillator-proof type CF applied part

AY-631P, AY-633P, AY-651P, AY-653P, AY-661P, AY-663P, AY-671P and AY-673P:

ECG, Respiration (impedance and thermistor method), IBP, Temperature, SpO₂, CO₂, O₂, NIBP, BIS

AY-660P: ECG, Respiration (impedance method), IBP, Temperature, SpO₂, CO₂, NIBP

AA-672P and AA-674P: Respiration (thermistor method), IBP, Temperature, SpO₂, CO₂, O₂, BIS

CF applied part:

AY-631P, AY-633P, AY-651P, AY-653P, AY-661P, AY-663P, AY-671P, AY-673P, AA-672P and AA-674P: CO

Degree of protection against harmful ingress of water: IPX0 (non-protected)

Degree of safety of application in the presence of FLAMMABLE ANAESTHETIC MIXTURE WITH AIR, OR WITH OXYGEN OR NITROUS OXIDE:

Equipment not suitable for use in the presence of FLAMMABLE ANAESTHETIC MIXTURE WITH AIR, OR WITH OXYGEN OR NITROUS OXIDE

Mode of operation: CONTINUOUS OPERATION

Safety Information

This User's Guide only contains safety information related to operation. Full information is in the BSM-6000A/K series Bedside Monitor Operator's Manual (code number: 0614-900685H).

Section 1 General

1

Introduction.....	1.3
General.....	1.3
Applications.....	1.4
Features.....	1.4
Measurement Parameters, and Applicable Units.....	1.6
Composition.....	1.8
Network Composition.....	1.9
Panel Description.....	1.10
MU-631R Main Unit.....	1.10
Front Panel.....	1.10
Left Side Panel.....	1.11
Right Side Panel.....	1.11
Rear Panel.....	1.12
MU-651R/MU-671R Main Unit.....	1.13
Front Panel.....	1.13
Left Side Panel.....	1.14
Right Side Panel.....	1.14
Rear Panel.....	1.15
AY-631P/633P/651P/653P/660P/661P/663P/671P/673P Input Unit.....	1.16
Front Panel.....	1.16
Using MULTI Sockets for CO Monitoring.....	1.16
Using the Output Signal from the ECG/BP OUT Socket.....	1.17
Left Side Panel.....	1.18
Right Side Panel.....	1.18
Rear Panel.....	1.19
AA-672P/AA-674P Smart Expansion Unit.....	1.19
Front Panel.....	1.19
Using MULTI Sockets for CO Monitoring.....	1.20
Right Side Panel.....	1.20
QF series Interface and IF series Communication Cable.....	1.21
RY-910PA Remote Controller.....	1.22
Basic Operating Concepts.....	1.23
Screen Displays.....	1.23
Using Touch Screen Keys.....	1.29
Keys on the Bedside Monitor.....	1.30
Using the Remote Control.....	1.31
Using the Mouse.....	1.31
Using the Data Acquisition Unit.....	1.32
Using the MENU Window.....	1.33
Transport Function.....	1.34
Overview.....	1.34
Requirements.....	1.34
Necessary Settings Before Use.....	1.34

Transported Data and Settings.....	1.35
Sending Data to a CNS-9701 Central Monitor	1.36
Patient Authentication.....	1.37
Preparing for Removing the Input Unit	1.41
Enabling the Input Unit	1.42
When the Input Unit is Disabled.....	1.42
Enabling the Input Unit.....	1.42

Introduction

1

General

The Life Scope TR BSM-6301A/K, BSM-6501A/K and BSM-6701A/K bedside monitors are for one patient. You can combine the monitor with other units and options depending on the measurement parameters and use the monitor in a wide range of sites such as the operating rooms and intensive care unit (ICU).

You can also connect this monitor to a network to communicate with a central monitor and other bedside monitors.

The BSM-6301A/K bedside monitor has a 10.4 inch TFT color display, BSM-6501A/K has a 12.1 inch TFT color display, and BSM-6701A/K has a 15 inch TFT color display. All models can display 15 waveforms on the screen.

For simplicity, the suffix A/G/K will be omitted in this manual.

WARNING

Do not diagnose a patient based on only part of the monitoring data on the bedside monitor or only on the data acquired by the bedside monitor. Overall judgement must be performed by a physician who understands the features, limitations and characteristics of the bedside monitor by reading this user's guide thoroughly and by reading the biomedical signals acquired by other instruments.

WARNING

Do not use the same monitor for more than one patient at the same time. Do not connect different sensors from different patients to the same monitor.

NOTE

- Upgrade the main unit and each optional unit to the Nihon Kohden recommended software version. Only use the specified configuration of units. If more than one BSM-6000 series bedside monitor is used in the same facility, make sure the bedside monitors have the same software version. If BSM-6000 series monitors with different software versions are used together, correct system operation cannot be guaranteed.
- Be sure to have the administrator change settings for system operation to modify purposes of system use or relocate the system, or have any changes checked by the administrator. Inappropriate changes may result in unsuitable monitoring or a missed alarm.

Applications

This system monitors biological information on a patient in an operating room, recovery room, ICU, CCU, HCU, NICU or emergency room.

Features

- **Components**

You can connect an input unit, smart expansion unit, interface and other options to the main unit.

- **Use of MULTI sockets**

The MULTI sockets allow you to flexibly connect different parameters.

- **Touch screen display**

The wide angle TFT color display can display measurement values and up to 15 waveforms. You can operate the monitor by touching the screen.

- **Use of remote control (Section 2)**

The remote control allows operation at a distance.

- **Telemetry system (Administrator's Guide)**

When the optional ZS-900P* transmitter is connected to the bedside monitor, waveform(s) and parameter data from the bedside monitor can be sent to a cardiac telemetry system or to a central monitor via a multiple patient receiver. (Available waveforms and parameter data depend on the receiving monitor. CO, O₂ and anesthetic gas data cannot be transmitted.)

* ZS-900P is not available for BSM-6000A series.

- **Available network connection (Administrator's Guide)**

You can connect this system via a 10/1000BASE-T LAN cable to a network to communicate with the central monitor and other devices.

- **Available backup battery**

When an SB-671P battery pack (option) is installed in the monitor, there is a sudden power failure or during patient transfer, the monitor can be operated continuously on battery power.

- **Home screen (Administrator's Guide)**

You can change the home screen display according to the needs of your facility.

- **Trendgraphs and OCRG display on the home screen (Administrator's Guide)**

The home screen displays trendgraphs of measured values and waveforms so you can easily identify changes in the patient condition. When a neonate is monitored, OCRG can also be displayed instead of trendgraphs.

- **Review information (Section 6)**

This system provides the capability to display review information as trends, arrhythmia recall and full disclosure waveforms.

- **Thermal array recorder (Section 10)**
You can install a WS-671P recorder module (option) to record up to three waveforms and reports.
- **Multi arrhythmia analysis mode (User's Guide Part II, Section 1)**
The multi arrhythmia analysis mode allows you to analyze arrhythmia more accurately.
- **ECG window (User's Guide Part II, Section 1)**
This system displays QRS waveforms of the normal waveform as the dominant QRS, allowing you to check analysis accuracy.
- **12 lead analysis (Section 7)**
When the 10-electrode ECG is monitored, you can display standard 12 lead ECG. 12 lead interpretation is provided.
- **Function keys (Administrator's Guide)**
You can register frequently used operations to function key.
- **Different site setting (Administrator's Guide)**
You can set different settings for different sites (OR, ICU and NICU).

Standard components

- MU-631R, MU-651R, MU-671R main unit
- QI-631P, QI-632P, QI-634P, QI-671P, QI-672P interface
- AY-631P, AY-633P, AY-651P, AY-653P, AY-660P*, AY-661P*, AY-663P*, AY-671P, AY-673P input unit
* AY-660P, AY-661P and AY-663P input units are not available for BSM-6000A series.
- AA-672P, AA-674P smart expansion unit
- WS-671P recorder module
- SB-671P battery pack

NOTE

When AY-660P input unit is used, the AA-672P or AA-674P smart expansion unit cannot be used.

When an AY-600P series input unit has a QM-600P memory unit installed, the data of the bedside monitor can be saved and sent to another bedside monitor. For details, refer to the "Transport Function" section.

Measurement Parameters, and Applicable Units

Measurement Parameters		Applicable Units		
		AY series Input Unit	QI-632P QI-634P QI-671P QI-672P Interface	Other Units
ECG		OK	—	—
Respiration	Impedance method	OK	—	—
	Thermistor method	OK ^{*1}	—	—
CO ₂	Mainstream	OK ^{*1}	—	—
	Sidestream	—	OK	• AG-400R CO₂ unit^{*3} • AG-920R multigas unit • GF-110PA multigas unit • GF-120PA multigas/flow unit^{*3} • GF-210R multigas unit^{*3} • GF-220R multigas/flow unit^{*3}
SpO ₂		OK	—	—
NIBP		OK	—	—
IBP		OK ^{*1}	—	—
Temperature	TEMP socket	OK	—	—
	MULTI socket	OK ^{*1}	—	—
BIS	MULTI socket	—	OK	• YJ-671P BISx connection cable • QE-910P BIS processor/BISx
	Multi-link socket	—	OK	External instrument
Cardiac output		OK ^{*1}	OK	—
Anesthetic gas ^{*2}		—	OK	• AG-920R multigas unit • GF-110PA multigas unit • GF-120PA multigas/flow unit^{*3} • GF-210R multigas unit^{*3} • GF-220R multigas/flow unit^{*3}
O ₂		OK ^{*1}	—	• AG-920R multigas unit • GF-110PA multigas unit • GF-120PA multigas/flow unit^{*3} • GF-210R multigas unit^{*3} • GF-220R multigas/flow unit^{*3}
Ventilation		—	OK	External instrument
TOF		—	OK	External instrument
CCO		—	OK	External instrument
FLOW/Paw		—	OK	• GF-120PA multigas/flow unit^{*3} • GF-220R multigas/flow unit^{*3}
EEG		—	OK	AE-918P neuro unit ^{*3}
tcPO ₂ /tcPCO ₂		—	OK	External instrument

^{*1} These parameters cannot be measured by the MULTI sockets on the AY-660P input unit, but can be measured by the MULTI sockets on the JA-694PA data acquisition unit.

^{*2} RR, CO₂ (Sidestream), O₂, N₂O, AGENT, MAC and FLOW/Paw can be measured.

^{*3} These units are not available for BSM-6000A series.

Differences Between the Input Unit Models

Input Unit Model	AY-631P	AY-633P	AY-651P	AY-653P	AY-660P*1	AY-661P*1 AY-671P	AY-663P*1 AY-673P
No. of MULTI sockets	1	3	1	3	1	1	3
Available parameters using MULTI sockets	RESP (Thermistor), CO ₂ , SpO ₂ , IBP, TEMP, BIS, CO, O ₂				CO ₂ , IBP	RESP (Thermistor), CO ₂ , SpO ₂ , IBP, TEMP, BIS, CO, O ₂	
No. of TEMP sockets	2				1	2	
ECG measurement using 10 electrodes	Yes				No	Yes	
12 lead analysis	Yes				No	Yes	
SpO ₂ probe	Masimo		Nellcor		Nihon Kohden		
Dual SpO ₂	Yes*2		Yes*3		Yes*4	Yes*5	
NIBP PWTT measurement	No				Yes		
Smart expansion unit	Yes				No	Yes	
Analog ECG							
Analog BP							
HT output							

*¹ AY-660P, AY-661P and AY-663P input units are not available for BSM-6000A series.


*² IF-925P communication cable is required.

*³ IF-919P communication cable is required.

*⁴ Dual SpO₂ is available when the MULTI socket on the JA-694PA data acquisition unit is used.

*⁵ JL-500P1 or JL-500P2 SpO₂ adapter is required.

Composition



* These units are not available for BSM-6000A series.


** This unit is only available for BSM-6000A series.

Network Composition

In a central monitor network, on a central monitor, you can see data of any bed in the network.

The data that can be displayed on the bedside monitor or central monitor depends on the type of bedside or central monitor used.

The number of central monitors and bedside monitors that can be connected to a central monitor network and the network communication method depends on the type of monitor used. For details, refer to the Network and System Installation Guide.



WARNING

Install all network devices, including printer and hubs, outside the patient environment (IEC 60601-1-1). If they are installed inside the patient environment, the patient or operator may receive electrical shock or injury. For installation, contact your Nihon Kohden representative.


WARNING

Check the software version number of the monitor before connecting it to the network. Different software versions have different communication methods. More than one communication method in a network may cause communication failure. For details, refer to the Network and System Installation Guide.

Panel Description

MU-631R Main Unit

Front Panel



1 Touch screen

Displays monitoring data. Touching a key or data on the screen changes the displayed screen and settings.

2 Alarm indicator

Red or yellow lamp blinks, or yellow or cyan lamps lights according to the alarm settings. Green lamp blinks in synchronization with the patient's QRS or pulse.

3 Handle

For carrying the monitor.

4 Silence Alarms key

Silences the alarm sound.

5 NIBP Interval key

Selects NIBP measurement mode. Pressing this key changes the mode.

6 NIBP Start/Stop key

Starts NIBP measurement in selected mode. Pressing the key during measurement stops measurement.

7 Menu key

Displays the MENU window.

8 Home key

Closes all opened windows and displays the home screen.

9 Power switch

Press to turn the monitor power on. When turning the monitor power off, press and hold for more than three seconds.

10 Power lamp

Lights when the monitor power is turned on.

11 AC power lamp

Lights when the power cord is connected between the AC SOURCE socket and AC outlet.

12 Battery lamp 1

Indicates a battery status of the battery in the battery slot 1.

13 Battery lamp 2

Indicates a battery status of the battery in the battery slot 2.

14 Remote control sensor

Receives an infrared signal from the remote control.

15 ERROR lamp (option)

Blinks when out of paper. Lights when the recorder door is open.


16 RECORD/STOP key (option)

Press to start or stop recording.


17 Speaker

For alarms and sync sound.

Left Side Panel




Right Side Panel



1. GENERAL

Rear Panel

Example shows the QI-631P and QI-632P interfaces installed.



1 QI-632P/QI-634P interface socket
Connects the QI-632P or QI-634P interface.

2 QI-631P interface socket
Connects the QI-631P interface.

3 AC SOURCE power cord socket
For the AC power cord.

4 Equipotential grounding terminal
For an equipotential grounding lead.

5 USB socket (QI-632P/QI-634P)
Connects a mouse or bar code reader.

6 Multi-link socket (QI-632P/QI-634P)
Connects a QF series interface, IF series communication cable or multi-link cable of an external unit.


7 Alarm socket (QI-632P)
Connects a YJ-672P nurse call cable.

8 RS-232C socket (QI-631P)
Connects a YJ-672P nurse call cable.

9 RGB socket (QI-631P)
Outputs the RGB video signal. Connects to the slave display.

MU-651R/MU-671R Main Unit

Front Panel



1 Touch screen

Displays monitoring data. Touching a key or data on the screen changes the displayed screen and settings.

2 Alarm indicator

Red or yellow lamp blinks, or yellow or cyan lamps lights according to the alarm settings. Green lamp blinks in synchronization with the patient's QRS or pulse.

3 Handle

For carrying the monitor.

4 Silence Alarms key

Silences the alarm sound.

5 NIBP Interval key

Selects NIBP measurement mode. Pressing this key changes the mode.

6 NIBP Start/Stop key

Starts NIBP measurement in selected mode. Pressing the key during measurement stops measurement.

7 Menu key

Displays the MENU window.

8 Home key

Closes all opened windows and displays the home screen.

9 Power switch

Press to turn the monitor power on. When turning the monitor power off, press and hold for more than three seconds.

10 Power lamp

Lights when the monitor power is turned on.

11 AC power lamp

Lights when the power cord is connected between the AC SOURCE socket and AC outlet.

12 Battery lamp 1

Indicates a battery status of the battery in the battery slot 1.

13 Battery lamp 2

Indicates a battery status of the battery in the battery slot 2.

14 Remote control sensor

Receives an infrared signal from the remote control.

15 ERROR lamp (option)

Blinks when out of paper. Lights when the recorder door is open.

16 RECORD/STOP key (option)


Press to start or stop recording.

17 Speaker


For alarms and sync sound.

1. GENERAL

Left Side Panel





Right Side Panel



Rear Panel

When the optional interface is connected



1 QI-672P interface socket

Connects the QI-672P interface.

2 QI-671P interface socket

Connects the QI-671P interface.

3 AC SOURCE power cord socket

For the AC power cord.

4 Equipotential grounding terminal

For an equipotential grounding lead.

5 USB sockets

Connects to a mouse or bar code reader.

6 Multi-link sockets

Connects a QF series interface, IF series communication cable or multi-link cable of an external unit.

7 Multi-link sockets

Connects a QF series interface, IF series communication cable or multi-link cable of an external unit.

8 RS-232C socket

Not available.

9 Alarm socket

Connects a YJ-672P nurse call cable.

10 RGB socket

Outputs the RGB video signal. Connects to the dual display or slave display.


1. GENERAL

AY-631P/633P/651P/653P/660P/661P/663P/671P/673P Input Unit

Front Panel


One MULTI socket

Example is AY-671P input unit.



Three MULTI sockets

Example is AY-673P input unit.



NOTE

- AY-660P, AY-661P and AY-663P input units are not available for BSM-6000A series.
- With the MULTI socket on the AY-660P input unit, either IBP or CO₂ can be monitored.

1 MULTI socket

Connects to the connection cord of the parameter to be monitored (IBP, temperature, CO, CO₂, SpO₂-2 (AY-661P, AY-663P, AY-671P or AY-673P only), O₂, respiration by thermistor method or BIS). The type of parameter is automatically recognized.

2 TEMP socket

Connects to the temperature probe cable.

3 SpO₂ socket

Connects to the SpO₂ connection cord.

4 ECG/RESP socket

Connects to the ECG connection cord.

5 ECG/BP OUT socket

Outputs 100 mmHg/V IBP waveform and 1 mV/V ECG waveform by using the YJ-910P or YJ-920P ECG/BP output cable. These analog signals can be used as the synchronization signal for other equipment, such as IABP.

6 NIBP socket

Connects to the air hose.

WARNING

Connect only the specified instrument to the monitor and follow the specified procedure. Failure to follow this warning may result in electrical shock or injury to the patient and operator, and cause fire or instrument malfunction.

Using MULTI Sockets for CO Monitoring

WARNING

When performing defibrillation during cardiac output monitoring, never touch the CO connection cord. The discharged energy may cause electrical shock or injury.

NOTE

CO monitoring using the MULTI socket does not comply with the defibrillator proof type CF.

Using the Output Signal from the ECG/BP OUT Socket

CAUTION

When using the output signal from the monitor as the synchronization signal for other equipment such as an IABP (intra-aortic balloon pump) or defibrillator:

- Set the timing of the IABP by checking the waveform on the IABP screen.
- Check the condition of the bedside monitor at all times. The output signal may become unstable.
- Check that the delay time of the output signal is within the range of the connected equipment.

CAUTION

Only a Nihon Kohden defibrillator can use the output signal from the monitor as a synchronization signal. Check that the delay time of the output signal (heart rate trigger 20 ms maximum) is within the range of the connected defibrillator.

NOTE


- When using an IBP waveform as a synchronization signal for other equipment, connect the IBP line to the MULTI socket on the input unit. The IBP waveform that is used for the synchronization signal depends on the "IBP ANALOG OUT" setting in the SYSTEM SETUP window.
 - When "IBP ANALOG OUT" is set to "FIXED POSITION":
The IBP line connected to the top MULTI socket on the input unit is used.
 - When "IBP ANALOG OUT" is set to "HIGHEST PRIORITY LABEL":
When more than one IBP waveform is acquired, the IBP waveform of the highest priority label is used.
IBP label priority:
ART > ART2 > RAD > DORS > AO > FEM > UA > LVP > P1 > P2 > P3 > P4 > P5 > P6 > P7
- The output signal from the ECG/BP OUT socket may become unstable in the following conditions.
 - Electrode is dry or detached.
 - Electrode lead is damaged or disconnected from the electrode.
 - Electrode lead is pulled.
 - AC interference or EMG noise superimposed.
 - Air bubbles or blood clog in the circuit for monitoring IBP.
 - Cord or cable is disconnected or damaged.
- All instruments which are to be connected to the ECG/BP OUTPUT socket must use a YJ-910P or YJ-920P ECG/BP output cable and comply with the IEC 60601-1 safety standard for medical equipment.
- When using an IABP, set <CALCULATION METHOD> on the OTHER page of the PRESS window to "PEAK" to improve measurement accuracy.

Output Signal Delay Time

Output Signal	Delay Time
ECG	maximum 20 ms
IBP	maximum 40 ms
Heart rate trigger	maximum 20 ms

1. GENERAL

Left Side Panel




1 Side panel

Remove to attach an AA-672P or AA-674P smart expansion unit.

2 Smart expansion unit socket


Connects an AA-672P or AA-674P smart expansion unit.

Right Side Panel



1 Tabs

Match the tabs on the input unit to the slots on the bedside monitor.

Rear Panel**1 Lock release lever**


Lift up the lever to remove the input unit from the bedside monitor.

2 Input unit socket

For connecting a bedside monitor.

AA-672P/AA-674P Smart Expansion Unit**NOTE**

AA-672P or AA-674P smart expansion unit cannot be used with AY-660P input unit.

Front Panel**1 MULTI socket**

Connect to the connection cord of the parameter to be monitored (Respiration by thermistor method, CO₂, SpO₂-2 (only when an AY-661P, AY-663P, AY-671P or AY-673P input unit is used), IBP, temperature, CO, O₂ or BIS). The type of parameter is automatically recognized.

1. GENERAL

Using MULTI Sockets for CO Monitoring


WARNING

When performing defibrillation during cardiac output monitoring, never touch the CO connection cord. The discharged energy may cause electrical shock or injury.

NOTE


CO monitoring using the MULTI socket does not comply with the defibrillator proof type CF.

Right Side Panel



1 Connector

Connects an AY-631P, AY-633P, AY-651P, AY-653P, AY-661P, AY-663P, AY-671P or AY-673P input unit.

QF series Interface and IF series Communication Cable**1 Multi-link connector**


Connect to the multi-link socket on the bedside monitor.

2 External device connector

Connect to an external device.

3 Ferrite core

RY-910PA Remote Controller



1 Power button

When the power cord is connected between the bedside monitor and AC outlet, turns the monitor power on or off.

2 MENU/HOME key

Opens the MENU window. Closes the window and displays the home screen when a window is opened.

3 DISPLAY SELECT key

Not available.

4 Strap hole

Use a strap to prevent dropping the remote control.

5 Display

Displays the channel number and the display number.

6 Selection knob

Move this knob up/down/left/right to move the cursor or mouse pointer on the screen.

7 LED

Lights when the pointer on the screen is moved by the selection knob. Blinks when a key on the remote control is pressed.

8 SILENCE ALARMS key

Silences the alarm sound.

9 Customized keys

Windows and functions can be assigned to each key for shortcut key operations.

10 CHANNEL keys

Select the monitor when a channel is assigned to the monitor.

11 Transmitter

Signal is transmitted from here. Point the transmitter to the remote control sensor on the bedside monitor when operating the monitor with the remote control.

12 ENTER key

Registers the setting selected on the screen.

Basic Operating Concepts

1

Screen Displays


Following are the screens and windows available on the Life Scope TR bedside monitor. For details about the individual screens and windows, see the appropriate section.

The shadow of the previous screen may remain for a few minutes after changing the screen.

Normally, the home screen is displayed. All screens, except for the LARGE NUMERICS screen, 12 LEAD ANALYSIS window and SYSTEM CONFIGURATION screen, return to the home screen when there is no key operation for about 3 minutes.

Home screen


Home



- The home screen can be displayed anytime by pressing the [Home] key on the bedside monitor.
- Displays waveforms and data of the monitoring parameters.
- Touching the patient name displays the ADMIT page for changing patient information.
- Touching the parameter data displays the parameter setting window.

MENU window

Menu




The MENU window can be displayed anytime by pressing the [Menu] key on the bedside monitor. From the MENU window, you can display any window except the home screen.


1. GENERAL

Other windows for monitoring


ENLARGED window for displaying numeric data



12 LEAD ANALYSIS window for displaying simultaneous 12 lead ECG. 12 lead ECG interpretation can be performed. Only available when the site mode is OR or ICU.



SLEEP window for turning sleep mode on.




Review windows


- TREND GRAPH page for displaying 24 hour trendgraphs of up to 6 selected parameters.
- TREND TABLE page for displaying table of parameter data.
- NIBP page for displaying vital signs data with NIBP measurement.
- HEMO page for displaying hemodynamics data when CO is measured.
- LUNG TREND page for displaying lung function measurement data.




ARRHYTHM RECALL window for displaying arrhythmia recall data.



ALARM HISTORY window for displaying vital sign data at alarm occurrence.




FULL DISC window for displaying full disclosure waveforms. Up to 5 parameters can be saved.




1. GENERAL

ST window for displaying ST level recall waveforms. ST measurement condition can be changed.




12 LEAD window for displaying 12 lead ECG interpretation and analysis result data.

Only available when the site mode is OR or ICU.




OCRG window for displaying OCRG trendgraph.

Only available when the site mode is NICU.




ADMIT window

ADMIT window for admitting a patient. Data can be deleted on this window.




Alarm setting window

ALARM LIMITS window for setting vital signs alarm and ARRHYTHM ALARMS window for setting arrhythmia alarms.




Parameter setting windows

For changing parameter monitoring settings. Example is ECG window. FLOW/Paw and EEG are not available for BSM-6000A series.




Interbed window

For displaying interbed beds when the monitor is connected to a network.



Drug calculation window


For registering drug and units, calculating drug and displaying the table of the selected drug titration.




1. GENERAL

Setup and other windows

- DATE window for changing date and time
- VOLUME window for changing alarm and sync sound volume
- DISPLAY window for setting number of ECG waveforms on the home screen, PRESS waveform display type, waveform sweep speed, and respiration/CO₂ waveform sweep speed
- RECORD window for setting recording parameters
- SYSTEM window for checking assigned functions to the remote control keys






TOUCH KEYS OFF window for turning touch screen function off



Using Touch Screen Keys

Any window can be opened and settings can be changed by touching the keys and items on the screen with your finger. Touching the key on the screen displays the window. You can use the scroll bar on the screen to scroll data on the window.

There is a pip sound when a key or screen is touched, or the scroll bar on the screen is used.




Tabs for changing displaying window

Selected items are highlighted

Setting bar
Touch or drag the sliders to the desired level on the setting bar.

Upper limit slider

Lower limit slider





Cursor

Scroll bar


Scroll keys

1. GENERAL



The time width of the trendgraph on the home screen can be adjusted by touching the right edge of the trendgraph and dragging it left or right.

Keys on the Bedside Monitor




Using the Remote Control

Use the RY-910PA remote controller to operate the monitor from a distance. A pointer appears on the screen when the monitor is operated by the remote control. The remote control channel can be assigned to the monitor to prevent operating a different monitor. Point the remote control at the remote control sensor on the bedside monitor.

Press the keys on the remote control to open/close a window. Move the selection knob up/down/left/right to scroll the data or select a setting and press the [ENTER] key to register the setting.

There is a pip sound when a key on the remote control is pressed or the selection knob is moved to scroll the data.




NOTE

- Watch the monitor screen and check the operation when using the remote control to avoid wrong operation.
- Make sure that the remote control is handled appropriately.

Using the Mouse


When connecting a QI-632P, QI-634P or QI-672P interface, use the mouse to move the pointer on the screen and click the left button to select and register the setting.

There is a pip sound when the mouse is clicked.



Using the Data Acquisition Unit

With the JA-690PA or JA-694PA data acquisition unit, you can use an input unit that is separate from the bedside monitor. With the keys on the data acquisition unit, you can operate the bedside monitor remotely. For details, refer to the JA-690PA or JA-694PA data acquisition unit manual.




Using the MENU Window

The MENU window can be displayed anytime by pressing the [Menu] key on the bedside monitor. From the MENU window, you can display any window except the home screen. The MENU window layout differs according to the selected site. Refer to “SITE Window” in Administrator’s Guide, Section 2.


For details on each window, refer to the section specified below.

When the site mode is OR or ICU



For the alarm off key on the MENU window, refer to “Silencing and Suspending Alarms” in Section 5.

When the site mode is NICU



Transport Function

Overview

The monitor has a transport function. Patient information and review data can be sent to another bed by disconnecting the input unit from the monitor or JA-690PA or JA-694PA data acquisition unit and connecting it into another monitor or data acquisition unit.

If the original monitor and destination monitors are in the same central monitor network, you can observe the transported patient continuously from the central monitor.

Requirements

NOTE

- Transport function not using the network is available with BSM-6000 series bedside monitor software version 02-01 or later.
- Transport function using the network is available with BSM-6000 series bedside monitor software version 02-02 or later.
- If the BSM-6000 series bedside monitors have different software version, transport function cannot be used.
- Transport function using BSM-9101 bedside monitor is available with BSM-6000 series bedside monitor software version 02-03 or later.
- A QM-600P memory unit must be installed in the input unit to use the transport function.

Necessary Settings Before Use

CAUTION

If the patient data in the input unit has different measuring units from the data in the main unit, an INPUT UNIT ERROR dialog box to delete the data in the input unit appears. If you do not want to delete the data in the input unit, touch the CANCEL key and remove the input unit from the main unit.

CAUTION

When installing the monitor, change the time zone setting to the same setting as the other bedside monitors and central monitors. If the time zone setting is not the same, the data which was in the input unit before transport is deleted when using the transport function with the input unit.

NOTE

- When <DATA TRANSPORT USING INPUT UNIT> on the TRANSPORT window of the SYSTEM CONFIGURATION screen is set to ENABLE, AUTO ADMIT is fixed to OFF. Refer to Section 2 of the Administrator's Guide.
- The unit settings must be the same on the input unit and main unit to use the transport function. Refer to "UNITS Window" in Administrator's Guide, Section 2.

When <DATA TRANSPORT USING INPUT UNIT> on the TRANSPORT window of the SYSTEM CONFIGURATION screen is set to ENABLE, the patient data are saved in the optional QM-600P memory unit in the input unit.

Select ON or OFF on <USE SETTINGS IN INPUT UNIT> on the TRANSPORT window of the SYSTEM CONFIGURATION screen to select whether to use the settings on the original monitor at the destination monitor. Select ON or OFF according to the operating environment. Refer to "TRANSPORT Window" in Administrator's Guide, Section 2 for the settings which can be used on the destination monitor.

Transported Data and Settings

The following settings and data are saved in the QM-600P memory unit in the input unit. Review data of past 24 hours can be sent.

The settings sent from the original monitor to the destination monitor depend on <USE SETTINGS IN INPUT UNIT> on the TRANSPORT window of the SYSTEM CONFIGURATION screen. Refer to "TRANSPORT Window" in Administrator's Guide, Section 2.

Settings

- Patient information (patient ID, name, date of birth, height, weight and gender)
- Pacing detection On or Off
- QRS detection type
- Arrhythmia analysis On or Off
- Vital sign upper/lower alarm limits settings
- Arrhythmia alarms settings
- Parameters to be saved for full disclosure and ECG lead settings of TRACE 1 and TRACE 2

Review data

NOTE

- The oldest file is deleted when the maximum number of files is saved.
- PCCO, ScvO₂, SVV, EDV, EDVI, ESV, ESVI, EF, PPV and SPV data on the GRAPH 1 to GRAPH 3 pages and TABLE 1 to TABLE 3 pages of the TREND window cannot be saved in the input unit and cannot be sent.
- EEG (monitored with the AE-918P neuro unit), SEF, MDF, PPF and TP data cannot be saved in the input unit and cannot be sent.

1. GENERAL

- When you enable the transport function, set the <SELECT THE WAVE TO SAVE AND DISPLAY> setting on the FULL DISC window on both the original monitor and the destination monitor to the same setting.
- Review data on the TREND windows
- Review data on the RECALL window
- Review data on the ALARM HISTORY window
- Full disclosure waveform (First trace of ECG and the four other waveforms selected on the FULL DISC window)
- Review data on the ST window
- Review data on the 12 LEAD window

Sending Data to a CNS-9701 Central Monitor

Review data of the past 24 hours can be sent to a CNS-9701 central monitor.

WARNING

When using transport function, patient data may be mixed together or lost in the following cases:

- Transport function and wireless LAN are used at the same time.
- The network cable is connected or disconnected from the bedside monitor or the input unit is removed while the bedside monitor power is off.

WARNING

When you send data from the bedside monitor to the central monitor, use a 10BASE-T or 100BASE-TX switching hub. If you use another type of hub, the network may lose connection and the patient cannot be monitored on the central monitor.

CAUTION

Do not remove the input unit while the data is being sent to the central monitor. The data may be lost.

NOTE

The transport function is available with CNS-9701 central monitor software version 01-77 or later.

Review data

NOTE

- The oldest file is deleted when the maximum number of files are saved.
- When you enable the transport function, set the saved waveform setting of the original monitor, destination monitor and the central monitor to the same setting.
- PCCO, ScvO₂, SVV, EDV, EDVI, ESV, ESVI, EF, PPV and SPV data on the GRAPH 1 to GRAPH 3 pages and TABLE 1 to TABLE 3 pages of the TREND window cannot be sent to another bed with the input unit.
- EEG (monitored with the AE-918P neuro unit), SEF, MDF, PPF and TP data cannot be saved in the input unit and cannot be sent.

- Data on the NIBP TREND page
- Data on the TABLE 1 to TABLE 3 pages
- Data on the GRAPH 1 to GRAPH 3 pages
- Data on the HEMO page
- Data on the RECALL window
- Full disclosure waveform (First trace of ECG and the four other waveforms selected on the FULL DISC window)
- Review data on the ST window
- Data on the 12 LEAD window

If the input unit is removed from a monitor and connected to a monitor in a central monitor network, the “SENDING DATA” message appears while the data is being sent.

Patient Authentication

The SELECT PATIENT DATA window appears when the input unit is inserted into the monitor or the monitor is turned on when the transport function is enabled.

Authenticate the patient on the SELECT PATIENT DATA window and select the monitoring patient.

- Use the patient information in the input unit (the data saved in the QM-600P memory unit installed in the input unit)
- Use the patient information in the main unit (the data saved in the main unit)
- Start monitoring as a new patient

WARNING

When the input unit is connected to the monitor, make sure to authenticate the patient on the SELECT PATIENT DATA window. Otherwise, monitoring cannot be started.

WARNING

Check the patient information and data range on the SELECT PATIENT DATA window. Otherwise, the patient may be incorrectly identified.

WARNING

Check the alarm settings after patient authentication. The alarm settings depend on the <USE SETTINGS IN INPUT UNIT> ON/OFF setting on the TRANSPORT window of the SYSTEM CONFIGURATION screen of the destination monitor.

1. GENERAL

1. Insert the input unit into the monitor and turn the power on. The SELECT PATIENT DATA (INPUT UNIT) window appears.

SELECT PATIENT DATA (INPUT UNIT)

Patient information in the input unit:

PATIENT ID	000-000-2	NAME	MARY SMITH	
DATE OF BIRTH	1955-01-30	HEIGHT/WEIGHT	170.0 [cm]	65.0 [kg]
AGE	54 YEAR(S)	5 MONTH(S)	GENDER	FEMALE

Data Range: 18-07-2009 17:15 to 18-07-2009 17:28

Confirm the Patient Information.

Touch YES to Use Patient Data
From the Input Unit
Touch NO to Delete Patient Data
in the input unit

CONFIRM ALARM SETTINGS PRIOR TO MONITORING PATIENT.

CAUTION


If the patient data in the input unit has different measuring units from the data in the main unit, an INPUT UNIT ERROR dialog box to delete the data in the input unit appears. If you do not want to delete the data in the input unit, touch the CANCEL key and remove the input unit from the main unit.

INPUT UNIT ERROR


The patient data in the input unit
has different measuring units
from the data in the main unit.
The data in the input unit
will be deleted.

NOTE

- The unit settings must be the same on the input unit and main unit to use the transport function. Refer to “UNITS Window” in Administrator’s Guide, Section 2.
- If the patient data in the input unit is damaged, an INPUT UNIT ERROR dialog box appears. If the data in the input unit is not required, touch the OK key to display the SELECT PATIENT DATA (MAIN UNIT) window and select whether to use the data in the main unit.



- If the input unit and main unit have different software versions, an INPUT UNIT ERROR dialog box to delete the data in the input unit appears. If you do not want to delete the data in the input unit, touch the CANCEL key and remove the input unit from the main unit.



If an input unit without a QM-600P memory unit is inserted into the monitor, the SELECT PATIENT DATA (MAIN UNIT) window appears. Do step 3 and select whether to use the data in the main unit.

2. Confirm the patient information and data range on the SELECT PATIENT DATA (INPUT UNIT) window and select whether to use the data in the input unit.
 - To use the data in the input unit or only use the data in the input unit and edit the patient information
Touch the YES key and start monitoring.
 - To use the data in the main unit or start monitoring as a new patient
Touch the NO key to display the SELECT PATIENT DATA (MAIN UNIT) window.

NOTE

If the patient information in the input unit and main unit are the same, a SELECT PATIENT DATA (INPUT UNIT) window appears. If you need to start monitoring as a new patient, touch the OK key and delete the data on the DELETE DATA page of the ADMIT window.

Patient information in the input unit

Data range of the review data in the input unit

SELECT PATIENT DATA (INPUT UNIT)

Patient information in the input unit:

PATIENT ID	000-000-1	NAME	JOHN SMITH	
DATE OF BIRTH	1960-01-31	HEIGHT/WEIGHT	180.0 [cm]	80.0 [kg]
AGE	49 YEAR(S)	4 MONTH(S)	GENDER	MALE

Data Range: 18-06-2009 17:06 to 18-06-2009 17:11

Confirm the Patient Information.

OK

CONFIRM ALARM SETTINGS PRIOR TO MONITORING PATIENT.

3. Check the patient information and data range on the SELECT PATIENT DATA (MAIN UNIT) window and select whether to use the data in the main unit.
- To use the data in the main unit
Touch the YES key and start monitoring.
 - To start monitoring as a new patient
Touch the NO key and display the PATIENT INFO page of the ADMIT window to start monitoring as a new patient.

Patient information in the main unit

Data range of the review data in the main unit

SELECT PATIENT DATA (MAIN UNIT)

Patient information in the main unit:

PATIENT ID	000-000-1	NAME	JOHN SMITH	
DATE OF BIRTH	1960-01-31	HEIGHT/WEIGHT	180.0 [cm]	80.0 [kg]
AGE	49 YEAR(S)	4 MONTH(S)	GENDER	MALE

Data Range: 18-07-2009 15:19 to 18-07-2009 17:31

Confirm the Patient Information.

Touch YES to Use Patient Data From Bedside Monitor.
Touch NO to Delete Patient Data in Bedside Monitor

YESBACKNO

CONFIRM ALARM SETTINGS PRIOR TO MONITORING PATIENT.

YES: Use the data in the main unit and start monitoring.
NO: Display the PATIENT INFO page and start monitoring as a new patient.
BACK: Returns to the SELECT PATIENT DATA (INPUT UNIT) window.

The BACK key is displayed only when there is data in the input unit.

Preparing for Removing the Input Unit

When the transport function is enabled, perform the following procedure before removing the input unit from the monitor.

WARNING

The monitor cannot start monitoring when the input unit is not ready. When the preparation for removing the input unit is complete, immediately insert the input unit into the destination monitor.

CAUTION

When removing the input unit from the monitor when the transport function is enabled, perform the removal procedure of the input unit on the REMOVE page of the TRANSPORT DATA window before removing the input unit. Otherwise, the data in the input unit may be lost.

NOTE


If you removed the input unit but you will not transfer the patient, reinsert the input unit into the original monitor and enable the input unit.

1. Display the REMOVE page.

Press the [Menu] key → ADMIT key → TRANSPORT DATA tab → REMOVE tab.


NOTE

- When the patient is discharged and there is no need to send the patient data to the central monitor, removing the input unit from the bedside monitor is not necessary.
- If the QM-600P memory unit is not installed in the input unit or the memory unit is damaged, the following message appears when the REMOVE page is displayed: "This input unit has no memory unit or the memory unit is damaged. Data cannot be transferred to another bed with this input unit."



Message


2. Touch the YES key to remove the input unit.



1. GENERAL

When the NO key is touched, it returns to the home screen.

3. The “PLEASE WAIT” message appears while the monitor is preparing for the input unit removal. When preparation is complete, the “Remove the input unit.” message appears.



4. Remove the input unit from the monitor.


Enabling the Input Unit

When the Input Unit is Disabled

When the transport function is enabled and prepared for removing the input unit on the monitor or when you remove the input unit without performing the removal procedure, the input unit is disabled and the “CONNECT INPUT UNIT” message appears.

When the input unit is disabled, the measurement values and waveforms are not displayed on the home screen and the data cannot be saved in the monitor. Authenticating the patient and changing the patient information are also not available.

The drug calculation results, interbed data and review data before disabling the input unit are displayed.



Enabling the Input Unit

To enable the input unit, insert the input unit into the monitor and authenticate the patient on the SELECT PATIENT DATA window. Refer to the “Patient Authentication” earlier in this section.

Section 2 Preparation

Preparation Flowchart	2.2
Installation Conditions	2.3
Inserting and Removing the Battery Pack	2.5
Battery Handling and Operation	2.5
Safety Information	2.5
Battery Pack Handling Procedures	2.6
When Not Using the Monitor or Battery Pack	2.6
Inserting and Removing the Battery Packs	2.6
Inserting the Battery Pack	2.7
Removing the Battery Pack	2.8
Inserting and Removing the Input Unit	2.9
Inserting the Input Unit	2.9
Removing the Input Unit	2.9
When the Transport Function is Enabled	2.10
Preparing the Optional Recorder	2.11
Installing the Recorder Module	2.11
Loading Recording Paper	2.11
Preparing the Remote Control	2.13
Installing the Batteries	2.13
Setting the Remote Control Channel	2.14
Attaching the Remote Control Channel Label to the Bedside Monitor	2.14
Assigning Functions to the Customized Keys	2.14
Power	2.15
Connecting the Power Cord and Grounding the Monitor	2.15
Connecting the Power Cord	2.15
Grounding the Monitor	2.16
Turning the Power On	2.16
Check Before Turning On the Power	2.16
Turning the Power On	2.17
AUTO ADMIT Setting	2.18
Check After Turning On the Power and During Monitoring	2.18
Power and Battery Status Indications	2.19
When the "BATTERY WEAK" Message Appears	2.20
Charging the Battery Pack	2.20
Monitor Status on Power Interruption	2.21
Turning the Power Off	2.22
Check After/Before Turning the Power Off	2.22

Preparation Flowchart

You may not need to do all these.

1. Install the monitor. Refer to Administrator's Guide.
2. Prepare battery pack, remote control and recorder. Refer to Section 2 in this manual.
3. Check or change any initial settings on the SYSTEM CONFIGURATION screen. Changing these settings during monitoring interrupts monitoring. Refer to Administrator's Guide, Section 2.
4. Check or change any initial settings on the SYSTEM SETUP window. These settings are the password protected settings which only an administrator can change. Refer to Administrator's Guide, Section 3.
5. Check or change the necessary settings before monitoring in Section 3 in this manual.
 - Date and time
 - Sound volume
 - Screen brightness
 - Waveform display settings
6. Enter the information of the new patient. Refer to "Entering Patient Information" in Section 3 in this manual.
7. Check or change all alarm items for the patient. Refer to Section 5 in this manual. When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the alarm settings return to the default settings 30 minutes after the monitor is turned off. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.
8. Check or change settings for the review windows, such as trendgraphs, tables and arrhythmia recall files. Refer to Section 6 in this manual.
9. Check or change recording settings. Refer to Section 10 in this manual.
10. Prepare the equipment (electrodes, transducers, probes, etc.) for monitoring individual parameters and check or change the settings for each parameter. Refer to User's Guide, Part II.

Installation Conditions

Put the monitor on a stable and flat stand, on an optional KC-600P cart or KG-951P wall mount kit in a suitable location where the screen is easy to see and does not reflect light. Follow the cautions below.

The monitor must be installed by qualified personnel. Details are in Administrator's Guide.

WARNING

Never use the monitor in the presence of any flammable anesthetic gas or high concentration oxygen atmosphere. Failure to follow this warning may cause explosion or fire.

WARNING

Connect only the specified instrument to the monitor and follow the specified procedure. Failure to follow this warning may result in electrical shock or injury to the patient and operator, and cause fire or instrument malfunction.

CAUTION

Avoid collision when moving the monitor on a cart. Strong impact may damage the monitor.

CAUTION

Avoid a location where the monitor is sprinkled with liquids. Avoid direct sprinkling, spray or moist air from a nebulizer or a humidifier.

CAUTION

The display screen is made of glass. Strong impact may damage it.

CAUTION

Avoid locations where the monitor may receive strong electromagnetic interference such as radio or TV stations, cellular phones or mobile two-way radios.

CAUTION

If fluids are accidentally spilled on the monitor, take the monitor out of service and check for damage.

CAUTION

Avoid exposing the monitor to direct sunlight.

CAUTION

Do not use the monitor in an ambulance. The monitor may not function properly in a moving vehicle.

CAUTION

Do not place blankets or cloth over the monitor. It may affect monitoring.

CAUTION

Do not place the monitor in a dusty area.

CAUTION

Do not place the monitor in an MRI examination room. The monitor may not function properly, or noise from the monitor may interfere with the MRI.


2. PREPARATION

CAUTION

Connect the power cord to an AC outlet which can supply enough AC current to the monitor. The monitor cannot function properly with low current.

CAUTION

Make sure that there is more than 5 cm of space between the monitor and the wall for adequate ventilation. When the monitor is surrounded, make sure that there is about 10 cm of space above the monitor for ventilation so that the operating temperature does not exceed 40°C (104°F).



CAUTION

Do not use an electrical blanket. It may affect monitoring.

CAUTION

When there is any problem on the monitor, turn off the power immediately and disconnect the power cord from the AC outlet. Take the monitor out of service and check for damage.

CAUTION

Avoid placing the monitor near a heater or humidifier.

Inserting and Removing the Battery Pack

Battery Handling and Operation

Safety Information

WARNING

- Never short-circuit the + and – terminals on the battery pack. It may cause overheating and fire.
- Keep the battery pack away from fire. It may explode.
- Do not damage, disassemble, drop or give impact to the battery pack.
- Never use the battery pack on unspecified instruments.
- Never charge the battery pack on unspecified instruments.
- Never install the battery pack with the wrong polarity.
- Keep the battery pack away from patients.

WARNING

If the battery pack is damaged and the substance inside the battery contacts the eyes or skin, wash immediately and thoroughly with water and see a physician. Never rub your eyes, because you may lose your eyesight.

WARNING

- Do not immerse the battery pack in water. The battery pack may heat up and rust and the substance inside the battery pack may leak.
- Do not leave the battery pack unused for more than about two years. The battery pack may leak.

CAUTION

Do not expose the battery pack to direct sunlight or leave in a high temperature place. The lifetime of the battery pack may be shortened, the performance of the battery pack may be degraded and the battery may leak.

CAUTION

Do not use a battery pack with a damaged cover. The operator may receive electrical shock.

CAUTION

Do not leave the battery pack near the patient or in reach of children.

CAUTION

Do not subject the battery pack to a strong mechanical shock.

CAUTION

Do not tilt the monitor when removing the battery pack from the monitor. If the lock release lever is lifted while the monitor is tilted, the battery pack falls out of the monitor and may injure the patient or operator.

CAUTION

Use the battery pack between 10°C (50°F) and 40°C (104°F). Temperatures out of this range affect the working of the battery.

CAUTION

Do not use a battery pack which is past the expiration date written on the label.

CAUTION

Before disposing of the battery pack, check with your local solid waste officials for details in your area for recycling options or proper disposal. The battery pack is recyclable. At the end of its useful life, under various state and local laws, it may be illegal to dispose of this battery pack into the municipal waste stream.

NOTE

Be careful when handling the fully charged battery pack. The battery pack heats up to about 60°C (140°F).

Battery Pack Handling Procedures

- Always place a battery pack in the monitor. This charges it so that you will always have a fully charged battery pack ready.
- Fully recharge the battery pack before using it for the first time or after storing it for over a month. When the battery is not used, it self-discharges.
- Replace the battery pack with a new one every year. This is because the battery is a chemical product which gradually deteriorates whether or not it is used.
- Store the battery packs under the following conditions.

Temperature: -20 to +60°C (-4 to +140°F) (within 30 days)

-20 to +45°C (-4 to +113°F) (within 90 days)

-20 to +35°C (-4 to +95°F) (more than 90 days)


Humidity: 20 to 85% RH (noncondensing)

When Not Using the Monitor or Battery Pack

- When the monitor is not used for a long time, remove the battery pack. When a charged or discharged battery pack is left inside the monitor with the power cord unplugged, the battery self-discharges and deteriorates.
- When a battery pack is not used, fully charge it before storage. When a battery pack is not used for over one month, fully charge it once every six months.

Inserting and Removing the Battery Packs

This monitor can hold two battery packs. Insert the battery pack to the battery slot 1 or/and battery slot 2.




NOTE


- Only use the SB-671P battery pack.
- The procedure for inserting and removing the battery packs is the same for BSM-6301 and BSM-6501/BSM-6701 bedside monitors even though the battery slot position and battery cover shape are different.

Inserting the Battery Pack


1. Remove the battery cover by pressing the tab on the battery cover and slide the cover off.



2. Insert the battery pack in the battery slot with the label (black) facing up.



3. Attach the battery cover.




2. PREPARATION


Removing the Battery Pack

CAUTION


Do not tilt the monitor when removing the battery pack from the monitor. If the lock release lever is lifted while the monitor is tilted, the battery pack falls out of the monitor and may injure the patient or operator.



1. Remove the battery cover by pressing the tab on the battery cover and slide the cover off.



2. Press the battery lever and release the lock.
3. Pull out the battery pack from the battery slot.




4. Attach the battery cover.

Inserting and Removing the Input Unit


2

The input unit can be inserted or removed from the monitor. When the patient is changed or moved to a different location, insert or remove the input unit.

Inserting the Input Unit




1. Put the input unit into the rear of the monitor so that the four tabs go into the four slots.



2. Slide the input unit all the way into the monitor until it clicks into place.

Removing the Input Unit



CAUTION

When inserting or removing the input unit from the monitor, be careful not to drop it.

Slide out the input unit while pulling up the lock release lever.

When the Transport Function is Enabled

CAUTION

When removing the input unit from the monitor when the transport function is enabled, perform the removal procedure of the input unit on the REMOVE page of the TRANSPORT DATA window before removing the input unit. Otherwise, the data in the input unit may be lost.

When Connected to the Network

CAUTION

Do not remove the input unit while the data is being sent to the central monitor. The data may be lost.

CAUTION

When the patient is discharged and there is no need to send the patient data to the central monitor, discharge the patient on the central monitor before removing the input unit. When the input unit is unintentionally removed or inserted when not using transport function, data that was sent to the central monitor in the past may be lost.

NOTE

When the patient is discharged and there is no need to send the patient data to the central monitor, removing the input unit from the bedside monitor is not necessary.

Preparing the Optional Recorder

2

Installing the Recorder Module

Install the optional WS-671P recorder module in the monitor by referring to the WS-671P recorder module Installation Guide.

CAUTION for Handling the Recording Paper

- Do not allow paper to contact pastes, adhesive agents, oil-based felt pen tips or diazo process (ditto/spirit) copying paper. These discolor the paper surface.
- Do not allow paper to contact any materials made of vinyl chloride, plastic eraser, adhesive tape, fluorescent felt tip pen, or cinnabar seal ink because these discolor the recorded waveforms and data.
- Do not apply strong pressure to the paper. Rubbing or scratching discolors the paper surface.
- Do not allow paper to contact saline solution. The paper discolors and if the saline solution gets on the thermal head, there will be dots missing from the recorded data.
- Avoid high humidity, high temperature, direct sunlight and direct fluorescent light when storing recording paper. Otherwise the paper may discolor. Store the recording paper in a dry, cool place.
- When using glue on the recording paper, use glue which consists of starch, polyvinyl alcohol, gum arabic, or carboxymethyl.


Loading Recording Paper

CAUTION for Loading the Recording Paper

- Correctly load the recording paper as specified. Otherwise, recording may not be performed properly.
- Do not touch the recording head with any hard material. When the head is tapped with hard material, the head may crack and the heater element wire may short-circuit.
- Clean the head surface with the provided head cleaner pen before loading new paper. After a period of usage, paper dust may accumulate between the paper and the head surface, and good printing cannot be obtained.


NOTE

Only use the specified recording paper, FQW50-2-100.




The out of paper lamp on the bedside monitor lights and the “INSERT REC PAPER” message appears on the screen when there is no paper.

2. PREPARATION




1. Move the recorder door release lever in the direction of the arrow (△) to release the lock.




2. Open the recorder door.

CAUTION

Do not touch the thermal head inside the recorder module. The thermal head may be damaged by static electricity or become dirty and cause printing failure.



3. Set the recording paper inside the recorder so that the detection mark (small black square on corner) of the paper is on the right side.



4. Draw out one page of paper toward you and close the recorder door.

If the out of paper lamp is still lit, the recorder door is not closed properly.

Preparing the Remote Control

The monitor has a remote control sensor for receiving signals from the remote control.

When the monitor cannot operate by remote control or the remote control distance becomes short, the battery may be deteriorated. Change the battery with new one. Use two AAA alkaline batteries and change the two batteries at the same time.

Installing the Batteries

WARNING


- Keep the batteries away from fire. They may explode.
- Keep the batteries away from patients.
- Never short-circuit the + and – terminals on the battery. It may cause overheating and fire.
- Do not damage, disassemble, drop or give impact to the battery.

WARNING


If the battery is damaged and the substance inside the battery contacts the eyes or skin, wash immediately and thoroughly with water and see a physician. Never rub your eyes, because you may lose your eyesight.

NOTE


When not using the remote control for a long time, remove the batteries from the remote control.



1. Remove the battery cover on the rear panel of the remote control as shown.



2. Insert two new AAA alkaline batteries into the remote control observing the correct + and – position.




3. Reattach the battery cover.

2. PREPARATION

NOTE

- Remove the battery from the remote controller when not using the battery.
- Check with your local solid waste officials for details in your area for recycling options or proper disposal.
- Take care not dropping or losing the remote controller.

Setting the Remote Control Channel



One remote control can operate up to nine monitors by changing channel. The remote control channel must be set to the correct monitor.


The infrared light emitted from the remote control has wide directivity and reflects the ceiling and wall and may operate the other devices.

The remote control channel must be set by the administrator. The procedure is described in the Administrator's Guide.

CAUTION

- Set the remote control channel on the monitor to prevent the remote control from operating a different monitor.
- When several monitors are installed close together, check that the remote control operates only the desired monitor. If the remote control operates a different monitor, recheck the channel setting.

Attaching the Remote Control Channel Label to the Bedside Monitor



After setting the remote control channel on the monitor, attach the remote control channel label to the display.

Assigning Functions to the Customized Keys

The window or operation can be assigned to each key on the remote control for the shortcut key operation. There are six customized keys on the remote control. The function is assigned on the SYSTEM SETUP window. Refer to Section 3 Administrator's Guide.

Power

2

The monitor can operate on either battery pack or AC power.

When the power cord is plugged into an AC outlet and the power switch on the front panel is turned on, the monitor operates on AC power.

When a SB-671P battery pack is inserted into the battery slot and the power cord is disconnected or there is a sudden power failure, the monitor automatically switches to battery power.

When the battery pack is not used and there is a sudden power failure, the stored data remains in memory for about 30 minutes after the power is shut down.

The battery pack is charged when the power cord is plugged into an AC outlet and the AC current is supplied to the monitor. The battery pack is also charged during monitoring.

When the monitor is operated on battery power, the brightness of the screen can be reduced to save battery power.

The monitor can operate for about 90 minutes (BSM-6301/BSM-6501) or 60 minutes (BSM-6701) with a new fully charged battery pack when:

- Used in normal temperature.
- Recorder is stopped.
- No alarm occurs.
- Monitoring ECG, respiration (impedance) and SpO₂.
- <POWER SAVING MODE> on the SYSTEM SETUP window is set to ON.
- <SYNC SOUND VOLUME> on the VOLUME window is set to OFF.
- NIBP measurement interval is 15 minutes.
- QI-671P and QI-672P interfaces or QI-631P and QI-632P or QI-634P interfaces are installed in the monitor.

Connecting the Power Cord and Grounding the Monitor

Connecting the Power Cord

WARNING

Connect only the specified instrument to the monitor and follow the specified procedure. Failure to follow this warning may result in electrical shock or injury to the patient and operator, and cause fire or instrument malfunction.

WARNING

When several medical instruments are used together, ground all instruments to the same one-point ground. Any potential difference between instruments may cause electrical shock to the patient and operator.

Connect the provided power cord to the AC SOURCE socket on the rear panel of the monitor and plug the cord into a 3-prong AC outlet.

2. PREPARATION

When the AC power is supplied to the monitor, the AC power lamp on the front panel lights.

NOTE

If the AC power lamp does not light, check the power cord connection.

Grounding the Monitor

WARNING

When several medical instruments are used together, ground all instruments to the same one-point ground. Any potential difference between instruments may cause electrical shock to the patient and operator.

When more than one electrical instrument is used, there may be electrical potential difference between the instruments. The potential difference between the instruments may cause current to flow to the patient connected to the instruments, resulting in electrical shock (micro shock).

Always perform equipotential grounding when required. It is often required in the operating room, ICU room, CCU room, cardiac catheterization room and X-ray room. Consult with a biomedical engineer to determine if it is required.

When equipotential grounding is required, connect the equipotential ground terminal on the instrument to the equipotential ground terminal on the wall (equipotential grounding system) with the equipotential grounding lead (potential equalization conductor).

Turning the Power On

Check Before Turning On the Power

Check the following items before turning on the power.

- Enough electrodes and electrode leads are ready.
- Cleaned and sterilized sensors and transducers are ready.
- Power cord is connected properly.
- Equipotential grounding lead is connected properly when equipotential grounding is required.
- All cables are connected properly.
- Enough recording paper in the recorder (when using an optional recorder).
- Fully charged battery pack is installed in the monitor in case of a sudden power failure.
- No scratches, damage or dirt on the monitor.
- No damage to the keys and panels.
- No damage to the power cord.
- No damage to the electrode leads, transducers, probes and cables.
- The monitor is not in a wet place.


Turning the Power On

CAUTION


When the monitor is turned on, check that a single beep sounds and the red, yellow, cyan and green alarm indicator lamps blink once. This shows that the alarm is functioning properly.

NOTE

- It takes a few minutes for the LCD screen to reach full brightness.
- The shadow of the previous screen may remain for a few minutes after changing screens.
- There may be some dots on the LCD screen which are always on or always off, but it does not affect monitoring. This is normal for all LCD screens.
- Even though the position of symbol marks for the lamps are different on BSM-6301 and BSM-6501/BSM-6701 bedside monitors, the function and the position of lamps are the same.



Press the [Power] switch on the front panel to turn the power on. The power can also be turned on by pressing the [POWER] button on the remote control. The power lamp and the AC power lamp light and self check starts. When the check is complete, the home screen appears.



If the power lamp does not light, check the power cord connection.

When the monitor power is turned on, alarms are suspended while the monitor is waiting for the electrodes and probe to be attached to the patient. The monitoring starts when the connection cord is connected to the socket on the monitor and the electrodes or probe are attached to the patient. The alarm activates when one of the following occurs:

- ECG, SpO₂ or IBP* is monitored or NIBP** is measured and a value is displayed. (when AUTO is selected for <ALARM ACTIVATION DELAY> on the ALARM window of the SYSTEM SETUP window)
 - * When SYS > DIA, the difference between these two values is 3 mmHg and this status continues for more than 3 seconds.
 - ** When SYS, DIA or MAP value is measured.
- ECG, SpO₂ or IBP is continuously monitored for the selected time (when 1, 2 or 3 min is selected for <ALARM ACTIVATION DELAY>)
- NIBP is measured (when 1, 2 or 3 min is selected for <ALARM ACTIVATION DELAY>)
- Heart rate becomes 0.


2. PREPARATION

If the monitor power is turned off and on again within 60 seconds, the monitoring continues.


AUTO ADMIT Setting

When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON and the monitor power is turned on more than 30 minutes after turning the power off, the stored data in the monitor is deleted. When the monitor is turned on in less than 30 minutes after turning power off, the stored data is not deleted and monitoring continues.

When <AUTO ADMIT> is set to OFF, the message appears asking whether monitoring a new patient or not. The factory default setting is ON.



When AUTO ADMIT is set to ON



When AUTO ADMIT is set to OFF

For setting <AUTO ADMIT>, refer to Administrator's Guide, Section 2.

Check After Turning On the Power and During Monitoring

To start monitoring safely and properly, check the following items after turning on the power. If any problem is detected, take the proper countermeasure according to the troubleshooting and maintenance sections.


- There is no fire, smoke or smell.
- The monitor is not too hot.
- The power lamp and other lamps light.
- Alarm indicators (red, yellow, cyan and green lamps) blink once and a beep sounds.
- The start up screen appears and the home screen appears.
- No error message is displayed on the screen.
- The time on the screen is correct.
- The monitor does not affect surrounding equipment.
- The data and waveforms are displayed properly.
- Keys and switches operate properly.
- The touch keys function properly and the key clicking sound is generated.
- Alarm functions properly.
- Alarm sound can be heard.
- Alarm sound volume setting is appropriate.
- There is no trouble in recording (when using an optional recorder).
- Sound can be heard from the monitor.

NOTE

After turning the monitor on and when admitting a patient on the monitor, make sure that the time displayed at the upper right of the screen is correct. When the date or time is changed during monitoring, the date and time of all stored data is also changed and may not match the date and time on the printout.

When the monitor is connected to a network


The time on this monitor is automatically adjusted to match the time of the network as long as the monitor is connected to the network. The date and time on all monitors in the network are set to the same setting.

Power and Battery Status Indications

Power and battery status are indicated by four lamps on the bedside monitor. A discharged battery pack is also indicated by battery marks, screen message and alarm.


NOTE

- When charging the battery pack with the monitor power turned off, check that the power lamp and battery charging lamp light. If the lamps do not light even when the power cord is connected and the battery pack is inserted, turn the power on, check that the battery charging lamp is blinking or lit, then turn the power off.
- Even though the position of symbol marks for the lamps are different on BSM-6301 and BSM-6501/BSM-6701 bedside monitors, the function and the position of lamps are the same.




- Operating on AC power and battery pack is fully charged or there is no battery
- Power lamp: Lit
- AC power lamp: Lit
- Battery lamp 1: Lit or off
- Battery lamp 2: Lit or off


2. PREPARATION




- Operating on AC power and battery pack is being charged
Power lamp: Lit
AC power lamp: Lit
Battery lamp 1: Slow blinking (once every 2 seconds) or off
Battery lamp 2: Slow blinking (once every 2 seconds) or off




- Operating on AC power when battery pack is damaged
Power lamp: Lit
AC power lamp: Lit
Battery lamp 1: Rapid blinking (4 times per second) or off
Battery lamp 2: Rapid blinking (4 times per second) or off



- Operating on battery power
Power lamp: Lit
AC power lamp: Off
Battery lamp 1: Lit* or off
Battery lamp 2: Lit* or off
* When two battery packs are used and when the battery pack which is not used is fully charged



- Operating on battery power and battery pack is damaged
Power lamp: Lit
AC power lamp: Off
Battery lamp 1: Rapid blinking (4 times per second) or off
Battery lamp 2: Rapid blinking (4 times per second) or off
Screen indication: “BATTERY WEAK” message
Alarm indication: Continuous “bing bong” sound and blinking yellow alarm



- No monitoring and charging battery pack
Power lamp: Off
AC power lamp: Lit
Battery lamp 1: Slow blinking (once every 2 seconds) or off
Battery lamp 2: Slow blinking (once every 2 seconds) or off

When the “BATTERY WEAK” Message Appears

Operate the monitor on AC power and/or replace the battery pack when the “BATTERY WEAK” message appears.

When the “BATTERY WEAK” message appears, the remaining battery power is less than 25%. The yellow alarm lamp lights with a continuous “bing bong” sound.

If no AC or battery power is supplied to the monitor, there is no measurement and patient data such as trend data may be lost.

Charging the Battery Pack

The battery pack can be charged by the monitor. It takes about 10 hours to charge one battery pack during monitoring and 6 hours to charge two battery packs when not monitoring.

NOTE

The new battery pack is not charged. Charge the battery pack before use.

The monitor can operate for about 90 minutes (BSM-6301/BSM-6501) or 60 minutes (BSM-6701) with a new fully charged battery pack when:

- Used in normal temperature.
- Recorder is stopped.
- No alarm occurs.
- Monitoring ECG, respiration (impedance) and SpO₂.
- <POWER SAVING MODE> on the SYSTEM SETUP window is set to ON.
- <SYNC SOUND VOLUME> on the VOLUME window is set to OFF.
- NIBP measurement interval is 15 minutes.
- QI-671P and QI-672P interfaces or QI-631P and QI-632P or QI-634P interfaces are installed in the monitor.

CAUTION

When charging the battery pack, keep the ambient temperature at approximately 20°C to maintain the optimal battery operation time. If the battery pack is charged at less than 10°C (50°F) or more than 30°C (86°F), the maximum battery operation time will be 20% to 30% less than the optimal operation time.

Charging in the Monitor**Normal charging**

During AC operation, the battery pack is automatically charged without interrupting monitoring. It takes approximately 10 hours of continuous charging to fully charge a battery pack.

Fast charging

It takes 6 hours of continuous charging to fully charge two battery packs when not monitoring. When installing two battery packs, the monitor can charge the two battery packs at the same time.

After continuous charging, the monitor automatically switches to trickle charging mode to keep the battery pack fully charged. Trickle charging is necessary because the battery pack can self-discharge even when it is not in use.

NOTE

Do not disconnect the power cord from the monitor during battery charging.

Monitor Status on Power Interruption

When there is a power failure or sudden power interruption, the monitor status is as follows.

- When a battery pack is installed in the monitor, the BSM-6301 and BSM-6501 bedside monitors operate for about 90 minutes and the BSM-6701 bedside monitor operates for about 60 minutes on battery power.

2. PREPARATION


- When the monitor has no battery pack installed or the battery pack is discharged, the monitor turns off. When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the settings return to the default settings 30 minutes after the monitor is turned off. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.

When there is a power failure or sudden power interruption, immediately connect the monitor to the emergency power source. It is recommended to always keep the battery pack in the monitor.

Turning the Power Off

NOTE

- Even though the position of symbol marks for the lamps are different on BSM-6301 and BSM-6501/BSM-6701 bedside monitors, the function and the position of lamps are the same.
- Do not disconnect the power cord while the monitor power is on. Data may be lost.



Press the [Power] switch on the front panel for more than three seconds to turn the power off. The screen becomes dark and the power lamp on the front panel turns off. The power can also be turned off by pressing the [POWER] button on the remote control.

Check After/Before Turning the Power Off

Check the following items for the next use.

- Previous patient data is deleted.
- Temporarily changed settings are changed back to the previous settings.
- There is no dirt, damage or scratches on the monitor.
- The sensors, probes, transducers, and cables are cleaned and sterilized.
- Accessories are cleaned and stored properly.
- There are enough consumables, such as recording paper, and disposable electrodes for the next use.
- Battery pack is fully charged.
- The power switch on the monitor is turned off and the power cord is disconnected from the monitor.
- The monitor is not in a wet place.
- Dead batteries are disposed of properly.
- The medical waste is disposed of properly.
- The monitor is stored properly.

Section 3 Necessary Settings Before Monitoring

Changing Date and Time	3.2
Changing Sound Volume Settings	3.3
Changing the Screen Brightness.....	3.4
Changing Waveform Display Settings.....	3.5
Entering Patient Information	3.7
Displaying the PATIENT INFO Page.....	3.8
Closing the PATIENT INFO Page	3.8
Entering the Patient Information	3.9
Entering the Patient ID	3.9
Entering the Patient Name	3.10
Entering the Date of Birth and Age	3.11
Entering the Height and Weight	3.13
Entering the Gender.....	3.13
Entering the Pacemaker Use	3.14
Deleting Data.....	3.16
Suspended Alarms after Deleting Data.....	3.18

Changing Date and Time


When the power is on, the current time is displayed in the upper right corner of the screen.

NOTE

- When the date or time is changed during monitoring, the date and time of all stored data is also changed and may not match the date and time on the printout.
- While the transport function is enabled and sending data to the central monitor, the date and time cannot be changed.

1. Display the DATE window.

Press the [Menu] key → DATE key.



The DATE window can also be displayed by touching the time on the upper right corner of the home screen.

2. Touch the YEAR, MONTH, DAY, HOUR or MINUTE key.
3. Touch the desired number(s) using the numeric keypad.
4. Repeat steps 2 and 3 to enter other items.
5. Touch the SET key. The SET key must be touched before changing windows. Otherwise the setting changes back to the previous setting.

When the set date is incorrect, the “OUT OF RANGE” message appears on the screen. Enter the correct date.


6. Press the [Home] key to return to the home screen.

Changing Sound Volume Settings

3

On the VOLUME window, you can select sync sound on or off and adjust the sync sound volume and alarm sound volume.

1. Display the VOLUME window.
Press the [Menu] key → VOLUME key.



2. Change any settings.
 - Select ON or OFF in <SYNC SOUND VOLUME> box to set sync sound volume on or off.
 - To change the sync sound volume, touch the ▲ or ▼ key or drag the slider to the desired level on the setting bar in <SYNC SOUND VOLUME> box. At the lowest volume setting, the sync sound is not audible. When ON is selected, there is a beeping sound.
 - To change the alarm sound volume, touch the ▲ or ▼ key to adjust the setting or drag the slider to the desired level on the setting bar in <ALARM VOLUME> box. At the lowest volume setting, the alarm is still audible.

NOTE

Set the alarm volume depending on the monitoring environment. When you drag the slider or touch the key to the lowest level, the alarm sound goes to the minimum volume.


3. After changing settings, press the [Home] key to return to the home screen.

Changing the Screen Brightness

When operating on battery power, the brightness is automatically set to minimum.

1. Display the BRIGHT page.

Press the [Menu] key → DISPLAY key → BRIGHT tab.



2. Touch the desired place on the setting bar in <BRIGHTNESS> box. Use the ▲ or ▼ key or drag the slider to the desired level on the setting bar to adjust the setting.
3. Press the [Home] key to return to the home screen.

Changing Waveform Display Settings


3

The following items can be set for the home screen configuration.

- Blood pressure waveform display mode
- Number of ECG waveforms
- Respiration/CO₂ waveform sweep speed
- Waveform sweep speed (except for respiration, CO₂ and EEG waveform)
- Waveform display on the home screen

1. Display the WAVES page.

Press the [Menu] key → DISPLAY key → WAVES tab.



2. Change settings.

To change the number of ECG waveforms, select 1, 2 or 3 in the <NO. ECG WAVES> box.

To change the blood pressure waveform display mode, select one of the following in <PRESS SCALE> box.

SEPARATE: Blood pressure waveforms are displayed separately on different scales.

COMMON: Blood pressure waveforms are displayed on the same scale.

DUAL: Blood pressure waveforms are separated into arterial blood pressures and other type of blood pressures. The arterial blood pressures are labeled ART, ART-2, RAD, DORS, AO, FEM, UA, LVP and P1 to P7.

To change the sweep speed of waveforms other than respiration, CO₂ and EEG waveforms, select a speed in the <SWEEP SPEED> box.

To change the respiration/CO₂ waveform sweep speed, select from one of four speeds in the <RESP/CO₂ SWEEP SPEED> box.

3. NECESSARY SETTINGS BEFORE MONITORING

To change the waveform display of the following parameters on the home screen, select a parameter in the <WAVE DISPLAY> box. Available parameters are SpO₂, SpO₂-2, FLOW, Paw, VOL, EEG, EEG2 and IBP.

NOTE

- The SpO₂-2 key is available only when an AY-661P, AY-663P, AY-671P or AY-673P input unit is used.
- When both BIS and EEG are monitored, both EEG waveforms are displayed.
- FLOW, Paw and VOL keys are not available for BSM-6000A series.

3. Press the [Home] key to return to the home screen.

Entering Patient Information

3

Before entering data for a new patient, you must first delete all data of a previous patient. Refer to “Deleting Data” section.

When the transport function is enabled, you can start or resume monitoring using patient information and data in the input unit. When using the input unit, check the patient information and data range on the SELECT PATIENT DATA window and select whether to continue with the existing monitored data or delete the existing data and enter new patient information.

Screen examples in this section are for BSM-6000K series when <DATA TRANSPORT USING INPUT UNIT> setting on the TRANSPORT window of the SYSTEM CONFIGURATION screen is set to ENABLE.

WARNING

Check the alarm settings when admitting a new patient and whenever the patient condition changes and change the alarm settings if necessary. The alarm settings return to the alarm master settings on the SYSTEM SETUP window when:

- All data is deleted on the DELETE page on the ADMIT window.
- <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON and 30 minutes elapse after monitor power off.

CAUTION

When admitting a new patient, first delete all data of the previous patient. Otherwise, the data of the previous patient and new patient will be mixed together.

CAUTION

When installing the monitor, change the time zone setting to the same setting as the other bedside monitors and central monitors. If the time zone setting is not the same, the data which was in the input unit before transport is deleted when using the transport function with the input unit.

NOTE

- After turning the monitor on and when admitting a patient on the monitor, make sure that the time displayed at the upper right of the screen is correct. When the date or time is changed during monitoring, the date and time of all stored data is also changed and may not match the date and time on the printout.
- After admitting a new patient or enabling the input unit when the transport function is enabled, check the alarm settings.

3. NECESSARY SETTINGS BEFORE MONITORING

The height unit (cm or inches) and weight unit (kg or pound) can be set on the SYSTEM CONFIGURATION screen. Refer to Administrator's Guide, Section 2.

Displaying the PATIENT INFO Page

Display the PATIENT INFO page.

Press the [Menu] key → ADMIT key.

When MENU is assigned to one of the function keys at the upper left of the screen, the MENU window can be displayed by touching the MENU function key.

You can display the MENU window by pressing the [MENU/HOME] key on the remote control.

The image shows two parts of the device's interface. The main part is the 'PATIENT INFO' page, which has a purple background and a white data entry area. At the top, there are tabs: 'ADMIT', 'ALARM LIMITS', 'ARRHYTHM ALARMS', 'PATIENT INFO' (selected), 'DELETE DATA', and 'TRANSPORT DATA'. The data entry area contains the following fields: 'PATIENT ID' with value '123456789', 'NAME' with value 'JOHN SMITH', 'DATE OF BIRTH' with value '1970-01-09' and a breakdown of 'AGE 39 YEAR(S) 2 MONTH(S) 10 DAY(S)', 'HEIGHT/WEIGHT' with values '170.0 [cm]', '70.0 [kg]', and 'BSA 1.81 [m²]', 'GENDER' with value 'MALE', and 'PACE MAKER' with value 'YES'. Below this is a small snippet of the home screen. It has a black background with green text and waveforms. At the top, there are tabs: 'TREND GRAPH', 'ZERO ALL', 'ALARM HISTORY', and 'PATIENT INFO' (selected). The patient name 'JOHN SMITH' is displayed. Below it, a large green number '74' is shown, with '[mV] VPC' and '[/min]' below it. To the right, there is a green waveform.

The PATIENT INFO page can also be displayed by touching the patient name area at the upper part of the home screen.

Closing the PATIENT INFO Page

Press the [Home] key.

When HOME is assigned to one of the function keys at the upper left of the screen, the home screen can be displayed by touching the HOME function key.

You can display the home screen by pressing the [MENU/HOME] key on the remote control.

You can also close the page by touching the waveform or current trendgraph display area on the home screen.


Entering the Patient Information

Entering the Patient ID

The patient ID can be entered with the screen keyboard or bar code reader or from the central monitor. Up to 16 alphanumeric characters can be entered. The patient ID can only be displayed on the PATIENT ID window. The patient ID is necessary to identify the patient on the central monitor network.

Entering the Patient ID Using the Keyboard

1. Touch the PATIENT ID key to display the PATIENT ID window.



2. Enter the patient ID by using the keyboard keys.
3. Touch the ENT key.
4. Touch the  key to close the PATIENT ID window.

Entering the Patient ID Using the Bar Code Reader

1. Touch the Patient ID key to display the PATIENT ID window.

NOTE

For BSM-6000A series, patient ID can be entered from the home screen.

2. Scan the bar code of the patient. The PATIENT ID window closes.
3. Confirm that the patient ID is displayed on the PATIENT INFO page.

3. NECESSARY SETTINGS BEFORE MONITORING

Entering the Patient Name

There are two methods to enter the patient name. You can use both methods together.


KEYBOARD: Use the keyboard keys displayed on the window. Up to 15 alphanumeric characters can be entered.

FREE: Any character or image you have drawn on the free writing area appears as the patient name.

When the monitor is connected to a monitor network, the FREE window is not available. When the patient name is entered from the FREE window and the monitor is then connected to a network, the patient name on the bedside monitor is deleted and the patient name entered on the central monitor appears on the bedside monitor.

Entering the Patient Name Using the Keyboard

1. Touch the NAME tab. The NAME window appears.



2. Enter the patient name by using the keyboard keys.


3. Touch the ENT key. The patient name appears in the patient name area on the home screen.

4. Touch the  key to close the NAME window.

Entering the Patient Name Using Free Function

1. Touch the NAME (FREE) tab. The free writing area appears.

2. Write the patient name with your finger or touch pen in the free writing area.



You can enter any character by drawing it. You can also edit names which were previously entered by keyboard. For example, you can make European language characters by drawing accent marks over English characters.

3. Touch the ENT key. The patient name appears in the patient name area on the home screen.

Entering the Date of Birth and Age

CAUTION

When the date of birth or age is not entered, 12 lead ECG interpretation is performed with the patient as 35 years old.

1. Touch the DATE OF BIRTH key to display the DATE OF BIRTH window.

3. NECESSARY SETTINGS BEFORE MONITORING

The screenshot shows a medical device interface with a top menu bar containing 'ADMIT', 'ALARM LIMITS', and 'ARRHYTHM ALARMS'. Below this is a sub-menu bar with 'PATIENT INFO', 'DELETE DATA', and 'TRANSPORT DATA'. The main window is titled 'DATE OF BIRTH' and features a close button (X) in the top right corner. The interface includes three input boxes for 'YEAR', 'MONTH', and 'DAY'. Below these is an 'AGE' section with three input boxes for 'YEAR(S)', 'MONTH(S)', and 'DAY(S)'. A numeric keypad is located at the bottom left, with keys for digits 0-9, a decimal point, and 'BS' (Backspace). To the right of the keypad is an 'OUT OF RANGE' indicator and an 'ENT' (Enter) key. A 'SET' button is positioned at the bottom right of the keypad area.

2. Touch YEAR, MONTH or DAY key or touch the box under the YEAR, MONTH or DAY key to enter year, month and day.
3. Enter the numbers by using the number keys.
4. Touch the ENT key. The number is entered under the YEAR, MONTH or DAY box.
5. Touch the SET key. When the year, month and day are entered, age is automatically calculated and appears at the AGE area on the DATE OF BIRTH window.
6. Touch the  key to close the DATE OF BIRTH window.

Entering the Height and Weight

The height and weight units can be changed on the SYSTEM CONFIGURATION screen. Refer to Administrator's Guide, Section 2.

1. Touch the HEIGHT/WEIGHT key to display the HEIGHT AND WEIGHT window.

2. Touch the HEIGHT or WEIGHT key or the box beside the HEIGHT or WEIGHT key to enter height and weight.
3. Enter the numbers by using the number keys.
4. Touch the ENT key. When the height and weight are entered, BSA is automatically calculated and appears at the BSA area on the DATE OF BIRTH window.
5. Touch the  key to close the HEIGHT AND WEIGHT window.

Entering the Gender

CAUTION

When the gender is not specified, 12 lead ECG interpretation is performed with the patient as male.

1. Touch the GENDER key to display the GENDER window.

3. NECESSARY SETTINGS BEFORE MONITORING

The screenshot shows the 'PATIENT INFO' window with the following fields: PATIENT ID (123456789), NAME (JOHN SMITH), DATE OF BIRTH (1970-01-09), GENDER (dialog box open), HEIGHT (1.81 m), and WEIGHT (10 DAY(S)). The GENDER dialog box has three buttons: MALE, FEMALE, and -. The window has tabs for ADMIT, ALARM LIMITS, and ARRHYTHM ALARMS, and buttons for PATIENT INFO, DELETE DATA, and TRANSPORT DATA.

2. Touch the MALE or FEMALE key. Touch - key when the patient sex is unknown.
3. Touch the  key to close the GENDER window.

Entering the Pacemaker Use

1. Touch the PACE MAKER key to display the PACE MAKER window.

The screenshot shows the 'PATIENT INFO' window with the following fields: PATIENT ID (123456789), NAME (JOHN SMITH), DATE OF BIRTH (1970-01-09), GENDER (dialog box open), HEIGHT (1.81 m), and WEIGHT (10 DAY(S)). The PACE MAKER dialog box has two buttons: YES and NO. The window has tabs for ADMIT, ALARM LIMITS, and ARRHYTHM ALARMS, and buttons for PATIENT INFO, DELETE DATA, and TRANSPORT DATA.

2. Touch the YES or NO key.
3. Touch the  key to close the PACE MAKER window.

The pacing spike detection can be turned on/off on the OTHER page of the ECG window. The setting linked between the ADMIT window and the OTHER page of the ECG window.



When the pacing spike detection set to off, the non-paced mark (✖) is displayed on the upper part of the screen.

3

WARNING

Turn the pacing pulse detection* to ON when monitoring a pacemaker patient. Otherwise the pacemaker pulse is not rejected. However, even when the pacing pulse detection is set to ON, the pacemaker pulse might not be rejected. When the pacemaker pulse is not rejected, the pacemaker pulse is detected as QRS and false heart rate may be indicated or critical arrhythmia such as asystole may be overlooked. Keep pacemaker patients under close observation.

WARNING

Even when the pacing pulse detection is set to ON, the pacemaker pulse can be overlooked or detected as QRS. You cannot confirm the pacemaker operation only from the detected pacemaker pulse.

* For the pacemaker pulse rejection capability of BSM-6000 series bedside monitor, refer to the “Specifications - ECG” in operator’s manual.

NOTE

When you monitor a premature baby or infant and the monitor miscounts the narrow width QRS, set this to NO.

Deleting Data

When monitoring the patient is no longer required, delete the data on the DELETE DATA page. The following data are deleted, and the alarm settings, arrhythmia analysis on or off and QRS detection type return to the alarm master settings, and the NIBP measurement mode returns to the INTERVAL MASTER setting on the SYSTEM SETUP window.

- Patient information
- Data on the review windows
- Data on the 12 LEAD ANALYSIS window
- Data on the DRUG window
- Data on the LUNG FUNCTION window
- PCWP value on the CO window
- Thermodilution curve on the CO window
- CO table on the MEASURE page of the CO window
- Current trendgraph on the home screen

Screen examples in this section are for BSM-6000K series when <DATA TRANSPORT USING INPUT UNIT> setting on the TRANSPORT window of the SYSTEM CONFIGURATION screen is set to ENABLE.

For BSM-6000A series, the DELETE DATA tab is the NEXT CASE tab when the site mode is OR.


CAUTION

When admitting a new patient, first delete all data of the previous patient. Otherwise, the data of the previous patient and new patient will be mixed together.

When DELETE DATA is assigned to one of the function keys at the upper left of the screen, the DELETE DATA page of the ADMIT window can be displayed by touching the DELETE DATA function key.


1. Display the DELETE DATA page.
Press the [Menu] key → ADMIT key → DELETE DATA tab.

The message confirming the data deletion appears.



2. Touch the YES key to delete data. Touch the NO key to not delete data.
3. Check the following items to confirm that all data are deleted.
 - Patient name on the home screen is deleted.
 - The message on the DELETE DATA page is dimmed.
 - ALARMS SUSPENDED message appears and alarms are suspended on the monitor.


Patient name is deleted. ALARMS SUSPENDED message appears.



The message is dimmed.

4. Press the [Home] key to return to the home screen.

3. NECESSARY SETTINGS BEFORE MONITORING



Suspended Alarms after Deleting Data

All alarms are suspended while deleting data, entering patient information or when preparing for monitoring. Alarms function resumes when the SUSPEND ALARMS key is touched or the following monitoring conditions are continuously met.

Setting of <ALARM ACTIVATION DELAY> on the SYSTEM SETUP window	Condition	
AUTO	Alarm function activates when ECG, SpO ₂ or IBP* is monitored or NIBP** is measured and a value is displayed. * When SYS > DIA, the difference between these two values is 3 mmHg and this status continues for more than 3 seconds. ** When SYS, DIA or MAP value is measured. The alarm function is also recovered when the heart rate is 0.	
	When one of the following requirements is met.	
1 min 2 min 3 min	1	ECG, SpO ₂ or IBP is continuously monitored for the selected time.
	2	NIBP is measured (SYS, DIA or MAP value is measured)
	3	Heart rate becomes 0.

Section 4 Home Screen

Safety Precautions for Monitoring.....	4.3
Using an Electrosurgical Unit.....	4.3
Using a Defibrillator.....	4.3
Overview.....	4.4
Home Screen	4.4
Review Windows	4.4
Sync Sound.....	4.4
Adjusting the Sync and Alarm Sound Volume.....	4.4
Changing Settings and Performing Other Tasks During Monitoring	4.4
Site Mode	4.5
Recording/Printing on the Home Screen.....	4.5
Interbed Monitoring	4.5
Home Screen.....	4.6
Settings for the Home Screen	4.7
Waveform Sweep Mode and Speed.....	4.7
Waveform Display on the Home Screen	4.7
Pacing Mark Position on the ECG Waveform.....	4.7
ST Waveform and Reference ST Recall Waveform Display on the Home Screen On or Off.....	4.7
Blood Pressure Waveform Display Mode	4.7
PPV or SPV Display on the Home Screen.....	4.8
Pulse Rate Display on the Home Screen.....	4.8
Current Average CO and PCWP Values Display on the Home Screen.....	4.8
Trendgraph/PWTT Trendgraph/OCRG Display on the Home Screen On or Off.....	4.8
Scale Setting for the Trendgraph on the Home Screen.....	4.9
Parameter Colors	4.9
Waveform Sensitivity.....	4.9
Displaying Other Windows from the Home Screen	4.10
Displaying PWTT Trendgraph.....	4.11
Displaying OCRG	4.13
Freezing Waveforms.....	4.14
Using Sleep Mode	4.15
Turning Sleep Mode On	4.15
Turning Sleep Mode Off	4.16
Displaying the LARGE NUMERICS Screen	4.17

4. HOME SCREEN

This section explains how to monitor the patient's waveforms and data.

Before monitoring the patient:

- Prepare the patient and equipment according to Sections 2 to 3, 5 to 9, Administrator's Guide, Sections 1 to 3 and User's Guide Part II. When using an optional recorder, also see Section 10.
- Before monitoring a new patient, follow the flowchart in Section 2.
- Read the safety precautions in the "Safety Precautions for Monitoring" section.

In this section:

- "Overview" gives general information for all monitoring.
- "Displaying PWTT Trendgraph" explains about displaying PWTT trendgraph.
- "Displaying OCRG" explains about displaying OCRG.
- "Freezing Waveforms" explains how to freeze waveforms.
- "Using Sleep Mode" explains how to use sleep mode.
- "Displaying LARGE NUMERICS screen" explains about displaying large numeric data.

Safety Precautions for Monitoring

Before beginning monitoring, observe the following safety precautions and the safety precautions in User's Guide Part II for ECG and other parameters.

4

Using an Electrosurgical Unit

WARNING

Electrosurgical units (ESU) emit a lot of RF interference. If the monitor is used with an ESU, RF interference may affect the monitor operation.

WARNING

Locate the monitor as far as possible from the ESU. Locate them on opposite sides of the operating table, if possible.

WARNING

Connect the monitor and ESU to different AC outlets located as far as possible from each other.

WARNING

When the monitor is used with an electrosurgical unit (ESU), firmly attach the entire area of the ESU return plate. Otherwise, the current from the ESU flows into the electrodes of the monitor, causing electrical burn where the electrodes are attached. For details, refer to the ESU manual.

Using a Defibrillator

WARNING

Before defibrillation, all persons must keep clear of the bed and must not touch the patient or any equipment connected to the patient. Failure to follow this warning may cause electrical shock or injury.

If the ECG waveform on the screen is too unstable to synchronize with the patient's heart beat because of the following reason(s), remove the cause(s) of an alarm, message, or unstable ECG, and then use a stable ECG lead for synchronization.

- ECG electrode is detached or broken. Lead wire is detached or broken.
- Lead wire moves. AC interference, EMG noise or noise from ESU is superimposed.
- Connection cable is broken or has a short circuit. Connector has poor contact.

Overview

Home Screen

When you first begin monitoring, a home screen appears. The home screen displays waveforms and numeric data for ECG and other parameters. Any time you press the [Home] key, the home screen appears.

The parameters on the home screen depend on the measured parameters.

When the monitor power is turned on, alarms are suspended while the monitor is waiting for the electrodes and probe to be attached to the patient. Monitoring starts when the connection cord is connected to the socket on the monitor and the electrodes or probe is attached to the patient.

NOTE

When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.

Review Windows

The trend, arrhythmia recall, alarm history, full disclosure, ST level recall and 12 lead windows display the stored data. For details about the review windows, refer to Section 6.

Sync Sound

During monitoring, a continuous “pip” sounds in synchronization with either the QRS or pulse waveform. QRS is the default setting. Refer to “Changing the Sync Sound Source” in User’s Guide Part II, Section 1, 4 or 6 to change the source of the sync sound.

Adjusting the Sync and Alarm Sound Volume

The sync sound volume and alarm sound volume can be adjusted on the VOLUME window. At the lowest setting, the alarm sound is audible but the sync sound is not audible. Refer to “Changing Sound Volume Settings” in Section 3.

Changing Settings and Performing Other Tasks During Monitoring

Every screen except the SYSTEM CONFIGURATION screen always displays at least one real-time ECG waveform and the numeric data of monitoring parameters. This lets you monitor the patient continuously without interruption while you do other tasks, such as changing settings, printing reports, or viewing trendgraphs.

The screen returns to the home screen when there is no key operation for about 3 minutes.

Site Mode

The site mode can be selected from OR, ICU and NICU according to the environment. The default settings, including alarm upper and lower limit settings, differ according to site. Refer to Administrator's Guide, Section 2.

- OR: The "BYPASS" key is displayed on the MENU window.
The "OCRG" key is not displayed on the MENU window.
- ICU: The "BYPASS" and "OCRG" keys are not displayed on the MENU window.
- NICU: The "BYPASS", "ST", "12 LEAD" and "12 LEAD ANALYSIS" keys are not displayed on the MENU window.

When "ALL ALARMS OFF" is selected for ALARMS OFF TYPE on the ALARM window of the SYSTEM SETUP window, the "ALL ALARMS OFF" key is displayed instead of the "BYPASS" or "SUSPEND MONITORING" key on the MENU window. Refer to "Alarm Windows" in Administrator's Guide, Section 3.

For details on the functions of the "BYPASS", "SUSPEND MONITORING" and "ALL ALARMS OFF" keys, refer to "Silencing and Suspending Alarms" in Section 5.

Recording/Printing on the Home Screen

When the optional WS-671P recorder module is installed in the monitor, the waveforms on the home screen can be recorded. ECG and up to two parameters selected on the RECORD window are recorded when the  [Record] key is pressed.

When "PRINT WAVE" is assigned to one of the function keys at the upper left corner of the screen, all monitoring waveforms and numeric data can be printed on the network printer when the function key is touched.

For details, refer to Section 10 "Recording".

Interbed Monitoring

When the bedside monitor is connected to a central monitor, the bedside monitor data can be sent to the central monitor. Up to 16 beds in the network can be registered as "interbed" beds and monitoring data of the selected interbed bed can be displayed on the INTERBED window. When an alarm occurs at an interbed bed, the highlighted bed name appears on the upper right corner of the home screen. The interbed alarm can also be silenced from this bedside monitor. Refer to Section 9.


Home Screen

When you first begin monitoring, a home screen appears. To return to the home screen from another window or screen, press the [Home] key.

When a window is displayed and there is no operation for about 3 minutes, the screen automatically returns to the home screen.

The home screen is automatically laid out according to the measured parameters. The layout changes when a measuring parameter changes.

The settings for monitoring parameters can be changed individually on the parameter window. For details about individual parameters, see User's Guide Part II.



The respiration rate can only be detected from one parameter. When CO₂, respiration and anesthetic gas are monitored at the same time, the respiration rate is detected in the following priority.

Gas > FLOW > CO₂ > thermistor respiration > impedance respiration

You can “freeze” (stop sweeping) the waveforms on the home screen. By freezing the waveforms, you can observe one part of a waveform in detail. The numerical data on the screen are not frozen. For details, refer to the “Freezing Waveforms” section.

The latest 30 minute parameter data can be displayed as a trendgraph on the home screen. This trendgraph can be dragged by touching the right edge of the trendgraph and moving it right or left.

A PWTT trendgraph or an OCRG can be displayed on the home screen instead of a trendgraph. Refer to “Displaying PWTT Trendgraph” and “Displaying OCRG” sections.

Settings for the Home Screen

Waveform Sweep Mode and Speed

The waveform displaying mode (fixed or moving) on the home screen can be set on the SYSTEM window of the SYSTEM SETUP window. Refer to “SYSTEM Window” in Administrator’s Guide, Section 3.

The sweep speed of waveforms other than respiration/CO₂ and EEG waveforms on the home screen can be selected from one of four speeds: 6, 12.5, 25 or 50 mm/s at <SWEEP SPEED> on the DISPLAY window.

The respiration and CO₂ waveform sweep speed on the home screen can be selected from one of four speeds: 1, 6, 12.5 or 25 mm/s at <RESP/CO₂ SWEEP SPEED> on the DISPLAY or RESP/CO₂ window.

Waveform Display on the Home Screen

Waveform display of the following parameters on the home screen can be selected in the <WAVE DISPLAY> setting on the WAVES page of the DISPLAY window. Available parameters are SpO₂, SpO₂-2, FLOW, Paw, VOL, EEG, EEG2, ART, PAP and CVP.

Pacing Mark Position on the ECG Waveform

The position of the pacing mark on the ECG waveform displays on the home screen and ECG window can be selected on the PARAMETERS window of the SYSTEM SETUP window. Refer to “PARAMETERS Window” in Administrator’s Guide, Section 3.

ST Waveform and Reference ST Recall Waveform Display on the Home Screen On or Off

The ST waveforms, reference ST recall waveforms, selected monitoring ECG leads and ST levels display on the home screen are set in the <ST WAVE ON HOME SCREEN> and <ST REF WAVE ON HOME SCREEN> settings on the ST window of the REVIEW window.

Blood Pressure Waveform Display Mode

There are three ways of displaying blood pressure waveforms. This can be

changed at <PRESS SCALE> on the DISPLAY window or PRESS window. Refer to “Changing Waveform Display Settings” in Section 3 when changing the press scale on the DISPLAY window or refer to the “Selecting the IBP Waveform Display Mode” in User’s Guide Part II, Section 6 when changing the press scale on the PRESS window.

SEPARATE: Blood pressure waveforms are displayed separately on different scales.

COMMON: Blood pressure waveforms are displayed on the same scale.

DUAL: Blood pressure waveforms are separated into arterial blood pressures and other type of blood pressures. The arterial blood pressures are labeled ART, ART2, RAD, DORS, AO, FEM, UA, LVP and P1 to P7.

PPV or SPV Display on the Home Screen

The PPV or SPV display on the home screen can be selected on the OTHER page of PRESS window. Refer to the “Displaying PPV or SPV on the Home Screen” in User’s Guide Part II.

Pulse Rate Display on the Home Screen

When using an AY-661P, AY-663P, AY-671P or AY-673P input unit, the pulse rates display in SpO₂ areas and SpO₂-2 area and the ΔSpO₂ display in SpO₂-2 area on the home screen can be set to on or off on the NUMERIC DISPLAY page of the SpO₂ window. When using an AY-660P input unit, only the pulse rate can be set to on or off. Refer to the “Displaying Pulse Rate and ΔSpO₂ on the Home Screen” in User’s Guide Part II, Section 4-1.

When using an AY-651P or AY-653P input unit, the pulse rates display in the SpO₂ areas and SpO₂-2 area and the ΔSpO₂ display in the SpO₂-2 area on the home screen can be set to on or off on the NUMERIC DISPLAY page of the SpO₂ window. Refer to the “Displaying Pulse Rate and ΔSpO₂ on the Home Screen” in User’s Guide Part II, Section 4-2.

When using an AY-631P or AY-633P input unit, the pulse rate and perfusion index (PI) display in SpO₂ area and SpO₂-2 area and the ΔSpO₂ display in SpO₂-2 area on the home screen can be set to on or off. Refer to the “Displaying Pulse Rate, ΔSpO₂ and Perfusion Index (PI) on the Home Screen” in User’s Guide Part II, Section 4-3.

Current Average CO and PCWP Values Display on the Home Screen

Current average CO and PCWP values and the measured time are displayed on the home screen. The data dims after 15 minutes and disappears from the home screen after 24 hours. When data is added to the hemodynamics trend table in the HEMO page of the TREND window, the data disappears from the home screen.

Trendgraph/PWTT Trendgraph/OCRG Display on the Home Screen On or Off

The trendgraph, PWTT trendgraph and OCRG display on the home screen is set at <CURRENT TREND> setting on the LAYOUT page of the SYSTEM

window in the SYSTEM SETUP window. Refer to “DISPLAY Window” in Administrator’s Guide, Section 3.

NORMAL:	Trendgraph display on the home screen
PWTT:	PWTT trendgraph display on the home screen
OCRG 1 cm/min:	OCRG display with the horizontal scale 1 cm/min
OCRG 3 cm/min:	OCRG display with the horizontal scale 3 cm/min
OFF:	No trendgraph/PWTT trendgraph/OCRG display on the home screen

Scale Setting for the Trendgraph on the Home Screen

The scale for the trendgraph on the home screen is the same as the setting on the TREND GRAPH window.

Parameter Colors

The parameter colors are set on the COLOR window of the SYSTEM SETUP window. Refer to “COLOR Window” in Administrator’s Guide, Section 3.

Waveform Sensitivity


Waveform sensitivity can be changed on the parameter window. Refer to User’s Guide Part II.

4. HOME SCREEN

Displaying Other Windows from the Home Screen

Touching the following items on the home screen displays the following windows.


- Numeric value: Parameter setting window
- Patient name: ADMIT window
- Time: DATE window
- Function key: Window assigned to the function key



Displaying PWTT Trendgraph

The PWTT trendgraph can be displayed on the home screen instead of a trendgraph. For details of PWTT measurement, refer to the User's Guide Part II, Section 5.

On the PWTT trendgraph, trendgraph of HR, NIBP, respiration and RR are displayed together with PWTT trendgraph.



The blue part represents PWTT threshold (PWTT trigger time set on the PWTT window).

Auto NIBP measurement triggered by a change in PWTT.

PWTT

To display PWTT trendgraph on the home screen, set <CURRENT TREND> to PWTT on the DISPLAY window of the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3.

When the optional WS-671P recorder module is installed in the monitor, PWTT trendgraph can be recorded. To record PWTT trendgraph at any time, assign "RECORD PWTT" to one of the function keys at the upper left corner of the screen. The PWTT trendgraph on the home screen is recorded when the "RECORD PWTT" function key is pressed. Refer to "KEYS Window" in Administrator's Guide, Section 3.

4. HOME SCREEN

To record PWTT trendgraph periodically, set PERIODIC REC INTERVAL (min) on the RECORDING window to 30 (PWTT). The PWTT trendgraph on the home screen is recorded at 30 minute intervals. Refer to “Setting Periodic Recording” in Section 9.

The PWTT trendgraph on the home screen can be printed on the network printer. To print PWTT trendgraph, assign “PRINT PWTT” to one of the function keys. Refer to “KEYS Window” in Administrator’s Guide, Section 3.

Displaying OCRG

The OCRG (oxygen-cardio-respirogram) can be displayed on the home screen instead of a trendgraph.

4

On the OCRG, only HR and SpO₂ trendgraphs and compressed respiration waveform are displayed. When other parameter is monitored, only the numeric data and waveform for that parameter are displayed on the home screen.


To display OCRG on the home screen, set <CURRENT TREND> to either OCRG 1 cm/min or OCRG 3 cm/min on the DISPLAY window of the SYSTEM SETUP window. Refer to “DISPLAY Window” in Administrator’s Guide, Section 3.

When the optional WS-671P recorder module is installed in the monitor, OCRG can be recorded. To record OCRG at any time, assign “RECORD OCRG” to one of the function keys at the upper left corner of the screen. The OCRG on the home screen is recorded when the “RECORD OCRG” function key is pressed. Refer to “KEYS Window” in Administrator’s Guide, Section 3.


To record OCRG periodically, set <PERIODIC REC INTERVAL (min)> on the RECORD window to 5 (OCRG) or 15 (OCRG). The OCRG is recorded at 5 or 15 minute intervals. Refer to “Setting Periodic Recording” in Section 10.

The OCRG on the home screen can be printed on the network printer. To print OCRG, assign PRINT OCRG key to one of the function keys. Refer to “KEYS Window” in Administrator’s Guide, Section 3.

OCRG 1 cm/min



OCRG 3 cm/min




Freezing Waveforms

Normally, the waveforms continuously sweep across the screen. You can also “freeze” (stop sweeping) the waveforms. By freezing the waveforms, you can observe one part of a waveform in detail. The numerical data on the screen are not frozen.

To freeze waveforms, the freeze function must be assigned to one of the function keys in the upper left corner of the screen. Refer to “KEYS Window” in Administrator’s Guide, Section 3.

When the freeze function is assigned to a function key, waveforms on the home screen can be frozen any time by touching the FREEZE key. The waveforms are frozen for 3 minutes or until they are unfrozen.

When the waveforms are frozen, the “FREEZE” message appears with the frozen time.



To unfreeze the waveforms,

- touch any key on the screen, or
- press any key on the bedside monitor.

When the waveforms are unfrozen by pressing a hard key, the function of that hard key is also performed. For example, if the  [NIBP Start/Stop] key is pressed, NIBP measurement in manual mode is performed.

Using Sleep Mode

4

In sleep mode, the screen is darkened and sync sound is turned off. The sleep mode is available only when the site mode is set to ICU or NICU and ZS-900P* transmitter is connected or the bedside monitor is connected to the central monitor network. To change the site mode, refer to “SITE Window” in Administrator’s Guide, Section 2.

* ZS-900P transmitter is not available for BSM-6000A series.

Use this mode when you want to prevent the monitor from disturbing the patient, such as during sleep.

When <EXIT SLEEP MODE ON CRISIS ALARM> on the SLEEP window of the SYSTEM SETUP window is set to:

YES: Sleep mode is turned off and the home screen appears when a CRISIS level alarm occurs.

NO: Sleep mode continues even when an alarm occurs.

When the time is set in <SLEEP MODE WILL END AT> box on the SLEEP window of the SYSTEM SETUP window, the monitor exits the sleep mode on the set clock time.

When the communication between the bedside monitor and central monitor is interrupted, the bedside monitor exits sleep mode.

Refer to Administrator’s Guide, Section 3.


WARNING

When using sleep function, monitor the patient on the central monitor or telemetry system. Otherwise, the bedside monitor alarm may be overlooked. When <EXIT SLEEP MODE ON CRISIS ALARM> check box on the ALARM page of the SYSTEM SETUP window is OFF, bedside monitor alarms and sync sound appear on the central monitor but do not appear on the bedside monitor during sleep mode.

Turning Sleep Mode On

1. Press the [Menu] key. The MENU window appears.


4. HOME SCREEN



2. Touch the SLEEP key to set the sleep mode.

When SLEEP is assigned to one of the function keys at the upper left of the screen or one of the function keys on the remote control keys, the SLEEP window can be displayed by touching the SLEEP function key. Refer to “KEYS Window” in Administrator’s Guide, Section 3 to assign a function to the function key.

During the sleep mode, the following screen is displayed.



Turning Sleep Mode Off

Touch the screen or press any hard key.

When the sleep mode is turned off by pressing a hard key, the function of that hard key is also performed. For example, if the  [NIBP Start/Stop] key is pressed, NIBP measurement in manual mode is performed.

Displaying the LARGE NUMERICS Screen


The numeric data of all monitoring parameters are enlarged on the LARGE NUMERICS screen. This window is useful for viewing at a distance.

Two types of the LARGE NUMERICS screen are provided. For the difference, refer to the next page. You can select either type on the DISPLAY window of the SYSTEM SETUP window. Refer to “DISPLAY Window” in Administrator’s Guide, Section 3.

When respiration by impedance method, respiration by thermistor method, CO₂ and anesthetic gas are monitored at the same time, the respiration rate data on the LARGE NUMERICS screen is detected in the following priority.

Gas > CO₂ > respiration by thermistor > respiration by impedance


1. Press the [Menu] key. The MENU window appears.




2. Touch the LARGE NUMERICS key. The LARGE NUMERICS screen appears.

4. HOME SCREEN

2 × 2



3 × 4



Touching the numeric value displays the parameter setting window.

On the LARGE NUMERICS screen, the trendgraph can be dragged by touching the right edge of the trendgraph and moving it right or left.

3. Press the [Home] key to return to the home screen.

Section 5 Alarm Function

Overview of Alarms	5.4
What is an Alarm	5.4
Alarm Level	5.5
Alarm Priority.....	5.5
Alarm Sound/Alarm Indicator	5.5
Alarm Messages on the Screen.....	5.5
Silencing/Suspending Alarms	5.5
Alarm Master	5.6
Automatic Recording	5.7
Alarm Setting.....	5.7
Canceling the Technical Alarm	5.8
Adjusting Alarm Sound Volume	5.8
Alarm Activation after Power On	5.8
ALARM HISTORY Window.....	5.8
Interbed Alarm.....	5.9
Alarm Types	5.10
Vital Signs Alarms	5.10
Arrhythmia Alarms.....	5.10
Technical Alarms	5.11
ECG Related Alarms.....	5.11
Respiration Related Alarms	5.11
CO ₂ Related Alarms	5.12
Microcap® Related Alarms	5.12
SpO ₂ Related Alarms	5.12
NIBP Related Alarms	5.13
IBP Related Alarms.....	5.13
Temperature Related Alarms	5.13
BIS Related Alarms.....	5.13
CO Related Alarms	5.14
Gas Related Alarms	5.14
O ₂ Related Alarms.....	5.15
VENT Related Alarms.....	5.15
TOF Related Alarms	5.15
CCO Related Alarms	5.15
PiCCO Related Alarms	5.16
FLOW/Paw Related Alarms	5.16
EEG Related Alarms.....	5.16
tcPO ₂ /tcPCO ₂ Related Alarms.....	5.17
Other Alarms	5.17
Messages	5.18
ECG Related Messages.....	5.18
Respiration Related Messages	5.18
CO ₂ Related Messages.....	5.18

SpO ₂ Related Messages	5.19
NIBP Related Messages	5.19
IBP Related Message	5.19
BIS Related Messages.....	5.20
O ₂ Related Messages	5.20
CO Related Messages.....	5.20
Gas Related Messages.....	5.21
FLOW/Paw Related Messages	5.21
EEG Related Messages.....	5.21
Microcap [®] Related Messages	5.22
Other Messages.....	5.22
Alarm Indications	5.23
Overview	5.23
Individual Alarm Indications	5.24
Vital Signs Alarms.....	5.25
Arrhythmia Alarms.....	5.29
Technical Alarms.....	5.30
Other Alarms.....	5.37
Interbed Alarms.....	5.37
Alarm Control Marks	5.37
Individual Vital Signs Alarm Off Marks	5.38
Flow of Alarm Function.....	5.39
Silencing and Suspending Alarms.....	5.40
Overview	5.40
Silencing an Alarm	5.40
Suspending Alarms.....	5.40
Silencing Alarms After Alarm Occurrence.....	5.43
Silencing an Alarm	5.43
Canceling Alarm Silence	5.44
Suspending Alarms Before Alarm Occurrence.....	5.44
Suspending Alarms.....	5.44
Suspending All Alarms Indefinitely.....	5.44
Suspending All Alarms and NIBP STAT and Auto Measurement Indefinitely.....	5.47
Turning Automatic Alarm Recording On/Off	5.49
Setting Alarms	5.50
Overview	5.50
Alarm Limits Ranges	5.50
Vital Signs Alarms.....	5.51
Arrhythmia Alarms.....	5.56
Setting Vital Signs Alarms Individually	5.57
Setting All Vital Signs Alarms to a Preset Pattern (Alarm Master)	5.58
Setting Arrhythmia Alarms Individually.....	5.59
Setting All Arrhythmia Alarms to a Preset Pattern (Alarm Master).....	5.60

This section explains:

- An overview of alarms.
- Alarm types.
- Alarm indications.
- Silencing an alarm.
- Suspending all alarms before occurrence.
- Setting individual alarms, turning automatic alarm recording on or off and all other functions for alarms.

Overview of Alarms

WARNING

A physician must be within the range where he/she can hear the alarm sound of the bedside monitor while monitoring a patient on the bedside monitor. If the physician cannot hear the alarm sound, critical changes on the patient may be overlooked.

WARNING

Do not diagnose a patient based on only the alarm information of the bedside monitor. An alarm may not be indicated due to alarm level or alarm on/off setting and critical changes on the patient may be overlooked.

WARNING

Check the alarm settings when admitting a new patient and whenever the patient condition changes and change the alarm settings if necessary. The alarm settings return to the alarm master settings on the SYSTEM SETUP window when:

- All data is deleted on the DELETE page on the ADMIT window.
- <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON and 30 minutes elapse after monitor power off.

WARNING

If more than one medical equipment is used together in the same facility, make sure all equipments have the same alarm default settings (alarm master). If the medical equipments have different alarm default settings and when initialized, the alarm settings differ with the other equipments and alarm cannot be managed appropriately in the facility. If using different alarm default settings according to areas or wings in the facility, manage the alarms appropriately.

WARNING

When an alarm occurs:


- Check the patient first and take necessary measure to ensure patient's safety.
- Remove the cause of the alarm.
- Check the alarm settings on the bedside monitor and change the alarm settings if necessary.

What is an Alarm

When the monitor detects an abnormal patient condition, it can generate an alarm sound, screen indication and alarm lamp indication. When the optional recorder module is installed in the monitor, ECG waveforms and data can be recorded at an alarm occurrence. You can set each individual alarm condition. There are four types of alarms: vital signs, arrhythmias, technical and interbed alarms, and three levels of alarm: crisis, warning and advisory. The different alarm types are fully explained in the "Alarm Types" section and different alarm levels are explained in the "Alarm Indications" section.

NOTE

When the transport function is enabled or admit a new patient, check the alarm settings.



Alarm Level

There are three alarm levels.

- CRISIS:** Patient is in critical condition and the patient's life may be at risk. Immediate action must be taken. Electrodes or probe off, or incorrect lead or other cable connections may also cause this alarm.
- WARNING:** Patient is in critical condition. Prompt action should be taken. Electrodes or probe off, or incorrect lead or other cable connections may also cause this alarm.
- ADVISORY:** Electrodes, probe, cuff, lead and other cable connections or settings on the monitor are not appropriate for accurate measurement. Prompt action should be taken.

Alarm Priority

Alarm Sound/Alarm Indicator

When several alarms occur at the same time, only the alarm with the highest alarm level is indicated.

Alarm Messages on the Screen

When several alarms (arrhythmia, vital sign and technical alarms) with the same alarm level occur, the alarm messages for each alarm are alternately displayed on the home screen. The message display position depends on the alarm level.

Only one interbed ID can be displayed at a time on the home screen. When more than one interbed alarm occurs, the alarm messages for each alarming interbed ID are alternately displayed in the alarm level color when the <INTERBED ALARM> is set to ON.

Silencing/Suspending Alarms

You can temporarily silence current alarm sounds and indications for a 1, 2 or 3 minute period. See the "Silencing and Suspending Alarms" section. You can also silence an interbed alarm from this bedside monitor but the alarm silence time depends on the setting on the alarmed bed. For interbed alarms, refer to Section 9 "Interbed Window".

5. ALARM FUNCTION

WARNING

During alarm suspension (“ALARMS SUSPENDED” or “ALL ALARMS OFF” message displayed), all alarms are turned off. Be careful when you suspend the alarm.

WARNING

Do not turn all alarms off with the ALL ALARMS OFF or BYPASS key when there is no medical staff around the patient or when the patient is connected to a ventilator.

The BYPASS key is only available in OR mode. The site mode is set on the SYSTEM SETUP window. Refer to Administrator’s Guide, Section 3.

Either the SUSPEND MONITORING, SUSPEND ALARMS or ALL ALARMS OFF/BYPASS key is displayed on the MENU window. The key to be displayed on the MENU window is set on the SYSTEM SETUP window. Refer to Administrator’s Guide, Section 3.

The SUSPEND MONITORING, SUSPEND ALARMS or BYPASS key can be assigned to one of the function keys. Refer to Administrator’s Guide, Section 3.

When the monitor connected to the central monitor network, the bedside monitor alarm can be silenced by touching the Silence Alarms key on the central monitor. For details, refer to the central monitor operator’s manual.

Alarm Master

For fast and easy alarm setup, a group of alarm items can be set all together at one time. For example, there may be typical alarm settings at your hospital, or you may have certain alarm settings for certain patients. There is one alarm master for vital signs and one alarm master for arrhythmias. The alarm masters are set by the administrator on the MASTER window of the SYSTEM SETUP window.

Even when alarms are set by an alarm master, individual alarm settings can still be changed on the ALARM LIMITS and ARRHYTHM ALARMS windows or the alarm setting window of each parameter window. See the “Setting Alarm” section.

WARNING

If more than one medical equipment is used together in the same facility, make sure all equipments have the same alarm default settings (alarm master). If the medical equipments have different alarm default settings and when initialized, the alarm settings differ with the other equipments and alarm cannot be managed appropriately in the facility. If using different alarm default settings according to areas or wings in the facility, manage the alarms appropriately.

Automatic Recording

When the optional recorder module is installed in the monitor, you can set the monitor to automatically record ECG waveforms and data when an alarm occurs. See the “Turning Automatic Alarm Recording On/Off” section.

If a higher level alarm occurs during another alarm recording, the present alarm recording is canceled and the higher level alarm is recorded.

From the bedside monitor, the alarm recording cannot be recorded on the recorder of the connected central monitor.

Alarm Setting

Usually, alarms are set before monitoring, but alarms can be set or changed anytime without interrupting monitoring.

If you turn the bedside monitor power off, all alarm settings return to the alarm master settings of the SYSTEM SETUP window 30 minutes later when <AUTO ADMIT> is set to ON. When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to OFF, you can select whether to save the settings or initialize the master settings.

To set a parameter alarm to off, set the upper and lower limits to OFF.

WARNING

Check the alarm settings when admitting a new patient and whenever the patient condition changes and change the alarm settings if necessary. The alarm settings return to the alarm master settings on the SYSTEM SETUP window when:

- All data is deleted on the DELETE page on the ADMIT window.
- <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON and 30 minutes elapse after monitor power off.

WARNING

If more than one medical equipment is used together in the same facility, make sure all equipments have the same alarm default settings (alarm master). If the medical equipments have different alarm default settings and when initialized, the alarm settings differ with the other equipments and alarm cannot be managed appropriately in the facility. If using different alarm default settings according to areas or wings in the facility, manage the alarms appropriately.

CAUTION

When the alarm limit is set to OFF, there will be no alarm for that limit. Depending on the setting, the alarm off mark might not be displayed on the screen. Be careful when you set the alarm limit to OFF.

CAUTION

When the alarm is turned OFF for an arrhythmia, there will be no alarm for that arrhythmia type. There is no message or mark to indicate that a certain arrhythmia alarm is turned off. Therefore, be careful when you turn off an arrhythmia alarm.

CAUTION

When the ZS-900P transmitter is attached to the bedside monitor, check the alarm, arrhythmia and monitoring settings on the central monitor or telemetry system. The transmitter does not transmit the alarm, arrhythmia and monitoring setting information.

Canceling the Technical Alarm

When you remove a sensor cable, probe cable or input unit from the bedside monitor and press the [Silence Alarms] key, the technical alarm can be canceled. Touching the SUSPEND MONITORING, SUSPEND ALARMS, BYPASS and ALL ALARMS OFF keys also cancel the technical alarm.

Adjusting Alarm Sound Volume

The alarm sound volume can be adjusted on the VOLUME window. Refer to “Changing Sound Volume Settings” in Section 3.

Alarm Activation after Power On

CAUTION

After the monitor power is turned on, parameter-related alarms do not function until the parameters are monitored.

When the monitor power is turned on, alarms are suspended while the monitor is waiting for the electrodes and probe to be attached to the patient. The monitoring starts when the connection cord is connected to the socket on the monitor and the electrodes or probe are attached to the patient. The alarm activates when one of the following occurs:

- at least one parameter is measured and a value is displayed (when AUTO is selected for <ALARM ACTIVATION DELAY> on the ALARM window of the SYSTEM SETUP window)
- ECG, SpO₂ or IBP is continuously monitored for the selected time (when 1 min, 2 min or 3 min is selected for <ALARM ACTIVATION DELAY>)
- NIBP is measured (when 1 min, 2 min or 3 min is selected for <ALARM ACTIVATION DELAY>)

ALARM HISTORY Window

The vital sign data is saved as a file on a vital sign or arrhythmia alarm occurrence. These data can be viewed on the ALARM HISTORY window. Refer to “Alarm History Window” in Section 6.

Interbed Alarm

The bedside monitor can display monitoring data of up to 16 other beds in the network on the INTERBED window. To do this you must register the other beds as “interbed” beds. When an alarm occurs at an interbed bed, the highlighted “ALARM bed name” of the alarmed interbed appears in the alarm priority color on the home screen and “Ping” sounds are generated three times. The interbed alarm can also be silenced from this bedside monitor. The interbed alarm can only be suspended on the alarmed bed. The interbed alarm on or off and automatic INTERBED window display on an interbed alarm occurrence can be set on the SETTINGS window of the INTERBED window. Refer to Section 9. When this monitor is monitored by another monitor with the interbed function, the other monitor can silence alarms on this monitor.

CAUTION

The interbed window only appears on the home screen when an interbed alarm occurs and <AUTO INTERBED DISPLAY> is set to ON.

NOTE

The interbed alarm for another bed is lower level than any other alarm for this bed. Therefore, the interbed alarm might not be indicated during an alarm for this bed.

Alarm Types

Alarms are divided into 4 categories: vital signs, arrhythmia, technical and interbed alarms. The alarm name is displayed on the screen when an alarm occurs. For the vital signs and arrhythmia alarms, waveforms and data can be recorded in automatic alarm recording when an optional recorder module is installed in the monitor.

For the alarm types which are not classified into alarm levels, only the message is displayed.

Vital Signs Alarms

Vital sign alarm occurs when the parameter value exceeds the upper or lower alarm limit.

Arrhythmia Alarms

Arrhythmia name	Description
ASYSTOLE	Longer than 3 to 10 seconds (selectable) with no QRS complex.
VF	Ventricular fibrillation longer than 4 seconds.
VT	Ventricular tachycardia. 3 to 9 (selectable) or more consecutive VPCs when heart rate exceeding the VT heart rate limit (16 to 300 beats/min selectable).
EXT TACHY* ¹	Extreme tachycardia exceeding the EXTREME TACHY limit.
EXT BRADY* ¹	Extreme bradycardia dropping below the EXTREME BRADY limit.
VPC RUN	VPC short run. 3 to 8 (selectable) consecutive VPCs when heart rate exceeding the VPC RUN heart rate limit (16 to 300 beats/min selectable).
V BRADY* ¹	Ventricular bradycardia. 3 or more consecutive VPCs when heart rate dropping below V BRADY heart rate limit (15 to 299 beats/min selectable).
SV TACHY* ¹	Supraventricular tachycardia. 3 to 9 (selectable) or more consecutive normal QRS of regular R-R interval when heart rate exceeding the SV TACHY heart rate limit (16 to 300 beats/min selectable).
TACHYCARDIA	Heart rate above the upper heart rate limit.
BRADYCARDIA	Heart rate below the lower heart rate limit.
PAUSE* ¹	1 to 3 seconds (selectable) with no QRS.
COUPLET	VPC couplet (paired VPCs). 2 consecutive VPCs.
EARLY VPC	Early VPC including R-on-T type. VPC with a time interval from the preceding normal QRS complex of less than approximately one-third of the normal R-R interval, at heart rate dropping below 120* ² beats/min.
MULTIFORM* ¹	Two different shaped VPCs within the last 3 minutes.
V RHYTHM* ¹	Ventricular rhythm. 3 or more consecutive VPCs.

Arrhythmia name	Description
BIGEMINY	Ventricular bigeminy. 3 or more consecutive pairs of VPC and normal QRS. A dominant rhythm of N-V-N-V-N-V (N = normal beat, V = ventricular beat)
TRIGEMINY* ¹	Ventricular trigeminy. A dominant rhythm of N-N-V-N-N-V.
FREQ VPC	Frequent VPCs. VPC rate (VPCs/min) reaching or exceeding the preset limit of 1 to 99 VPCs/min (selectable).
VPC	Ventricular premature contraction.
IRREGULAR RR* ¹	Consistently irregular R-R intervals.
PROLONGED RR* ¹	R-R interval 1.75 times longer than the dominant R-R interval.
NO PACER PULSE* ¹ * ³	No QRS and pacing pulse within the bradycardia limit. Oversensing.
PACER NON-CAPTURE* ¹ * ³	No QRS from the preceding pacing pulse for the preset time interval (40 to 480 ms selectable). Non-capture.

*¹ These arrhythmias become available when “EXTENDED” is selected for <ARRHYTHMIA TYPE> on the SYSTEM SETUP screen. The arrhythmia type setting is not available on the BSM-6000A series bedside monitors. For BSM-6000A series, arrhythmia type is STANDARD only.

*² 120 beats/min when <QRS DETECTION TYPE> is set to ADULT, 150 beats/min when <QRS DETECTION TYPE> is set to CHILD or NEONATE.

*³ Available only when DETECT in the <PACING> box is set to ON.

When an arrhythmia alarm is generated, even if the patient recovers quickly from the arrhythmia, the alarm status continues for a short time. The time depends on the alarm level.

- CRISIS: 30 s
- WARNING: 20 s
- ADVISORY: 10 s

Technical Alarms

ECG Related Alarms

Alarm Name	Description
ECG CHECK ELECTRODES	Electrode loose or disconnected.
ECG CHECK ELECTRODE --	Specified electrode loose or disconnected
ECG MODULE ERROR	Module malfunction.

Respiration Related Alarms

Alarm Name	Description
RESP CHECK SENSOR	The respiration pickup is damaged.
RESP CONNECTOR OFF	The respiration pickup is disconnected from the monitor (thermistor).

CO₂ Related Alarms

Alarm Name	Description
CO ₂ APNEA	Apnea exceeded the apnea alarm limit.
CO ₂ CHANGE ABSORBENT	The CO ₂ absorption agent must be replaced. (Sidestream method only)
CO ₂ CHANGE ADAPTER	The CO ₂ adapter is damaged.
CO ₂ CHECK SENSOR	Insufficient sensor light. (Mainstream method only)
CO ₂ CHECK EXTERNAL DEVICE	The AG-400RK CO ₂ unit is disconnected from the bedside monitor.
CO ₂ CONNECTOR OFF	CO ₂ connection cord is disconnected from the socket during measurement. (Mainstream method only)
CO ₂ DEVICE ERROR	CO ₂ unit failure. (Sidestream method only)
CO ₂ LINE BLOCK	The airway adapter, FilterLine or exhaust gas adapter is clogged. (Sidestream method only)
CO ₂ NO FILTER LINE	The FilterLine is not properly connected to the CO ₂ unit or an unspecified sampling tube is used. (Sidestream method only)
CO ₂ SENSOR ERROR	CO ₂ sensor is damaged. (Mainstream method only)

Microcap® Related Alarms

Alarm Name	Description
CO ₂ CHECK EXTERNAL DEVICE	The Microcap® monitor is disconnected from the bedside monitor. Communication error between the bedside monitor and Microcap® monitor.
CO ₂ DEVICE ERROR	Microcap® monitor or QF-921P interface failure.
CO ₂ LINE BLOCK	The airway adapter, filterline or exhaust gas tube is clogged and CO ₂ cannot be measured.
CO ₂ NO FILTERLINE	The filterline is not connected to the Microcap® monitor or an unspecified tube is connected.

SpO₂ Related Alarms

Alarm Name	Description
SpO ₂ -2 ALARM	Alarm occurring on the pulse oximeter. (when using an IF-919P or IF-925P only)
SpO ₂ /SpO ₂ -2 CANNOT DETECT PULSE	Pulse cannot be detected.
SpO ₂ /SpO ₂ -2 CHANGE PROBE	SpO ₂ probe or connection cord is damaged.
SpO ₂ /SpO ₂ -2 CHECK PROBE	Finger probe is not attached to the patient firmly or the amount of transmitted light is too small to measure.
SpO ₂ /SpO ₂ -2 CHECK PROBE SITE	The probe is not attached at the appropriate site or the probe is past its expiration date.
SpO ₂ /SpO ₂ -2 CONNECTOR OFF	SpO ₂ connection cord is disconnected from the SpO ₂ socket during monitoring.
SpO ₂ /SpO ₂ -2 LIGHT INTERFERENCE	Too much light on probe.
SpO ₂ /SpO ₂ -2 MODULE ERROR	SpO ₂ hardware malfunction.

NIBP Related Alarms

Alarm Name	Description
NIBP AIR LEAK	Cuff pressure does not change after inflation.
NIBP CANNOT DETECT PULSE	Measurement cannot be performed because the patient's pulse wave is small, the cuff or hose leaks air, the cuff hose is obstructed or the cuff is not connected.
NIBP CHECK INTERVAL SETTING	NIBP is measured at 1 minute intervals for more than 30 minutes.
NIBP CONNECTOR OFF	NIBP hose is disconnected from the cuff socket during monitoring.
NIBP CUFF OCCLUSION	Cuff pressure does not decrease after measurement has completed.
NIBP HIGH CUFF PRESS	Enormous pressure was applied by the pressure of the cuff.
NIBP MEAS TIME OUT	The measuring time exceeded the specified time.
NIBP MODULE ERROR	NIBP module malfunction.
NIBP SAFETY CIRCUIT RUNNING	Instrument automatically stopped inflating.
NIBP SYSTOLIC OVER	Systolic value is outside the measurable range.

IBP Related Alarms

Alarm Name	Description
PRESS CHECK SENSOR	Blood pressure transducer is disconnected from the IBP connection cord or the IBP connection cord is damaged.
PRESS CONNECTOR OFF	IBP connection cord is disconnected from the socket during measurement.
PRESS THIS LABEL IS ALREADY REGISTERED	More than one IBP connection cord with the same label are used.

Temperature Related Alarms

Alarm Name	Description
TEMP CHECK SENSOR	Temperature sensor is disconnected from the TEMP socket or temperature connection cord is disconnected from the MULTI socket, or the probe or connection cord is damaged.
TEMP CONNECTOR OFF	Temperature connection cord is disconnected from the socket during monitoring.
TEMP THIS LABEL IS ALREADY REGISTERED	More than one temperature probe with the same label are used.

BIS Related Alarms

Alarm Name	Description
BIS CHECK EXTERNAL DEVICE	The BIS monitor is disconnected from the bedside monitor. (when using a BIS monitor only)

5. ALARM FUNCTION

Alarm Name	Description
BIS CHECK SENSOR	The BIS sensor is detached from the patient. (when using a BIS processor or a BISx only)
	The BIS sensor is disconnected from the PIC Plus patient interface cable. (when using a BIS processor or a BISx only)
	The PIC Plus patient interface cable is disconnected from the BIS processor. (when using a BIS processor or a BISx only)
	The impedance between the BIS sensor and skin is too high. (when using a BIS processor or a BISx only)
BIS CONNECTOR OFF	The BIS processor is disconnected from the connection cord or the connection cord is disconnected from the monitor. (when using a BIS processor or a BISx only)
BIS MODULE FAILURE	Faulty BIS processor. (when using a BIS processor or a BISx only)
BIS SENSOR ERROR	The BIS sensor failure. (when using a BIS processor or a BISx only)
BIS SENSOR EXPIRED	BIS sensor is past its expiration date. (when using a BIS processor or a BISx only)

CO Related Alarms

Alarm Name	Description
CO CHECK SENSOR	Tb sensor is disconnected from the CO connection cord or the CO connection cord is damaged.
CO CONNECTOR OFF	CO connection cord is disconnected from the socket during monitoring.

Gas Related Alarms

Alarm Name	Description
GAS APNEA	Apnea exceeded the apnea alarm limit.
GAS CHANGE WATERTRAP	The water trap is clogged.
	The sampling line is clogged.
	The exhaust gas tube is clogged.
GAS CHECK EXTERNAL DEVICE	Measure switch on the unit is turned off.
	The connection cable is disconnected from the monitor.
	An error occurs in the communication between the unit and monitor.
	The power cord is disconnected. (GF-210R/220R only)
	<GAS MEASUREMENT> on the GAS window is OFF. (GF-110PA/120PA and GF-210R/220R only)
GAS CHECK SAMPLE LINE	The sampling gas inlet on the water trap or sampling gas outlet on the rear panel of the unit is pressurized. (AG-920R only)
GAS CHECK WATERTRAP	The water trap is not attached properly. The sampling line is not connected properly.
	An unspecified sampling line is used. (GF-210R/220R only)

Alarm Name	Description
GAS EXTERNAL DEVICE ERROR	Faulty unit.
GAS LINE BLOCK	The water trap is clogged.
	The sampling line is clogged.
	The exhaust gas tube is clogged.
GAS MIXED GAS	Two anesthetic agents are detected at the same time when the vaporizer is changed.
	Wrong agent is delivered to the vaporizer.
	Two anesthetic agents are detected when two vaporizers operated at the same time.
GAS OVERHEAT	Faulty fan. (GF-210R/220R only)

O₂ Related Alarms

Alarm Name	Description
O ₂ CONNECTOR OFF	FiO ₂ connection cord is disconnected from the socket during monitoring.
O ₂ CHECK SENSOR	FiO ₂ sensor is disconnected from the FiO ₂ connection cord or the FiO ₂ connection cord is damaged.

VENT Related Alarms

Alarm Name	Description
VENT ALARM	Alarm occurring on the ventilator.
VENT CHECK EXTERNAL DEVICE	The ventilator is disconnected from the bedside monitor.
	Communication error between the bedside monitor and ventilator.

TOF Related Alarms

Alarm Name	Description
TOF ALARM	There is an error on the TOF-watch® SX.
TOF CHECK EXTERNAL DEVICE	The TOF-watch® SX is disconnected from the bedside monitor.
	Communication error between the bedside monitor and TOF-watch® SX.

CCO Related Alarms

Alarm Name	Description
CCO ALARM	Alarm on the CCO monitor.
CCO CHECK EXTERNAL DEVICE	The CCO monitor is disconnected from the bedside monitor.
	Communication error between the bedside monitor and external device.

PiCCO Related Alarms

Alarm Name	Description
PCCO CHECK EXTERNAL DEVICE	The PiCCO monitor is disconnected from the bedside monitor.
	Communication error between the bedside monitor and external device.

FLOW/Paw Related Alarms

Alarm Name	Description
FLOW APNEA	Apnea exceeded the apnea alarm limit.
FLOW CHECK EXTERNAL DEVICE	Measure switch on the unit is turned off.
	The connection cable is disconnected from the monitor.
	An error occurs in the communication between the unit and monitor.
	The power cord is disconnected.
	<FLOW/Paw MEASUREMENT> on the FLOW/Paw window is OFF.
FLOW CONNECTOR OFF	Faulty flow tube.
	The flow tube is disconnected from the unit.
FLOW EXTERNAL DEVICE ERROR	Faulty unit.

EEG Related Alarms

Alarm Name	Description
EEG CHECK ELECTRODES	The electrode is dry or not attached to the patient.
	The electrode lead is disconnected from the EEG connection cord.
	Contact between the electrode lead clip and electrode is poor (when using disposable electrodes).
	The electrode lead is damaged.
	Abnormal electrode polarization.
	The electrode impedance is too high.
	The EEG connection cord is disconnected then connected.
EEG CHECK EXTERNAL DEVICE	The neuro unit is disconnected from the bedside monitor.
EEG CONNECTOR OFF	The EEG connection cord is disconnected from the neuro unit.
	The EEG connection cord is damaged.

tcPO₂/tcPCO₂ Related Alarms

Alarm Name	Description
tcPO ₂ /PCO ₂ ALARM	Alarm on the transcutaneous monitor.
tcPO ₂ /PCO ₂ CHECK EXTERNAL DEVICE	The transcutaneous monitor is disconnected from the bedside monitor.
	Communication error between the bedside monitor and transcutaneous monitor.

5

Other Alarms

Alarm Name	Description
--- ALARM	Alarm concerning the --- (parameter name)
BATTERY ERROR	Battery problems.
BATTERY WEAK	Battery pack is fully discharged.
CLOCK IC FAILURE	The clock IC is damaged.
DATA SEND ERROR	Sending data to the central monitor failed when using the transport function.
INPUT UNIT DISCONNECT	The input unit is disconnected from the monitor when the transport function is enabled.
INPUT UNIT FAILURE	Communication error between the input unit and main unit.
	The QM-600P memory unit in the input unit is damaged.
	The data is sent to a bedside monitor or central monitor which has a different time zone setting and data in the input unit is deleted.
MPU MODULE ERROR	MPU circuit malfunction.
MULTILINK CONFIG ERROR	Communication failure between QF series interface or IF series communication cable and monitor.
MULTILINK POWER ERROR	Multi-link power supply failure.
PARAMETER NOT AVAILABLE	Connected cord or cable of the parameter is not available on the monitor.
PRINT ERROR	Printing failed.
TRANSMITTER CONNECTOR OFF	The connection cord of the transmitter is disconnected from the monitor.

Messages

The following messages are monitoring information and are not considered alarms.

ECG Related Messages

Message	Description
ARRHYTHMIA ANALYSIS OFF	Arrhythmia analysis is turned off.
ECG AUTO LEAD CHANGE	Monitoring lead is being changed by auto lead change function.
ECG CANNOT ANALYZE	Noise interference for more than 30 seconds and heart rate cannot be counted and arrhythmia cannot be analyzed.
ECG LEARNING	Learning QRS for arrhythmia analysis.
ECG NOISE	(During the first 30 seconds) Too much noise preventing analysis.
ECG PACING	Paced QRS is detected. (This message appears only when PACING DETECT is set to ON.)

Respiration Related Messages

Message	Description
RESP OFF	Respiration monitoring in impedance mode is turned off.

CO₂ Related Messages

Message	Description
CO ₂ CAL??	Zero calibration is not performed when using a TG-950P CO ₂ sensor kit.
CO ₂ CAL COMPLETE	Calibration is complete.
CO ₂ CAL ERROR	Calibration failed.
CO ₂ PLEASE WAIT	Measurement of the sensitivity calibration is completed and calculation is started. (Sidestream method only)
CO ₂ PURGING	Purging to remove clogging of the sampling path. (Sidestream method only)
CO ₂ WARMING UP	The CO ₂ unit is warming up. (Sidestream method only)
CO ₂ ZEROING	Zeroing is performed when using a TG-950P CO ₂ sensor kit.
CO ₂ ZEROING COMPLETE	Calibration is complete when using a TG-950P CO ₂ sensor kit.
CO ₂ ZEROING ERROR	Zeroing failed when using a TG-950P CO ₂ sensor kit.

SpO₂ Related Messages

Message	Description
SpO ₂ /SpO ₂ -2 CANNOT DETECT PULSE	Pulse cannot be detected.
SpO ₂ /SpO ₂ -2 CHECK PROBE SITE	The probe is not attached to the appropriate site or the probe is damaged.
SpO ₂ /SpO ₂ -2 DETECTING PULSE*	Searching for the correct pulse wave. Auto gain control is being done. When the message is displayed for more than 20 seconds, the detected pulse is too small to measure.
SpO ₂ /SpO ₂ -2 LOW QUALITY SIGNAL	Pulse waveform is not stable.
SpO ₂ /SpO ₂ -2 WEAK PULSE	Poor peripheral circulation.

* When this message is displayed for more than 30 seconds, the message changes to the “CANNOT DETECT PULSE” alarm.

NIBP Related Messages

Message	Description
NIBP INFLATION PRESS LOW	Insufficient cuff inflation pressure.
NIBP INFLATION TIME PASSED	Venous puncture cuff inflation time is passed.
NIBP MEASURING NIBP	Start venous puncture during NIBP.
NIBP PLEASE WAIT	Measurement and cuff inflation started before the cuff is deflated enough.
NIBP REMEASURING	Remeasuring NIBP.
NIBP ZEROING	NIBP zero balance adjustment is performed. If the message does not disappear, the monitor has a malfunction.
NIBP WEAK PULSE	Patient's pulse is small.

IBP Related Message

Message	Description
PRESS OUT OF RANGE	The measured value is outside the measurable range.
PRESS ZERO CALIBRATING	Zero balance adjustment is performed.
PRESS ZERO IMBALANCE	Zero balance is not adjusted.
PRESS ZERO OUT OF RANGE	Cannot adjust zero balance.
PRESS ZERO UNSTABLE	Unstable zero balance.
PRESS ZEROING COMPLETE	Zero balance adjustment is complete.

BIS Related Messages

Message	Description
BIS HIGH IMPEDANCE	The impedance between the BIS sensor and skin is too high. (when using a BIS processor or a BISx only)
BIS CHECKING IMPEDANCE	The impedance of the BIS sensor is being checked. (when using a BIS processor or a BISx only)
BIS NOISE	Noise interference. (when using a BIS processor or a BISx only)

O₂ Related Messages

Message	Description
O ₂ CAL??	Calibration is not performed.
O ₂ CALIBRATING	Calibration is performed.

CO Related Messages

Message	Description
CO BASELINE DRIFT	Baseline is not stable.
CO DETECTING BASELINE	Searching for the baseline of the blood temperature.
CO INJECT	Injectate is not injected.
CO INJECTION TIME OUT	The injectate is not injected within the specified time.
CO MEASURING CO	Measuring the CO value.
CO OUT OF RANGE	Measured value is outside the measurable range.
CO Tb TEMP ERROR	The blood temperature is out of range.
CO THERMODILUTION CURVE ERROR	Returned to the baseline of the thermodilution curve too late. Possible endocardial shunt.
CO Ti TEMP ERROR	The injectate is not cooled.

Gas Related Messages

Message	Description
GAS CALIBRATING	Air or gas calibration is being performed.
GAS CAL COMPLETE	Air or gas calibration is complete. (GF-110P/120P and GF-210R/220R only)
GAS CAL ERROR	The sampling line or exhaust gas tube is clogged.
	Contaminated air due to leaking prevented air calibration.
	The pressure in the gas cylinder is less than 0.1 MPa. (AG-920R and GF-110PA/120PA only)
	Correct gas is not used for calibration. (AG-920R and GF-110PA/120PA only)
GAS OUT OF RANGE	The measured value is outside the measurable range.
	The measurement sensitivity has shifted.
GAS PURGING	Purging to remove clogging from the sampling line. (AG-920R only)
GAS UNSPECIFIED ACCURACY	The measured value is outside the accuracy range. (AG-920R only)
	The measurement sensitivity has shifted. (AG-920R only)
GAS WARMING UP	The unit is still warming up.

5

FLOW/Paw Related Messages

Message	Description
FLOW CAL COMPLETE	Zero calibration is complete.
FLOW CAL ERROR	There was vibration during calibration and zeroing failed.
	Nearby device was generating a strong noise during calibration and zeroing failed.
FLOW OUT OF RANGE	The measured value is outside the measurable range.
FLOW ZERO CALIBRATING	Zero calibration is being performed.

EEG Related Messages

Message	Description
EEG CALIBRATING	The CAL key on the EEG window is touched to display the calibration waveforms.
EEG CHECKING IMPEDANCE	Checking electrode impedance.
EEG HIGH IMPEDANCE	The electrode impedance is too high.
EEG RESETTING BASELINE	The RESET key on the EEG window is touched to return all EEG waveforms to the baseline position.

Microcap® Related Messages

Message	Description
CO ₂ PURGING	Purging to remove clog from the sampling path.
CO ₂ WARMING UP	The Microcap® monitor is warming up. Measurement is not possible.
CO ₂ ZERO CALIBRATING	Auto zero balance adjustment is being performed.

Other Messages

Message	Description
ALARM SILENCE	Alarm is suspended.
ALARMS SUSPENDED	The [Silence Alarms] key was pressed before alarm occurrence.
ALARMS SUSPENDED: X min	Remaining suspended time.
ALL ALARMS OFF	All alarms are OFF.
CALIBRATING	Monitor is calibrated.
CLOSE PAPER MAGAZINE	Recorder door is open.
CONNECT INPUT UNIT	The input unit is not connected to the main unit and the monitor is not ready for monitoring when the transport function is enabled.
FREEZE	Waveforms are frozen.
INSERT REC PAPER	No recording paper.
Bed name INTERBED ALARM	Alarm occurred on an interbed bed of the bed name.
INVALID CARD	Invalid SD card is inserted.
MONITOR OFF	Monitor cannot access to interbed bed.
PRINTING	Printing now.
SENDING DATA	The input unit is removed from a bedside monitor and connected to another bedside monitor in a central monitor network. The data of the source bedside monitor is sent to the central monitor.
SIMULATED DATA	The displayed data is simulated data.
UPDATING DATA	Changing the parameter on the trend screen.

Alarm Indications

5

Overview

The monitor can indicate alarms both visually and audibly:

- Alarm sound
- Alarm message or highlighted numeric data on the screen
- Alarm indicator: red blinking, yellow blinking or cyan or yellow lit LED

Alarm control marks indicating that various alarm functions are turned off are also displayed.

There are two color display modes. The color mode and colors are set on the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3.

PARAMETER: Different colors can be set for each parameter. When an alarm occurs, the alarmed parameter data is highlighted.

ALARM: The same color is set for all parameters. When an alarm occurs, the alarmed parameter color changes according to the alarm level set on the SYSTEM SETUP window.

CRISIS: red
 WARNING: yellow
 ADVISORY: cyan
 or,
 CRISIS: red
 WARNING: orange
 ADVISORY: yellow

The alarm indicator on the monitor indicates three alarm levels: crisis, warning and advisory. The lamp blinks or lights according to the alarm level. The colors are set on the SYSTEM SETUP window.

CRISIS: Blinking red
 WARNING: Blinking yellow
 ADVISORY: Lights in cyan or yellow


5. ALARM FUNCTION

Individual Alarm Indications

The alarm level for the HR/PR (upper and lower), VPC, ST, RR, APNEA, CO₂(E), CO₂(I), SpO₂, SpO₂-2*¹, ΔSpO₂*¹, BIS, NIBP, PRESS, TEMP, ΔT, ΔT2, O₂(E), O₂(I), N₂O(E), N₂O(I), HAL(E), HAL(I), ISO(E), ISO(I), ENF(E), ENF(I), DES(E), DES(I), SEV(E), SEV(I), MV*², Ppeak*², PEEP*², SEF*², TP*², ECG CHECK ELECTRODES, CANNOT ANALYZE, SpO₂ CHECK PROBE, and arrhythmia (ASYSTOLE, VF, VT, V BRADY, EXT TACHY, EXT BRADY, SV TACHY, VPC RUN, TACHYCARDIA, BRADYCARDIA, COUPLET, EARLY VPC, MULTIFORM, V RHYTHM, PAUSE, BIGEMINY, TRIGEMINY, VPC, IRREGULAR RR, PACER NON-CAPTURE, PROLONGED RR, NO PACER PULSE) alarms can be selected on the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3.

*¹ Available only when an AY-661P, AY-663P, AY-671P or AY-673P input unit is used.

*² These alarms are not available for BSM-6000A series.



ARRHYTHMIA ANALYSIS message is not highlighted when the site setting is NICU.

Vital Signs Alarms

Alarm	Alarm level	Alarm sound	Alarm display	Sound/display duration	Alarm indicator LED
UPPER/ LOWER HR*1/PR	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
VPC	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
ST	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
RR	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
APNEA	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Highlighted “APNEA ALARM” message	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted “APNEA ALARM” message		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted “APNEA ALARM” message		Lights in cyan/yellow
SpO ₂ , SpO ₂ -2*2, ΔSpO ₂ *2	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow

*1 When arrhythmia analysis is turned on, the “TACHYCARDIA” or “BRADYCARDIA” message also appears.

*2 Available only when an AY-661P, AY-663P, AY-671P or AY-673P input unit is used.

5. ALARM FUNCTION

Alarm	Alarm level	Alarm sound	Alarm display	Sound/display duration	Alarm indicator LED
NIBP	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
PRESS	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
TEMP, ΔT, ΔT2	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
CO ₂ (E)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted “CO ₂ (E) ALARM” message		Blinking yellow
CO ₂ (I)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted “CO ₂ (I) ALARM” message		Blinking yellow
O ₂ (E)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
O ₂ (I)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow

Alarm	Alarm level	Alarm sound	Alarm display	Sound/display duration	Alarm indicator LED
N ₂ O(E)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
N ₂ O(I)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
HAL(E)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
HAL(I)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
ISO(E)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
ISO(I)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
ENF(E)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow

5. ALARM FUNCTION

Alarm	Alarm level	Alarm sound	Alarm display	Sound/display duration	Alarm indicator LED
ENF(I)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
DES(E)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/ yellow
DES(I)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
SEV(E)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/ yellow
SEV(I)	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
MV*	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/ yellow
PEEP*	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/ yellow

Alarm	Alarm level	Alarm sound	Alarm display	Sound/display duration	Alarm indicator LED
Ppeak*	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
SEF*	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow
TP*	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted numeric data	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted numeric data		Lights in cyan/yellow

* These alarms are not available for BSM-6000A series.

Arrhythmia Alarms

Alarm	Alarm level	Alarm sound	Alarm display	Sound/display duration	Alarm indicator LED
ASYSTOLE VF VT	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted message	During detection	Blinking red
VPC RUN COUPLET EARLY VPC FREQ VPC EXT TACHY* EXT BRADY* V BRADY* SV TACHY* PAUSE*	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted message	During detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted message		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		Lights in cyan/yellow

5. ALARM FUNCTION

Alarm	Alarm level	Alarm sound	Alarm display	Sound/display duration	Alarm indicator LED
MULTIFORM* V RHYTHM* BIGEMINY TRIGEMINY* IRREGULAR RR* PROLONGED RR* NO PACER PULSE* PACER NON-CAPUTRE*	CRISIS	NK1 (Continuous pip sound), NK2 (Continuous ping sound) or IEC standard (ceg-gC)	Blinking highlighted message	At detection	Blinking red
	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted message		Blinking yellow
	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		Lights in cyan/yellow

* Available only when ARRHYTHMIA TYPE on the ECG page of the SYSTEM SETUP window is set to “EXTENDED”. The arrhythmia type setting is not available on the BSM-6000A series. For BSM-6000A series, arrhythmia type is STANDARD only.

Technical Alarms

ECG related alarms

Alarm	Alarm level	Alarm sound	Alarm display	Sound/display duration	Alarm indicator LED
ECG CHECK ELECTRODES	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted numeric data and message	During detection	Blinking yellow
ECG CHECK ELECTRODE – – ECG MODULE ERROR	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		Lights in cyan/yellow

CO₂ related alarms

Mainstream method

Alarm	Alarm level	Alarm sound	Alarm display		Sound/display duration	Alarm indicator LED
			Home screen	When a window is open		
CO ₂ BLOCKED LINE CO ₂ REPLACE SCRUBBER	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted message		During detection	Blinking yellow
CO ₂ CHANGE ADAPTER CO ₂ CHECK SENSOR CO ₂ NO LINE	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

Sidestream method

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
CO ₂ CHANGE ABSORBENT	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted message		During detection	Blinking yellow
CO ₂ CHECK EXTERNAL DEVICE	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow
CO ₂ DEVICE ERROR						
CO ₂ LINE BLOCK						
CO ₂ NO FILTERLINE						

Respiration related alarm

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
RESP CONNECTOR OFF RESP CHECK SENSOR	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

SpO₂ related alarms

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
SpO ₂ /SpO ₂ -2 CHANGE PROBE SpO ₂ /SpO ₂ -2 CHECK PROBE	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted message		During detection	Blinking yellow
SpO ₂ -2 ALARM SpO ₂ /SpO ₂ -2 CANNOT DETECT PULSE SpO ₂ /SpO ₂ -2 CHECK PROBE SITE SpO ₂ /SpO ₂ -2 CONNECTOR OFF SpO ₂ /SpO ₂ -2 LIGHT INTER- FERENCE SpO ₂ /SpO ₂ -2 MODULE ERROR	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

5. ALARM FUNCTION

NIBP related alarms

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
NIBP CUFF OCCLUSION NIBP SAFETY CIRCUIT RUNNING	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted message		During detection	Blinking yellow
NIBP AIR LEAK NIBP CANNOT DETECT PULSE NIBP CHECK INTERVAL SETTING NIBP MEAS TIME-OUT NIBP MODULE ERROR NIBP SYSTOLIC OVER	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

IBP related alarms

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
PRESS CHECK SENSOR PRESS CONNECTOR OFF PRESS THIS LABEL IS ALREADY REGISTERED	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

* The labels are displayed for BP.

Temperature related alarms

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
TEMP CHECK SENSOR TEMP CONNECTOR OFF TEMP THIS LABEL IS ALREADY REGISTERED	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

BIS related alarms

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
BIS CHECK EXTERNAL DEVICE BIS CHECK SENSOR BIS MODULE FAILURE BIS SENSOR ERROR BIS SENSOR EXPIRED BIS THIS PARAMETER IS ALREADY REGISTERED	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

CO related alarms

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
CO CHECK SENSOR CO CONNECTOR OFF	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

5. ALARM FUNCTION

Gas related alarms

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
GAS APNEA GAS LINE BLOCK GAS MIXED GAS	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted message		During detection	Blinking yellow
GAS CHANGE WATERTRAP GAS CHECK EXTERNAL DEVICE GAS CHECK WATERTRAP GAS DEVICE ERROR GAS OVERHEAT	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

O₂ related alarms

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
O ₂ CHECK SENSOR O ₂ CONNECTOR OFF	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

VENT related alarm

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
VENT ALARM VENT CHECK EXTERNAL DEVICE	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

TOF related alarm

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
TOF ALARM TOF CHECK EXTERNAL DEVICE	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

CCO and CCO/S $\bar{V}$ O₂ related alarm

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
CCO ALARM CCO CHECK EXTERNAL DEVICE	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

5

PiCCO related alarm

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
PiCCO CHECK EXTERNAL DEVICE	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

FLOW/Paw related alarms

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
FLOW APNEA	WARNING	NK1 (Continuous bing bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted message		During detection	Blinking yellow
FLOW CONNECTOR OFF FLOW CHECK EXTERNAL DEVICE FLOW DEVICE ERROR	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

5. ALARM FUNCTION

EEG related alarms

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
EEG CHECK ELECTRODES EEG CHECK EXTERNAL DEVICE EEG CONNECTOR OFF	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

tcPO₂/tcPCO₂ related alarms

Alarm	Alarm level	Alarm sound	Alarm display		Sound/ display duration	Alarm indicator LED
			Home screen	When a window is open		
tcPO ₂ /PCO ₂ ALARM tcPO ₂ /PCO ₂ CHECK EXTERNAL DEVICE	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message		During detection	Lights in cyan/yellow

Other Alarms

Alarm	Alarm level	Alarm sound	Alarm display	Sound/display duration	Alarm indicator LED
BATTERY ERROR BATTERY WEAK MULTI LINK CONFIG ERROR MULTI LINK POWER ERROR	WARNING	NK1 (Continuous bong sound), NK2 (Continuous ding ding sound) or IEC standard (ceg)	Highlighted message	During detection	Blinking yellow
DATA SEND ERROR INPUT UNIT DISCONNECT INPUT UNIT FAILURE MPU MODULE ERROR PARAMETER NOT AVAILABLE PRINT ERROR THIS PARAMETER IS ALREADY REGISTERED TRANSMITTER CONNECTOR OFF	ADVISORY	NK1 and NK2 (Single beep every 20 or 120 seconds) or IEC standard (ec)	Highlighted message	During detection	Lights in cyan/yellow

Interbed Alarms

The interbed alarm indication depends on the INTERBED ALARM setting on the SETTING window of the INTERBED window. Refer to Section 9.

When set to ON, the highlighted bed name is displayed on the upper right corner of the home screen. Three Ping sounds are generated at detection. When set to OFF, only the non-highlighted message is displayed.

Alarm Control Marks

When certain alarm functions are not available, an alarm control mark and the message is displayed in the upper part of the screen.



Alarm is silenced by pressing the [Silence Alarms] key on the bedside monitor or [SILENCE ALARMS] key on the remote control. Remaining minutes appears.



Alarms are suspended for a certain period.



Alarms are suspended infinitely or vital sign alarm limit is set to off.

Individual Vital Signs Alarm Off Marks

The vital sign alarm off mark can be displayed at every parameter which has the vital signs alarm limit set to OFF. The upper/lower alarm limits can also be displayed at each parameter.

Set this setting at <LIMIT DISPLAY> of the ALARM window on the SYSTEM SETUP window. See Administrator's Guide, Section 3. The default setting is VALUES.

When <LIMIT DISPLAY> is set to VALUES, for BSM-6000A series, when the limit is set to OFF, "OFF" is displayed. For BSM-6000K series, when the limit is set to OFF, "---" is displayed.

BSM-6000A series



BSM-6000K series




LIMIT DISPLAY set to VALUES

LIMIT DISPLAY set to MARK
BRIGHT

LIMIT DISPLAY set to MARK DIM

Flow of Alarm Function



Silencing and Suspending Alarms

Overview

Silencing an Alarm

When an alarm occurs, you can silence the alarm sound and indications for one, two or three minutes by pressing the  [Silence Alarms] key on the bedside monitor or remote control. When a vital signs alarm or arrhythmia alarm is silenced, the alarm resumes after the alarm silence ends. When a vital signs alarm other than NIBP or arrhythmia alarm is silenced, the alarm resumes after the alarm silence ends. When a technical alarm other than the following alarms is silenced, the alarm indication does not resume after the alarm silence ends. If the following alarms are silenced, the alarm resumes after the alarm silence ends.

- BATTERY ERROR
- BATTERY WEAK
- CO₂ CHANGE ABSORBENT
- CO₂ LINE BLOCK
- ECG CANNOT ANALYZE
- EXTERNAL DEVICE ALARM
- GAS CHECK SAMPLE LINE
- GAS LINE BLOCK
- GAS MIXED GAS
- MULTILINK CONFIG ERROR
- MULTILINK POWER ERROR
- NIBP CUFF OCCLUSION
- NIBP SAFETY CIRCUIT RUNNING
- SpO₂ CHANGE PROBE

When several alarms occur together and the  [Silence Alarms] key is pressed, all alarms are silenced. To cancel vital sign or arrhythmia alarm silence, press the  [Silence Alarms] key. <SILENCE ALARMS TIME> is set on the ALARM window of the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3.

When the Monitor is Connected to the Central Monitor

When the bedside monitor is connected to a central monitor network, all alarms are temporarily silenced by touching the Silence Alarms key on the central monitor. Refer to the central monitor operator's manual for details.

Suspending Alarms

All alarms can also be suspended before they occur. During alarm suspension, all alarms are off. This monitor has three types of alarm suspension according to the site mode.

Monitor Operation	Example of How This Function is Used	Key to Press	How the Alarm Function Comes Back
Suspends all alarms for 1, 2 or 3 minutes	For electrode replacement.	[SUSPEND ALARMS] key on the bedside monitor or remote control	When 1,2 or 3 minutes set on the <SUSPEND ALARMS TIME> elapse. When the [SUSPEND ALARMS] key is pressed again.
Suspends all alarms and NIBP STAT/SIM and auto measurement indefinitely	When the patient is being examined.	SUSPEND MONITORING key on the screen	When the SUSPEND MONITORING key is touched again.
	When the patient is connected to a heart-lung machine or being examined.		When the condition set for the <ALARM ACTIVATION DELAY> is met.* ¹
		BYPASS key on the screen (OR mode only)	When the BYPASS key is touched again.
Suspends all alarms indefinitely	When you want to turn off an unnecessary alarm in such situations as when the patient's vital signs are obviously out of normal range and the medical staff are aware that the patient is in an alarm condition and are currently treating the patient.	ALL ALARMS OFF key on the screen	When the ALL ALARMS OFF key is touched again.

*1

Setting of <ALARM ACTIVATION DELAY> on the SYSTEM SETUP window	Condition
AUTO	Alarm function activates when ECG, SpO ₂ or IBP* is monitored or NIBP** is measured and a value is displayed. * When SYS > DIA, the difference between these two values is 3 mmHg and this status continues for more than 3 seconds. ** When SYS, DIA or MAP value is measured. The alarm function is also recovered when the heart rate is 0.
1 min 2 min 3 min	When one of the following requirements is met. 1 ECG, SpO ₂ or IBP is continuously monitored for the selected time. 2 NIBP is measured (SYS, DIA or MAP value is measured) 3 Heart rate becomes 0.

The BYPASS key is only available in OR mode. The site mode is set on the SYSTEM CONFIGURATION screen. Refer to Administrator's Guide, Section 2.


Either the SUSPEND MONITORING, SUSPEND ALARMS, ALL ALARMS OFF/BYPASS key is displayed on the MENU window. The key to be displayed on the MENU window is set on the ALARM window of the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3.

The SUSPEND MONITORING, SUSPEND ALARMS or BYPASS key can be assigned to one of the function keys. Refer to Administrator's Guide, Section 3.



For the interbed alarm, refer to Section 9 "Interbed Window".

5. ALARM FUNCTION

The alarm off key on the MENU window



Alarm off keys

ALARM INACTIVATION Setting	ICU/NICU Site	OR Site
SUSPEND ALARMS		
ALL ALARMS OFF		ALARMS OFF TYPE: BYPASS 
		ALARMS OFF TYPE: ALL ALARMS OFF 

Alarm off function**SUSPEND MONITORING key**

Use this key to temporarily stop patient monitoring for examination. When this key is touched, all alarms and NIBP STAT/SIM and auto measurements are suspended. Alarms resume when the SUSPEND MONITORING key is touched again or when the <ALARM ACTIVATION DELAY> condition is met.

SUSPEND ALARMS key

Use this key to suspend all alarms for the time set in <SUSPEND ALARMS TIME>.

BYPASS key

Use this key when the patient is connected to a heart-lung machine. When this key is touched, all alarms and NIBP STAT/SIM and auto measurements are indefinitely suspended. Touch the BYPASS key and touch the YES key on the confirmation window. Alarms resume when the BYPASS key is touched again.

ALL ALARMS OFF key

Use this key to suspend all alarms indefinitely. Touch the ALL ALARMS OFF key and touch the YES key on the confirmation window. Alarms resume when the ALL ALARMS OFF key is touched again.

Silencing Alarms After Alarm Occurrence

During alarm silence,


- the “ALARM SILENCED” message, the suspended mark and the remaining minutes are displayed
- the alarm sound is silenced

The alarm silence time can be set to either 1, 2 or 3 minutes at <SILENCE ALARMS TIME> on the ALARM window of the SYSTEM SETUP window. Refer to Administrator’s Guide, Section 3. The default setting is 2 minutes.

If another alarm occurs during alarm silence, the alarm sound, indication and recording occur as usual. The alarm silence does not affect alarms which occur after the  [Silence Alarms] key is pressed. (A new occurrence of the silenced alarm condition is treated as a different alarm.)

Silencing an Alarm

Press the  [Silence Alarms] key. The “ALARMS SILENCED” message and the alarm silenced mark and the minutes remaining in the alarm silence are displayed on the screen.



Canceling Alarm Silence

Vital sign and arrhythmia alarm silence can be cancelled by pressing the  [Silence Alarms] key. The alarm silence mark disappears and all alarms are resumed. Parameter alarm and other alarm silence cannot be canceled.

Suspending Alarms Before Alarm Occurrence

Suspending Alarms

By touching the SUSPEND ALARMS key, all alarms for the patient are suspended for 1, 2 or 3 minutes. The alarm silence time can be set to either 1, 2 or 3 minutes at <SILENCE ALARMS TIME> on the ALARM window of the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3. The default setting is 2 minutes.



During alarm suspension, all alarms are suspended and

- the “ALARMS SUSPENDED” message is displayed
- the alarm sound is silenced
- all alarm recording is suspended.

Resuming Alarms

Alarms resume when the set minutes elapses or when the  [Silence Alarms] key is pressed again.

Suspending All Alarms Indefinitely

In OR Mode


You can suspend all alarms and NIBP STAT/SIM and auto measurements for an indefinite time by touching the BYPASS key on the MENU window.

The BYPASS key is displayed on the MENU window when it is selected at <ALARMS OFF TYPE> on the ALARM window of the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3.

WARNING

Do not turn all alarms off with the ALL ALARMS OFF or BYPASS key when there is no medical staff around the patient or when the patient is connected to a ventilator.

1. Press the [Menu] key. The MENU window appears.



5

2. Touch the BYPASS key. The following window appears for confirmation.



NOTE

If the [Silence Alarms] key is pressed when this window is displayed, the BYPASS function is cancelled and the alarm is silenced or suspended.

3. Touch the YES key. If you wish to cancel, touch the NO key.

The “BYPASS” messages appear on the screen.



When the <ALARM INDICATOR LIT> on the ALARM window of the SYSTEM SETUP window is set to ON, the red lamp of the alarm indicator lights when all alarms are indefinitely suspended with the BYPASS key.

To resume alarms, touch the “BYPASS” key again. Alarms can only resume by touching the “BYPASS” key.

To resume NIBP measurement in STAT or Auto mode, press the [NIBP START/STOP] key. Refer to User’s Guide, Part II, Section 5.


In ICU and NICU Mode

You can suspend all alarms for an indefinite time by touching the ALL ALARMS OFF key on the MENU window. When you start monitoring or during monitoring, you can use this function to temporarily turn all alarms off. The ALL ALARMS OFF key is displayed on the MENU window when it is selected at <ALARMS OFF TYPE> on the ALARM window of the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3.

WARNING

Do not turn all alarms off with the ALL ALARMS OFF or BYPASS key when there is no medical staff around the patient or when the patient is connected to a ventilator.

1. Press the [Menu] key. The MENU window appears.




2. Touch the ALL ALARMS OFF key. The following window appears for confirmation.

**NOTE**

If the  [Silence Alarms] key is pressed when this window is displayed, the ALL ALARMS OFF function is cancelled and the alarm is silenced or suspended.

3. Touch the YES key. If you wish to cancel, press the NO key.

The “ALL ALARMS OFF” message appears on the screen.



When the <ALARM INDICATOR LIT> on the ALARM window of the SYSTEM SETUP window is set to ON, the red lamp of the alarm indicator lights when all alarms are indefinitely suspended with the ALL ALARMS OFF key.


To resume alarms, touch the ALL ALARMS OFF key again. Alarms can only resume by touching the ALL ALARMS OFF key.

Suspending All Alarms and NIBP STAT and Auto Measurement Indefinitely

You can suspend all alarms and NIBP STAT/SIM and auto measurements for an indefinite time by touching the SUSPEND MONITORING key.

The SUSPEND MONITORING key is displayed on the MENU window when the SUSPEND ALARMS is selected at <ALARM INACTIVATION> on the ALARM window of the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3.

1. Press the [Menu] key. The MENU window appears.



5. ALARM FUNCTION

2. Touch the SUSPEND MONITORING key. The following window appears for confirmation.



3. Touch the YES key. If you wish to cancel, touch the NO key.

The “SUSPEND MONITORING” and “ALARMS SUSPENDED” messages appear on the screen alternately.



To resume alarms, touch the “SUSPEND MONITORING” key again. Alarms can only resume by touching the “SUSPEND MONITORING” key.

To resume NIBP measurement in STAT or Auto mode, press the $\diamond/\odot$ [NIBP START/STOP] key. Refer to User’s Guide, Part II, Section 5.

Turning Automatic Alarm Recording On/Off

If <ALARM RECORDING> on the RECORD window is set to ON and an alarm occurs, waveforms beginning 8 seconds before and ending 12 seconds after the alarm are automatically recorded. If this setting is OFF, you can still record waveforms manually.

Recording is only available when the optional recorder module is installed in the monitor.

You can select which waveform(s) to record by changing the recording pattern. See Section 10.


To cancel recording while an automatic vital signs alarm is being recorded, press the  [Record] key.

NOTE

When an arrhythmia alarm is turned OFF on the ARRHYTHM ALARMS or ARRHYTHM ALARMS window of the ECG window, there will be no alarm recording for that arrhythmia type even when <ALARM RECORDING> is set to ON on the RECORD window.

To set automatic vital signs alarm recording on or off:

1. Display the OTHER page on the RECORD window.
Press the [Menu] key → RECORD key → OTHER tab.
2. Touch the ON or OFF key in <ALARM RECORDING> box to set alarm recording on or off.



3. Press the [Home] key to return to the home screen.

Setting Alarms

Overview

There are three ways to set alarm limits and on/off settings:

- Set all alarm limits at the same time on one window.
- Set a group of alarm items all together to a preset pattern using an alarm master.
- Set the alarms for individual parameters separately from the ECG, RESP/CO₂, SpO₂, NIBP, PRESS, TEMP, BIS, CO, GAS, O₂, FLOW/Paw and EEG windows. See User's Guide Part II.

Vital signs alarm limits can be set on two different windows: the ALARM LIMITS window and the alarm setting page for the individual parameter. When you change an alarm setting on one window, the same setting on the other window is also automatically changed.

Arrhythmia alarm limits can be set on two different windows: the ARRHYTHM ALARMS window and the ARRHYTHM window of the ECG window. When you change an alarm setting on one window, the same setting on the other window is also automatically changed.

When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the alarm settings return to the default settings 30 minutes after the monitor is turned off. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.

To set NIBP alarm limits for neonate, the cuff for neonates must be connected to the NIBP socket on the monitor.

Alarm Limits Ranges

The following tables show the setting ranges for each alarm. Any upper and lower limit can also be set to off.

Master: When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the setting remains in memory even when the power is turned off. After 30 minutes, the setting returns to the master settings. When <AUTO ADMIT> is set to OFF, you can select whether saving or initializing the master settings.

CAUTION

When the alarm limit is set to OFF, there will be no alarm for that limit. Depending on the setting, the alarm off mark might not be displayed on the screen. Be careful when you set the alarm limit to OFF.

Vital Signs Alarms

If the upper limit is set to a value above the maximum, or the lower limit is set to a value below the minimum, the alarm for that upper/lower limit is automatically set to OFF.

5

Window	Page	Setting Items	Settings Range		Step	Default Setting	Backup
ALARM LIMITS	MAIN ALARMS	HR/PR	Upper	OFF, 16 to 300 beats/min	1	OR, ICU: 140 beats/min NICU: 200 beats/min	Master
			Lower	OFF, 15 to 299 beats/min		OR, ICU: 50 beats/min NICU: 100 beats/min	
		RR	Upper	OFF, 2 to 150 counts/min	2	OFF	
			Lower	OFF, 0 to 148 counts/min			
		APNEA	Upper	OFF, 5 to 40 s	5	20 s	
		CO ₂	Upper	OFF, 2 to 99 mmHg	1	OFF	
				OFF, 1.0 to 13.5 kPa	0.5		
			Lower	OFF, 1 to 98 mmHg	1	OFF	
				OFF, 0.5 to 13.0 kPa	0.5		
		SpO ₂	Upper	OFF, 51 to 100%SpO ₂	1	OR, ICU: OFF NICU: 95%SpO ₂	
			Lower	OFF, 50 to 99%SpO ₂		OR, ICU: 90%SpO ₂ NICU: 85%SpO ₂	
		SpO ₂ -2*	Upper	OFF, 51 to 100%SpO ₂	1	OR, ICU: OFF NICU: 95%SpO ₂	
			Lower	OFF, 50 to 99%SpO ₂		OR, ICU: 90%SpO ₂ NICU: 85%SpO ₂	
		ΔSpO ₂ *	Upper	OFF, 1 to 50%SpO ₂	1	5%SpO ₂	
		BIS	Upper	OFF, 1 to 100	1	OFF	
			Lower	OFF, 0 to 99		40	
		NIBP-SYS	Upper	OFF, 15 to 260 mmHg	5	OR, ICU: 180 mmHg NICU: 100 mmHg	
				OFF, 1.5 to 35.0 kPa	0.5	OR, ICU: 24.0 kPa NICU: 13.5 kPa	
			Lower	OFF, 10 to 255 mmHg	5	OR, ICU: 80 mmHg NICU: 50 mmHg	
				OFF, 1.0 to 34.5 kPa	0.5	OR, ICU: 10.5 kPa NICU: 6.5 kPa	
		NIBP-DIA	Upper	OFF, 15 to 260 mmHg	5	OFF	
				OFF, 1.5 to 35.0 kPa	0.5		
			Lower	OFF, 10 to 255 mmHg	5	OFF	
				OFF, 1.0 to 34.5 kPa	0.5		

* Available only when an AY-661P, AY-663P, AY-671P or AY-673P input unit is used.

5. ALARM FUNCTION

Window	Page	Setting Items	Settings Range		Step	Default Setting	Backup				
ALARM LIMITS	MAIN ALARMS	NIBP-MAP	Upper	OFF, 15 to 260 mmHg	5	OFF	Master				
				OFF, 1.5 to 35.0 kPa	0.5						
			Lower	OFF, 10 to 255 mmHg	5	OFF					
				OFF, 1.0 to 34.5 kPa	0.5						
	ECG ALARMS	HR/PR	Upper	OFF, 16 to 300 beats/min	1	OR, ICU: 140 beats/min NICU: 200 beats/min					
			Lower	OFF, 15 to 299 beats/min		OR, ICU: 50 beats/min NICU: 100 beats/min					
		VPC*	Upper	OFF, 1 to 99 beats/min	1	OFF					
		ST-I to ST-V6	Upper	OFF, −1.99 to 2.00 mV	0.01	OFF					
				OFF, −19.9 to 20.0 mm	0.1						
			Lower	OFF, −2.00 to 1.99 mV	0.01	OFF					
				OFF, −20.0 to 19.9 mm	0.1						
				PRESS1 ALARMS	P1-SYS to P7-SYS			Upper	OFF, 2 to 300 mmHg	2	OFF
									OFF, 0.5 to 40.0 kPa	0.5	
		Lower	OFF, 0 to 298 mmHg			2		OFF			
			OFF, 0.0 to 39.5 kPa			0.5					
		P1-DIA to P7-DIA	Upper		OFF, 2 to 300 mmHg	2		OFF			
	OFF, 0.5 to 40.0 kPa				0.5						
	Lower		OFF, 0 to 298 mmHg		2	OFF					
			OFF, 0.0 to 39.5 kPa		0.5						
	P1-MEAN to P7-MEAN	Upper	OFF, 2 to 300 mmHg		2	OFF					
			OFF, 0.5 to 40.0 kPa		0.5						
		Lower	OFF, 0 to 298 mmHg		2	OFF					
			OFF, 0.0 to 39.5 kPa		0.5						
	PRESS2 ALARMS	ART-SYS, ART2-SYS, RAD-SYS, DORS-SYS, AO-SYS, FEM-SYS	Upper	OFF, 2 to 300 mmHg	2	OFF					
				OFF, 0.5 to 40.0 kPa	0.5						
			Lower	OFF, 0 to 298 mmH	2	OR, ICU: 80 mmHg NICU: 50 mmHg					
				OFF, 0.0 to 39.5 kPa	0.5	OR, ICU: 10.5 kPa NICU: 6.5 kPa					
				ART-DIA, ART2-DIA, RAD-DIA, DORS-DIA, AO-DIA, FEM-DIA	Upper	OFF, 2 to 300 mmHg		2	OFF		
						OFF, 0.5 to 40.0 kPa		0.5			
		Lower	OFF, 0 to 298 mmHg		2	OFF					
			OFF, 0.0 to 39.5 kPa		0.5						

* Only when the ARRHYTHMIA ANALYSIS is set to ON.

Window	Page	Setting Items	Settings Range		Step	Default Setting	Backup	
ALARM LIMITS	PRESS2 ALARMS	ART-MEAN, ART2-MEAN, RAD-MEAN, DORS-MEAN, AO-MEAN, FEM-MEAN	Upper	OFF, 2 to 300 mmHg	2	OFF	Master	
				OFF, 0.5 to 40.0 kPa	0.5			
			Lower	OFF, 0 to 298 mmHg	2	OR, ICU: 60 mmHg NICU: 30 mmHg		
				OFF, 0.0 to 39.5 kPa	0.5	OR, ICU: 8.0 kPa NICU: 4.0 kPa		
		UA-SYS	Upper	OFF, 2 to 300 mmHg	2	OFF		
				OFF, 0.5 to 40.0 kPa	0.5			
			Lower	OFF, 0 to 298 mmHg	2	OFF		
				OFF, 0.0 to 39.5 kPa	0.5			
		UA-DIA	Upper	OFF, 2 to 300 mmHg	2	OFF		
				OFF, 0.5 to 40.0 kPa	0.5			
			Lower	OFF, 0 to 298 mmHg	2	OFF		
				OFF, 0.0 to 39.5 kPa	0.5			
		UA-MEAN, UV-MEAN	Upper	OFF, 2 to 300 mmHg	2	OFF		
				OFF, 0.5 to 40.0 kPa	0.5			
			Lower	OFF, 0 to 298 mmHg	2	OFF		
				OFF, 0.0 to 39.5 kPa	0.5			
	PRESS3 ALARMS	PAP-SYS, RVP-SYS, LVP-SYS	Upper	OFF, 2 to 300 mmHg	2	OFF		
				OFF, 0.5 to 40.0 kPa	0.5			
			Lower	OFF, 0 to 298 mmHg	2	OFF		
				OFF, 0.0 to 39.5 kPa	0.5			
		PAP-DIA, RVP-DIA, LVP-DIA	Upper	OFF, 2 to 300 mmHg	2	OFF		
				OFF, 0.5 to 40.0 kPa	0.5			
			Lower	OFF, 0 to 298 mmHg	2	OFF		
				OFF, 0.0 to 39.5 kPa	0.5			
		PAP-MEAN, CVP-MEAN, RAP-MEAN, RVP-MEAN, LAP-MEAN, LVP-MEAN, ICP-MEAN, ICP2-MEAN to ICP4-MEAN	Upper	OFF, 2 to 300 mmHg	2	OFF		
				OFF, 0.5 to 40.0 kPa	0.5			
			Lower	OFF, 0 to 298 mmHg	2	OFF		
				OFF, 0.0 to 39.5 kPa	0.5			
		TEMP ALARMS	T1 to T4, Tskin, Tskin2, Tskin3, Trect, Tcore, Tnaso, Teso, Ttymp	Upper	OFF, 0.1 to 45.0°C	0.1		OR, ICU: 38.0°C NICU: 39.0°C
					OFF, 33.0 to 113.0°F	1.0		OR, ICU: 100°F NICU: 102°F
				Lower	OFF, 0.0 to 44.9°C	0.1		OFF
					OFF, 32.0 to 112.0°F	1.0		

5. ALARM FUNCTION

Window	Page	Setting Items	Settings Range		Step	Default Setting	Backup
ALARM LIMITS	TEMP ALARMS	Tblad, Taxil	Upper	OFF, 0.1 to 45.0°C	0.1	OR, ICU: 38.0°C NICU: 39.0°C	Master
				OFF, 33.0 to 113.0°F	1.0	OR, ICU: 100°F NICU: 102°F	
			Lower	OFF, 0.0 to 44.9°C	0.1	OFF	
				OFF, 32.0 to 112.0°F	1.0	OFF	
		Tb	Upper	OFF, 15.1 to 45.0°C	0.1	OR, ICU: 38.0°C NICU: 39.0°C	
				OFF, 51.0 to 113.0°F	1.0	OR, ICU: 100°F NICU: 102°F	
			Lower	OFF, 15.0 to 44.9°C	0.1	OFF	
				OFF, 50.0 to 112.0°F	1.0	OFF	
		ΔT, ΔT2	Upper	OFF, 0.1 to 45.0°C	0.1	OFF	
				OFF, 1.0 to 113.0°F	1.0	OFF	
	GAS ALARMS	RR	Upper	OFF, 2 to 150 counts/min	2	OFF	
			Lower	OFF, 0 to 148 counts/min		OFF	
		APNEA	Upper	OFF, 5 to 40 s	5	20 s	
		CO ₂ (E)	Upper	OFF, 2 to 99 mmHg	1	OFF	
				OFF, 1.0 to 13.5 kPa	0.5	OFF	
			Lower	OFF, 1 to 98 mmHg	1	OFF	
				OFF, 0.5 to 13.0 kPa	0.5	OFF	
		CO ₂ (I)	Upper	OFF, 1 to 5 mmHg	1	OR: 3 mmHg ICU, NICU: OFF	
				OFF, 0.1 to 0.7 kPa	0.1	OR: 0.4 kPa ICU, NICU: OFF	
		O ₂ (E)	Upper	OFF, 11 to 100%	1	OFF	
			Lower	OFF, 10 to 99%		OFF	
		O ₂ (I)	Upper	OFF, 19 to 100%	1	OFF	
			Lower	18 to 99%		18%	
		N ₂ O(E)	Upper	OFF, 1 to 100%	1	OFF	
			Lower	OFF, 0 to 99%		OFF	
		N ₂ O(I)	Upper	OFF, 1 to 100%	1	80%	
			Lower	OFF, 0 to 99%		OFF	
		HAL(E)	Upper	OFF, 0.1 to 7.0%	0.1	OFF	
			Lower	OFF, 0.0 to 6.9%		OFF	
		HAL(I)	Upper	OFF, 0.1 to 7.0%	0.1	4.0%	
			Lower	OFF, 0.0 to 6.9%		OFF	
		ISO(E)	Upper	OFF, 0.1 to 7.0%	0.1	OFF	
			Lower	OFF, 0.0 to 6.9%		OFF	
		ISO(I)	Upper	OFF, 0.1 to 7.0%	0.1	5.0%	
			Lower	OFF, 0.0 to 6.9%		OFF	
		ENF(E)	Upper	OFF, 0.1 to 7.0%	0.1	OFF	
			Lower	OFF, 0.0 to 6.9%		OFF	
		ENF(I)	Upper	OFF, 0.1 to 7.0%	0.1	5.0%	
			Lower	OFF, 0.0 to 6.9%		OFF	
		SEV(E)	Upper	OFF, 0.1 to 7.0%	0.1	OFF	
			Lower	OFF, 0.0 to 6.9%		OFF	
		SEV(I)	Upper	OFF, 0.1 to 7.0%	0.1	6.0%	
			Lower	OFF, 0.0 to 6.9%		OFF	

Window	Page	Setting Items	Settings Range		Step	Default Setting	Backup
ALARM LIMITS	GAS ALARMS	DES(E)	Upper	OFF, 0.1 to 20.0%	0.1	OFF	Master
			Lower	OFF, 0.0 to 19.9%		OFF	
		DES(I)	Upper	OFF, 0.1 to 20.0%	0.1	12.0%	
			Lower	OFF, 0.0 to 19.9%		OFF	
	OTHER ALARMS	MV*	Upper	OFF, 0.1 to 30.0 L/min	0.1	OR, ICU: 10.0 NICU: OFF	
			Lower	OFF, 0.0 to 29.9 L/min	0.1	OR, ICU: 2.0 NICU: OFF	
		Ppeak*	Upper	OFF, 1 to 100 cmH ₂ O	1	OR, ICU: 40 NICU: OFF	
			Lower	OFF, 0 to 99 cmH ₂ O		OR, ICU: OFF NICU: OFF	
		PEEP*	Upper	1 to 50, OFF cmH ₂ O	1	OR, ICU: 10 NICU: OFF	
			Lower	OFF, 0 to 49 cmH ₂ O		OR, ICU: OFF NICU: OFF	
		SEF*	Upper	OFF, 1.0 to 60.0 Hz	0.5	OFF	
			Lower	OFF, 0.5 to 59.5 Hz		OFF	
		TP*	Upper	OFF, 0.02 to 9.99 nW	0.01	OFF	
			Lower	OFF, 0.01 to 9.98 nW		OFF	

* These parameters are not available for BSM-6000A series.

5. ALARM FUNCTION

Arrhythmia Alarms

Window	Page	Setting Items	Settings Range	Step	Default Setting	Backup
ARRHYTHM ALARMS	ARRHYTH	ASYSTOLE	ON fixed 3 to 10 s	1	OR, ICU: 5 s NICU: 3 s	Master
		VF	ON fixed	—	ON	
		VT	ON fixed	—	ON	
			ON, OFF	—	OFF	
		EXT TACHY*	upper heart rate alarm limit to 300	1	OR, ICU: 160 bpm NICU: 220 bpm	
		EXT BRADY*	ON, OFF	—	OFF	
			15 to lower heart rate alarm limit	1	OR, ICU: 40 bpm NICU: 80 bpm	
		VPC RUN	ON, OFF	—	OR, NICU: OFF ICU: ON	
			16 to 300 bpm	1	OR, ICU: 100 bpm NICU: 140 bpm	
			3 to 8 beats	1	3 beats	
		V BRADY*	ON, OFF	—	OR, NICU: OFF ICU: ON	
			15 to 299 bpm	1	OR, ICU: 50 bpm NICU: 60 bpm	
		SV TACHY*	ON, OFF	—	OFF	
			16 to 300 bpm	1	OR, ICU: 170 bpm NICU: 210 bpm	
			3 to 9 beats	1	6 beats	
		PAUSE*	ON, OFF	—	ON	
			1.0 to 3.0 s	0.1	OR, ICU: 3.0 s NICU: 1.5 s	
		COUPLET	ON, OFF	—	OFF	
		EARLY VPC	ON, OFF	—	OFF	
		MULTIFORM*	ON, OFF	—	OFF	
		V RHYTHM*	ON, OFF	—	OR, NICU: OFF ICU: ON	
		BIGEMINY	ON, OFF	—	OFF	
		TRGEMINY*	ON, OFF	—	OFF	
		IRREGULAR RR*	ON, OFF	—	OFF	
		PROLONGED RR*	ON, OFF	—	OFF	
		NO PACER PULSE*	ON, OFF	—	OFF	
		PACER NON- CAPTURE*	ON, OFF	—	OFF	
			40 to 480 ms	4	400 ms	


* Available only when ARRHYTHMIA TYPE on the ECG page of the SYSTEM SETUP window is set to “EXTENDED” on BSM-6000K series. The arrhythmia type setting is not available on the BSM-6000A series. For BSM-6000A series, arrhythmia type is STANDARD only.

Setting Vital Signs Alarms Individually

CAUTION

When the alarm limit is set to OFF, there will be no alarm for that limit. Depending on the setting, the alarm off mark might not be displayed on the screen. Be careful when you set the alarm limit to OFF.

1. Display the ALARM LIMITS window.
Press the [Menu] key → ALARM LIMITS key.



2. Touch the parameter key for the limit you want to change. To change the displaying parameters, use the tabs to change the parameters.
3. Touch and drag the sliders to the desired level on the setting bar. Use the ▲ or ▼ to adjust the setting.

If the upper limit is set to a value above the maximum or the lower limit is set to a value below the minimum, the alarm is set to OFF.

4. Repeat steps 2 and 3 to change alarm settings for other parameters.
5. Press the [Home] key to return to the home screen.

Setting All Vital Signs Alarms to a Preset Pattern (Alarm Master)


For fast and easy alarm setup, a group of alarm items can be set all together to one group of preset settings. This is called an alarm master. This is useful, for example, if there are typical alarm settings at your hospital, or you have certain alarm settings for certain patients.

You can also change individual alarm settings, as described in previous pages, after setting all alarms with an alarm master.

The alarm masters are set by the administrator on the MASTER window of the SYSTEM SETUP window.

1. Display the ALARM MASTER page.

Press the [Menu] key → ALARM LIMITS key → ALARM MASTER tab.
The “APPLY SETTING FROM MASTER?” message appears.



2. Touch the YES key to change all settings to the value set on the ALARM MASTER of the SYSTEM SETUP window.

Touch the NO key to cancel changing the alarm settings to the alarm master setting.

3. Press the [Home] key to return to the home screen.

Setting Arrhythmia Alarms Individually

For BSM-6000A series, the arrhythmia type cannot be selected. There is only one pattern of arrhythmia analysis, STANDARD.

For BSM-6000K series, there are 2 patterns of arrhythmia analysis, EXTENDED or STANDARD. Select the arrhythmia type in the SYSTEM SETUP window. Refer to Administrator's guide, Section 3.

For details about arrhythmia monitoring, refer to "Monitoring Arrhythmia" in User's Guide Part II, Section 1.

WARNING

For arrhythmia monitoring, set <ARRHYTHMIA ANALYSIS> on the ECG window to ON. Otherwise, there is no sound or indication for arrhythmia alarms (except for ASYSTOLE).

CAUTION

When the alarm is turned OFF for an arrhythmia, there will be no alarm for that arrhythmia type. There is no message or mark to indicate that a certain arrhythmia alarm is turned off. Therefore, be careful when you turn off an arrhythmia alarm.

NOTE

When "EXTENDED" is selected for arrhythmia type and the bedside monitor is connected to a central monitor network that has old software so that "EXTENDED" arrhythmias cannot be monitored, the "COMMUNICATION LOSS" message appears for the bedside monitor and the bedside monitor cannot be monitored on the central monitor.

1. Display the ARRHYTH page.

Press the [Menu] key → ARRHYTH ALARMS key → ARRHYTH tab.

These arrhythmias are fixed to ON



Threshold settings

2. Touch the ON or OFF key for each arrhythmia type to set it on or off.


5. ALARM FUNCTION

- For “ASYSTOLE”, “VPC RUN” and “FREQ VPC”, set the detecting condition with the ▲ or ▼ key.

NOTE

- For BSM-6000A series, items can be turned on/off but thresholds are fixed and cannot be changed. The thresholds are set by the administrator on the MASTER window of the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3.
- The arrhythmia type setting is not available on the BSM-6000A series. For BSM-6000A series, arrhythmia type is STANDARD only.

When EXTENDED is selected for the arrhythmia type in the SYSTEM SETUP window, touch the threshold to display the ARRHYTH window and adjust the setting.



- Press the [Home] key to return to the home screen.

Setting All Arrhythmia Alarms to a Preset Pattern (Alarm Master)

For fast and easy alarm setup, a group of alarm items can be set all together to one group of preset settings. This is called an alarm master. This is useful, for example, if there are typical alarm settings at your hospital, or you have certain alarm settings for certain patients.

You can also change individual alarm settings, as described in previous pages, after setting all alarms with an alarm master.

The alarm masters are set by the administrator on the MASTER window of the SYSTEM SETUP window.

WARNING

For arrhythmia monitoring, set <ARRHYTHMIA ANALYSIS> on the ECG window to ON. Otherwise, there is no sound or indication for arrhythmia alarms (except for ASYSTOLE).


CAUTION

When the alarm is turned OFF for an arrhythmia, there will be no alarm for that arrhythmia type. There is no message or mark to indicate that a certain arrhythmia alarm is turned off. Therefore, be careful when you turn off an arrhythmia alarm.

1. Display the ALARM MASTER page.
Press the [Menu] key → ARRHYTH ALARMS key → ALARM MASTER tab.

5

The “APPLY SETTING FROM MASTER?” message appears.



2. Touch the YES key to change all settings to the values on the ALARM MASTER of the SYSTEM SETUP window.

Touch the NO key to not change the alarm settings to the alarm master settings.

3. Press the [Home] key to return to the home screen.

Section 6 Review Windows

General.....	6.3
Transport	6.4
Review Recording	6.5
Event Bar	6.6
Selecting the Event Display Position on the Event Bar	6.6
Changing the Event Bar Time Interval.....	6.7
Scrolling the Event Bar	6.7
Trend Window	6.8
GRAPH 1, GRAPH 2, GRAPH 3 Page.....	6.8
Displaying the GRAPH 1, GRAPH 2 or GRAPH 3 Page.....	6.10
Selecting Parameters for the Trendgraph Display	6.11
Changing the Trendgraph Scale.....	6.12
Changing the Trendgraph Display Format.....	6.13
Recording the Trendgraph.....	6.14
Printing the Trendgraph.....	6.15
TABLE 1, TABLE 2, TABLE 3 Page.....	6.17
Displaying the TABLE 1, TABLE 2 or TABLE 3 Page.....	6.18
Scrolling the Trend Table	6.19
Selecting Parameters for the Trend Table Display	6.19
Selecting the Measurement Interval.....	6.20
Recording a Trend Table.....	6.21
Printing a Trend Table.....	6.21
NIBP TREND Page	6.23
Displaying the NIBP TREND Page.....	6.24
Scrolling the NIBP Trend Table.....	6.25
Selecting Parameters for the NIBP Trend Display	6.25
Recording a NIBP Trend Table	6.26
Printing a NIBP Trend Table	6.27
HEMO Page	6.29
Displaying the HEMO Page.....	6.29
Scrolling the Hemodynamics Table	6.30
Explanation of the Hemodynamics Table	6.31
Recording a Hemodynamics Table.....	6.32
Printing a Hemodynamics Table.....	6.33
LUNG TREND Page.....	6.34
Displaying the LUNG TREND Page	6.34
Explanation of the Lung Trend Table	6.35
Recording the Lung Trend Table.....	6.36
Printing a Lung Trend Table.....	6.37
Arrhythmia Recall Window.....	6.38
General.....	6.38
Arrhythmia List	6.38
Displaying the Arrhythmia Recall Window	6.40

Selecting the Arrhythmia Types to be Saved as a Recall File	6.41
Scrolling the Arrhythmia Recall Files	6.41
Displaying the Actual Size Waveform of the Selected Arrhythmia Recall File	6.42
Arrhythmia Waveform Annotation	6.42
Recording or Printing the Arrhythmia Recall Waveform	6.42
Recording on the ARRHYTH HISTORY Window	6.42
Printing on the ARRHYTH HISTORY Window	6.44
Recording on the Actual Size ECG Waveform Window	6.45
Printing on the Actual Size ECG Waveform Window	6.46
Alarm History Window	6.47
Displaying the ALARM HISTORY Window	6.47
Scrolling the Alarm History Files	6.48
Recording the Alarm History File	6.48
Full Disclosure Window	6.50
Displaying the FULL DISC Window	6.50
Scrolling the Full Disclosure Waveform	6.52
Selecting the Parameters to be Saved for Full Disclosure	6.53
Recording or Printing the Full Disclosure Waveform	6.54
Recording the Full Disclosure Waveform	6.54
Printing the Full Disclosure Waveform	6.55
Recording or Printing the Enlarged ECG Waveform	6.57
Recording the Enlarged ECG Waveform	6.57
Printing the Enlarged ECG Waveform	6.58
ST Level Recall Window	6.60
Displaying the ST Window	6.61
Scrolling the ST Level Recall File	6.62
Displaying the ST Point	6.62
Displaying the ST Recall Waveform on the Home Screen	6.63
Saving as Reference ST Recall File	6.64
Displaying the Reference ST Recall Waveform on the Home Screen	6.65
Printing the ST Level Recall File	6.66
OCRG Window	6.68
Displaying the OCRG Window	6.68
Selecting the OCRG Trendgraph Type	6.69
Changing the Trendgraph Scale for Heart Rate and SpO ₂	6.70
Recording or Printing the OCRG Trend	6.71
Recording the OCRG Trend	6.71
Printing the OCRG Trend	6.72

General

You can review saved data on the following review windows. You can expand the memory of the monitor from 128 MB to 1 GB with the optional QM-601P memory card.

The parentheses show the capacity when the QM-601P memory card is installed in the monitor.

- **TREND window**
 - GRAPH page:** Displays the trendgraph of the past 24 hours (72 hours).
 - TABLE page:** Displays the vital sign data of the past 24 hours (72 hours).
 - NIBP TREND page:** Displays vital sign data at the NIBP measurement. Up to 512 files (1,024 files) can be saved.
 - HEMO page:** Displays the hemodynamic data when CO is measured. Up to 512 files (1,024 files) can be saved.
 - LUNG TREND page:** Displays data acquired at the lung function measurement. Up to 128 files (128 files) can be saved.
- **RECALL window:** Displays arrhythmia waveforms of 4 seconds before and 4 seconds after the arrhythmia detection. Up to 8,192 files (16,384 files) can be saved.
- **ALARM HISTORY window:** Displays the table of vital sign alarms and arrhythmia alarms. Up to 8,192 files (16,384 files) can be saved.
- **FULL DISC window:** Displays and up to 24 hours (72 hours) of compressed and expanded waveforms of up to 5 parameters.
- **ST window:** Displays the ST level waveforms of the past 24 hours (72 hours). All monitoring ECG can be saved.
- **12 LEAD window:** Displays the 12 lead analysis result data of up to 6 files (18 files). Refer to the Section 7 “12 LEAD/12 LEAD ANALYSIS Windows”.
- **OCRG window:** Displays the OCRG trendgraph of the past 24 hours (72 hours).

NOTE

- When changing the review window, the data at the cursor on the original window is displayed on the second window. For example, when the FULL DISC window is called up from the ALARM HISTORY window, the full disclosure is displayed with the time of the file selected on the ALARM HISTORY window.

6. REVIEW WINDOWS

- When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.
- Do not disconnect the power cord while the monitor power is on. Data may be lost.
- PCCO, ScvO₂, SVV, EDV, EDVI, ESV, ESVI, EF, PPV and SPV data on the GRAPH 1 to GRAPH 3 pages and TABLE 1 to TABLE 3 pages of the TREND window cannot be saved in the input unit and cannot be sent.
- EEG (monitored with the AE-918P neuro unit), SEF, MDF, PPF and TP data cannot be saved in the input unit and cannot be sent.
- The oldest file is deleted when the maximum number of files are saved.
- When transporting data between BSM-9101 and BSM-6000 series bedside monitors, the arrhythmia recall waveforms cannot be displayed on the destination monitor unless ECG is saved for full disclosure on the original monitor.
- To display data on the full disclosure window, select the same parameters for the waveforms to be saved on both the original monitor and the destination monitor.

Transport

The following review data are saved in the QM-600P memory unit and can be sent to the CNS-9701 central monitor. Review data of the past 24 hours can be saved and sent. For details of transport, refer to Section 1 “Transport Function”.

NOTE

If the QM-601P memory card is installed in the monitor, the data which can be sent to central monitor is up to 24 hours.

Review Window		Data Saved in Memory Unit	Data Transport to CNS
TREND - GRAPH		Available	Available
TREND - TABLE		Available	Available
TREND - NIBP TREND		Available	Available
TREND - HEMO		Available	Available
TREND - LUNG TREND		Available	Not available
RECALL		Available	Available
ALARM HISTORY		Available	Not available
FULL DISC	Compressed waveform	Available*	Available*
	Actual waveform	Available*	Available*
ST		Available	Available
OCRG		Not available	Not available
12 LEAD - 12 LEAD		Available	Available
12 LEAD - ANALYSIS WAVE		Available	Available
12 LEAD - REPORT		Available	Available
12 LEAD - AVERAGE WAVE		Available	Available

* First trace of ECG and the four other waveforms selected on the FULL DISC window.

Review Recording

Available review recordings are listed below. For details of recording, refer to the Section 10 “Recording”.


Review Window		Recording		Printing	
		Record Page	Record All	Print Page	Print All
TREND - GRAPH		Available	Not available	Available	Not available
TREND - TABLE		Available	Available	Available	Available
TREND - NIBP TREND		Available	Available	Available	Available
TREND - HEMO		Available	Available	Available	Available
TREND - LUNG TREND		Available	Available	Available	Available
RECALL		Available	Not available	Available	Not available
ALARM HISTORY		Available	Available	Not available	Not available
FULL DISC	Compressed waveform	Available	Not available	Available	Not available
	Actual waveform	Available	Not available	Available	Not available
ST		Not available	Not available	Available	Not available
OCRG		Available	Not available	Available	Not available
12 LEAD - 12 LEAD		Available	Not available	Not available	Not available
12 LEAD - ANALYSIS WAVE		Available	Not available	Available	Not available
12 LEAD - REPORT		Available	Not available	Available	Not available
12 LEAD - AVERAGE WAVE		Not available	Not available	Available	Not available

Event Bar

The event bar is displayed at the lower part of the review window. The event bar shows the event occurrence during monitoring.

Up to four events from ARRHYTHMIA (arrhythmia alarms), TECHNICAL (technical alarms), LIMIT (vital sign alarms) and OPERATION (when SILENCE ALARM, SUSPEND ALARMS, ALL ALARMS OFF, BYPASS, SUSPEND MONITORING starts) can be displayed.


The event display position can be changed by touching the event name area on the event bar.




Selecting the Event Display Position on the Event Bar

You can select the event display position on the event bar by touching the event name display area.

1. Touch the event name display area. The EVENT BAR SETUP window appears.






2. Select the position where you want to assign the event from the box and select the event key. Use the NONE key to not assign any event.
3. Repeat step 2 to select other items.
4. Touch the key to close the window.

6


Changing the Event Bar Time Interval

You can change the time interval by touching the or key under the event bar. The same time interval is used for all the review windows.



Scrolling the Event Bar

The event bar can be scrolled by touching the , , , or key under the event bar.



- : Scroll the event bar to the previous event.
- : Scroll the event bar to the left.
- : Scroll the event bar to the right.
- : Scroll the event bar to the next event.

Trend Window

The TREND window has nine pages: GRAPH 1, GRAPH 2 and GRAPH 3, TABLE 1, TABLE 2 and TABLE 3, NIBP TREND, HEMO and LUNG TREND pages.

GRAPH 1, GRAPH 2, GRAPH 3 Page

The GRAPH 1, GRAPH 2 and GRAPH 3 pages displays monitoring parameter data of up to 6 selected parameters of the past 24 hours as a graph. With the optional QM-601P memory card, data of past 72 hours can be saved.

The trendgraph can be recorded on the optional recorder or printed on the network printer.

The maximum, mean and minimum values of all monitoring parameters are automatically acquired every 1 minute for the trendgraph. The acquired values are 1 minute averaged data. The frequency of data display depends on the selected trend time.

1 or 2 hours:	1 minute
4 hours:	2 minutes
8, 24 hours:	4 minutes

The following table shows the available trend parameters, screen displays and scales.

Parameter	Description	Vertical Scale Range
HR	Heart rate (beats/min)	0-300
PR	Pulse rate (beats/min)	0-300
VPC	VPC rate (VPCs/min)	0-100
RR	Respiration rate (breaths/min)	0-150
ST	ST level (mV, mm)	-2.0-2.0 (mV) -20.0-20.0 (mm)
APNEA T	Apnea time (Total time in one data segment, in seconds)	0-180
APNEA F	Apnea frequency (Total number of apnea occurrences in one data segment)	0-12
NIBP	NIBP (mmHg, kPa)	0-300 (mmHg) 0-40.0 (kPa)
CO ₂ (E)	CO ₂ partial pressure (mmHg, kPa)	0-120 (mmHg)
CO ₂ (I)		0-16.0 (kPa)
O ₂ (E), O ₂ (I)	Oxygen concentration (%)	0-100
SpO ₂ , SpO ₂ -2* ¹	Saturated oxygen from pulse oximeter (%SpO ₂)	0-100
Tb (CO)	Blood temperature (°C, °F)	0-45.0 (°C) 0-115.0 (°F)
PRESS* ²	IBP (mmHg, kPa)	0-300 (mmHg) 0-40.0 (kPa)

Parameter	Description	Vertical Scale Range
TEMP* ²	Temperature (°C, °F)	0-45.0 (°C) 0-115.0 (°F)
N ₂ O(E), N ₂ O(I)	Nitrogen oxide concentration from gas monitoring (%)	0-100
AGENT* ² (E), AGENT* ² (I)	Agent concentration from gas monitoring (%)	0.0-20.0
BIS	Bispectral Index	0-100
SQI	Signal quality indicator (%)	0.0-100.0
SR	Suppression ratio (s)	0.0-100.0
EMG	Electromyogram (dB)	0.00-80.0
PWTT	Pulse wave transit time (s)	0-500
CCO	Continuous cardiac output (L/min)	0.00-20.00
CCI	Continuous cardiac output index (L/min/m ²)	0.00-20.0
SvO ₂	Mixed venous oxygen saturation (%)	0-100
ScvO ₂	Central venous oxygen saturation (%)	0-100
EDV	End diastolic volume (ml)	0-800
SVRI	Systemic vascular resistance index (dyn•s•m ² /cm ⁵ , kPa•s•m ² /L)	0-30000 (dyn•s•m ² /cm ⁵) 0-3000.0 (kPa•s•m ² /L)
SVV	Stroke volume variation (%)	0-50
PCCO	Pulse contour cardiac output (L/min)	0.00-20.00
PCCI	Pulse contour cardiac output index (L/min/m ²)	0.00-20.00
TOFrat	TOF ratio (%)	0-200
TOFcnt	TOF counts (Times)	0-4
PTC	Post tetanic counts (Times)	0-15
MV* ³	Minute volume (L/min)	0-30
TVe* ³	Expiratory tidal volume (mL)	0-2000
C* ³	Compliance (mL/cmH ₂ O, hPa)	0-200
R* ³	Airway resistance (cmH ₂ O, hPa/L/s)	0-100
Re* ³	Expiratory airway resistance (cmH ₂ O, hPa/L/s)	0-100
Ri* ³	Inspiratory airway resistance (cmH ₂ O, hPa/L/s)	0-100
Ppeak* ³	Peak airway pressure (cmH ₂ O, hPa)	0-150
Pmean* ³	Mean airway pressure (cmH ₂ O, hPa)	0-150
PEEP* ³	Positive end expiratory pressure (cmH ₂ O, hPa)	0-150

*¹ Available only when AY-661P, AY-663P, AY-671P or AY-673P input unit is used.

*² The label appears.


*³ These parameters are not available for BSM-6000A series.

NOTE

- When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.
- Do not disconnect the power cord while the monitor power is on. Data may be lost.
- PCCO, ScvO₂, SVV, EDV, EDVI, ESV, ESVI, EF, PPV and SPV data on the GRAPH 1 to GRAPH 3 pages of the TREND window cannot be saved in the input unit and cannot be sent.

Displaying the GRAPH 1, GRAPH 2 or GRAPH 3 Page


1. Press the [Menu] key to display the MENU window.



2. Touch the TREND key. The TREND window appears.

When TREND GRAPH is assigned to one of the function keys at the upper left of the screen or one of the function keys on the remote control keys, the trendgraph window can be displayed by touching the TREND GRAPH function key. Refer to “KEYS Window” in Administrator’s Guide, Section 3 to assign a function to the function key.

3. Touch the GRAPH 1, GRAPH 2 or GRAPH 3 tab. The graph page appears.



You can select up to 6 parameters for displaying the trendgraphs on GRAPH 1, GRAPH 2 and GRAPH 3 page on the SETTINGS window, the scale on the

SCALE window and the display format by touching the MAX-MIN or MEAN key on under the event bar.

For details on the event bar, refer to the previous “EVENT BAR” section.

To return to the home screen, press the [Home] key.


Selecting Parameters for the Trendgraph Display

You can change the parameters of the trendgraph.

1. Touch the SETTING key on the GRAPH 1, GRAPH 2 or GRAPH 3 page. The SETTINGS window appears.



2. Select the display position of the trendgraph. The parameter selected for the “LEFT” is displayed on the left side of the page.



3. Select the parameter by touching the desired parameter key. Use the  or  key to display other parameters. Use the NONE key to unselect the parameter.

6. REVIEW WINDOWS

You can change the time threshold for the apnea trendgraph by touching the desired time in <APNEA TREND TIME> box.

4. Touch the  key to close the window.

Changing the Trendgraph Scale

You can change the trendgraph scale for each parameter.



1. Touch the SCALE key on the GRAPH 1, GRAPH 2 or GRAPH 3 page. The SCALE SETUP window appears.



2. Select the display position of the trendgraph. The scale selected for the “LEFT” is displayed on the left side of the page.
3. Touch and drag the sliders to the desired level on the setting bar.
4. Touch the  key to close the window.

Changing the Trendgraph Display Format

You can change the display format of the trendgraph by touching the MAX-MIN or MEAN key under the event bar. The same format is used for the GRAPH 1, GRAPH 2, GRAPH 3 page and the trendgraph on the home screen. The MAX-MIN key displays maximum and minimum values on the trendgraph. The MEAN key displays mean value on the trendgraph.

MAX-MIN



MEAN




Recording the Trendgraph

The trendgraph displayed on the GRAPH 1, GRAPH 2 or GRAPH 3 page can be recorded on the optional recorder.

1. Display the trendgraph you want to record on the GRAPH 1, GRAPH 2 or GRAPH 3 page.



2. Touch the PRINT key. The PRINT window appears.




3. Touch the RECORD PAGE key in <RECORDER> box. Recording starts.

To stop recording, press the  [Record] key.

4. Touch the  key to close the window.

Recording example




Printing the Trendgraph

The trendgraphs displayed on the GRAPH 1, GRAPH 2 or GRAPH 3 page can be printed when the monitor is connected to a network printer.

1. Display the trendgraph you want to print on the GRAPH 1, GRAPH 2 or GRAPH 3 page.



2. Touch the PRINT key. The PRINT window appears.



3. Touch the PRINT PAGE key in <PRINTER> box. Printing starts.
4. Touch the key to close the window.

Printing example




TABLE 1, TABLE 2, TABLE 3 Page

The TABLE 1, TABLE 2 and TABLE 3 pages displays monitoring parameter data of up to 15 selected parameters of the past 24 hours as a table and you can change the display interval. One page shows 7 measurements. Each measurement appears in a separate column. With the optional QM-601P memory card, data of past 72 hours can be saved.

The trend table of selected time period can be recorded on the optional recorder or printed on the network printer.

The following table shows the available trend parameter and screen display.

Parameter	Description
HR	Heart rate (beats/min)
PR	Pulse rate (beats/min)
VPC	VPC rate (VPCs/min)
RR	Respiration rate (breaths/min)
ST	ST level (mV, mm)
CO ₂ (E)	CO ₂ partial pressure (mmHg, kPa)
CO ₂ (I)	
O ₂ (E), O ₂ (I)	Oxygen concentration (%)
SpO ₂ , SpO ₂ -2* ¹	Saturated oxygen from pulse oximeter (%SpO ₂)
Tb (CO)	Blood temperature (°C, °F)
PRESS* ²	IBP (mmHg, kPa)
TEMP* ²	Temperature (°C, °F)
AGENT* ² (E), AGENT* ² (I)	Agent concentration from gas monitoring (%)
BIS	Bispectral index
SQI	Signal quality indicator (%)
SR	Suppression ratio (s)
EMG	Electromyogram (dB)
CCO	Continuous cardiac output (L/min)
CCI	Continuous cardiac output index (L/min/m ²)
SvO ₂	Mixed venous oxygen saturation (%)
ScvO ₂	Central venous oxygen saturation (%)
EDV	End diastolic volume (mL)
EDVI	End diastolic volume index (mL/m ²)
ESV	End systolic volume (mL)
ESVI	End systolic volume index (mL/m ²)
EF	Ejection fraction (%)
TOFrat	TOF ratio (%)
TOFcnt	TOF counts (times)

Parameter	Description
PTC	Post tetanic counts (times)
PCCO	Pulse contour cardiac output (L/min)
PCCI	Pulse contour cardiac output index (L/min/m ²)
SVR	Systemic vascular resistance (dyn•s/cm ⁵)
SVRI	Systemic vascular resistance index (dyn•s•m ² /cm ⁵ , kPa•s•m ² /L)
SVV	Stroke volume variation (%)
GEDV	Global end diastolic volume (mL)
GEDVI	Global end diastolic volume index (mL/m ²)
ITBV	Intrathoracic blood volume (mL)
ITBVI	Intrathoracic blood volume index (mL/m ²)
GEF	Global ejection fraction (%)
EVLW	Extravascular lung water (mL)
EVLWI	Extravascular lung water index (mL/kg)
MV* ³	Minute volume (L/min)
TVe* ³	Expiratory tidal volume (mL)
C* ³	Compliance (mL/cmH ₂ O, hPa)
R* ³	Airway resistance (cmH ₂ O, hPa/L/s)
Re* ³	Expiratory airway resistance (cmH ₂ O, hPa/L/s)
Ri* ³	Inspiratory airway resistance (cmH ₂ O, hPa/L/s)
Ppeak* ³	Peak airway pressure (cmH ₂ O, hPa)
Pmean* ³	Mean airway pressure (cmH ₂ O, hPa)
PEEP* ³	Positive end expiratory pressure (cmH ₂ O, hPa)

*¹ Available only when AY-661P, AY-663P, AY-671P or AY-673P input unit is used.

*² The label appears.


*³ These parameters are not available for BSM-6000A series.

NOTE

- When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.
- Do not disconnect the power cord while the monitor power is on. Data may be lost.
- PCCO, ScvO₂, SVV, EDV, EDVI, ESV, ESVI, EF, PPV and SPV data on the TABLE 1 to TABLE 3 pages of the TREND window cannot be saved in the input unit and cannot be sent.

Displaying the TABLE 1, TABLE 2 or TABLE 3 Page


1. Press the [Menu] key to display the MENU window.



2. Touch the TREND key. The TREND window appears.

When TREND DATA is assigned to one of the function keys at the upper left of the screen or one of the function keys on the remote control keys, the trend table window can be displayed by touching the TREND TABLE function key. Refer to “KEYS Window” in Administrator’s Guide, Section 3 to assign a function to the function key.

3. Touch the TABLE 1, TABLE 2 or TABLE 3 tab. The table page appears.



For details on the event bar, refer to the “EVENT BAR” section.

To return to the home screen, press the [Home] key.


Scrolling the Trend Table

Use the vertical scroll bar on the window to scroll the trend table.

The trend table can be scrolled by touching the ▲ or ▼ key on the scroll bar.

Selecting Parameters for the Trend Table Display


1. Touch the SETTING key on the TABLE 1, TABLE 2 or TABLE 3 page. The PARAMETER SETUP window appears.



2. Select the display position from the left column. Select the parameter from the right column. The selected parameter appears in the display order on the left column.

6. REVIEW WINDOWS


Selected parameters in the display order.
Up to 15 parameters can be selected




- 3. Repeat step 2 to select other parameters.
- 4. Touch the  key to close the window.

Selecting the Measurement Interval

- 1. Touch the INTERVAL key on the TABLE 1, TABLE 2 or TABLE 3 page.
The INTERVAL SETUP window appears.



- 2. Select the measurement interval for the trend table on the INTERVAL SETUP window.




- 3. Touch the  key to close the window.

Recording a Trend Table

You can record the trend table of the selected time period with the optional recorder.

1. Touch the PRINT key. The PRINT window appears.



2. Set the RECORD START TIME and RECORD END TIME with the ◀ or ▶ key or time slider.

3. Check the number of pages and touch the RECORD key in <RECORDER> box.

To stop recording, press the [⏏] [Record] key.

4. Touch the [X] key to close the window.

Recording example

BED-001 JOHN SMITH		2008-03-04 09:30						
	03-03-2008	17:27	17:28	17:29	17:30	17:31	17:32	17:33
HR	(bpm)	80	80	80	80	80	80	80
PR	(min)	80	80	80	80	80	80	80
RR	(min)	12	12	12	12	12	12	12
SpO2	(%)	98	98	98	98	98	98	98
ART-SYS	(mmHg)	---	---	---	---	---	---	118
ART-DIA	(mmHg)	---	---	---	---	---	---	76
ART-MEAN	(mmHg)	---	---	---	---	---	---	81
CVP-MEAN	(mmHg)	---	---	---	---	---	---	8
TEMP	(°C)							
TEMP2	(°C)							
CO2-E	(mmHg)	38	38	38	38	38	38	38
O2-I	(%)							
SEV-E	(%)							
SEV-I	(%)							

TREND DATA


NIHON KODEN

Printing a Trend Table

You can print the trend table of the selected time period with a network printer.

1. Touch the PRINT key. The PRINT window appears.

6. REVIEW WINDOWS



- 2. Set the RECORD START TIME and RECORD END TIME with the ◀ or ▶ key or time slider.
- 3. Check the number of pages and touch the RECORD key in <PRINTER> box. The “PRINTING” message appears on the screen and the table is printed.
- 4. Touch the ☒ key to close the window.

Printing example

4-9-2010 16:33											
Bed ID	BSM-TR	Name		JOHN SMITH		Gender		Not Specified			
Patient ID	123456789					Blood Type		Not Specified			
Date of Birth	7-1-1970	Age		39	Height	170.0cm	Weight	60.0kg			
4-9-2010		16:20	16:21	16:22	16:23	16:24	16:25	16:26			
HR	(bpm)	80	80	80	80	80	80	80			
PR	(bpm)	80	80	80	80	80	80	80			
RR	(bpm)	12	12	12	12	12	12	12			
SpO ₂	(%)	98	98	98	98	98	98	98			
ART-SYS	(mmHg)	118	118	118	118	118	118	118			
ART-DIA	(mmHg)	76	76	76	76	76	76	76			
ART-MEAN	(mmHg)	91	91	91	91	91	91	91			
CVP-MEAN	(mmHg)	8	8	8	8	8	8	8			
T1	(°C)	---	---	---	---	---	---	---			
T2	(°C)	---	---	---	---	---	---	---			
CO ₂ (F)	(mmHg)	38	38	38	38	38	38	38			
O ₂ (I)	(%)	---	---	---	---	---	---	---			
SEV (E)	(%)	---	---	---	---	---	---	---			
SEV (I)	(%)	---	---	---	---	---	---	---			

NIHON KOHDEN

NIBP TREND Page

The NIBP TREND page displays monitoring parameter data of up to 15 selected parameters as a table. Data for all parameters is automatically entered into the table every time NIBP is measured.

One page shows 7 measurements. Each measurement appears in a separate column. Up to 512 data can be registered to the NIBP trend table. If more than 512 measurements are made, the oldest measurement data is deleted.

The NIBP trend table of selected time period can be recorded on the optional recorder or printed on the network printer.

With the optional QM-601P memory card, data of up to 1,024 files can be saved.

The following table shows the available trend parameter and screen display.

Parameter	Description
HR	Heart rate (beats/min)
PR	Pulse rate (beats/min)
VPC	VPC rate (VPCs/min)
RR	Respiration rate (breaths/min)
ST	ST level (mV, mm)
CO ₂ (E)	CO ₂ partial pressure (mmHg, kPa)
CO ₂ (I)	
O ₂ (E), O ₂ (I)	Oxygen concentration (%)
SpO ₂ , SpO ₂ -2	Saturated oxygen from pulse oximeter (%SpO ₂)
Tb (CO)	Blood temperature (°C, °F)
PRESS* ¹	IBP (mmHg, kPa)
TEMP* ¹	Temperature (°C, °F)
AGENT* ¹ (E), AGENT* ¹ (I)	Agent concentration from gas monitoring (%)
BIS	Bispectral index
SQI	Signal quality indicator (%)
SR	Suppression ratio (s)
EMG	Electromyogram (dB)
CCO	Continuous cardiac output (L/min)
CCI	Continuous cardiac output index (L/min/m ²)
SvO ₂	Mixed venous oxygen saturation (%)
ScvO ₂	Central venous oxygen saturation (%)
EDV	End diastolic volume (ml)
EDVI	End diastolic volume index (mL/m ²)
ESV	End systolic volume (mL)
ESVI	End systolic volume index (mL/m ²)
EF	Ejection fraction (%)
TOFrat	TOF ratio (%)
TOFcnt	TOF counts (times)

*¹ The label appears.

*² These parameters are not available for BSM-6000A series.


Parameter	Description
PTC	Post tetanic counts (times)
PCCO	Pulse contour cardiac output (L/min)
PCCI	Pulse contour cardiac output index (L/min/m ²)
SVR	Systemic vascular resistance (dyn•s/cm ⁵)
SVRI	Systemic vascular resistance index (dyn•s•m ² /cm ⁵ , kPa•s•m ² /L)
SVV	Stroke volume variation (%)
GEDV	Global end diastolic volume (mL)
GEDVI	Global end diastolic volume index (mL/m ²)
ITBV	Intrathoracic blood volume (mL)
ITBVI	Intrathoracic blood volume index (mL/m ²)
GEF	Global ejection fraction (%)
EVLW	Extravascular lung water (mL)
EVLWI	Extravascular lung water index (mL/kg)
MV* ²	Minute volume (L/min)
TVe* ²	Expiratory tidal volume (mL)
C* ²	Compliance (mL/cmH ₂ O, hPa)
R* ²	Airway resistance (cmH ₂ O, hPa/L/s)
Re* ²	Expiratory airway resistance (cmH ₂ O, hPa/L/s)
Ri* ²	Inspiratory airway resistance (cmH ₂ O, hPa/L/s)
Ppeak* ²	Peak airway pressure (cmH ₂ O, hPa)
Pmean* ²	Mean airway pressure (cmH ₂ O, hPa)
PEEP* ²	Positive end expiratory pressure (cmH ₂ O, hPa)

NOTE

- When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.
- Do not disconnect the power cord while the monitor power is on. Data may be lost.


Displaying the NIBP TREND Page

1. Press the [Menu] key to display the MENU window.



2. Touch the TREND key. The TREND window appears.
3. Touch the NIBP TREND tab. The NIBP TREND page appears.

When NIBP TREND is assigned to one of the function keys at the upper left of the screen or one of the function keys on the remote control keys, the NIBP TREND page can be displayed by touching the NIBP TREND function key. Refer to “KEYS Window” in Administrator’s Guide, Section 3 to assign a function to the function key.



For details on the event bar, refer to the previous “EVENT BAR” section.


To return to the home screen, press the [Home] key.

Scrolling the NIBP Trend Table

Use the vertical scroll bar on the window to scroll the NIBP trend table. The trend table can be scrolled by touching the ▲ or ▼ key on the scroll bar.


Selecting Parameters for the NIBP Trend Display

1. Touch the SETTING key on the NIBP TREND page. The PARAMETER SETUP window appears.



2. Select the display position from the left column. Select the parameter from the right column. The selected parameter appears in the display order on the left column.

Selected parameters in the display order.
Up to 15 parameters can be selected




3. Repeat step 2 to select other parameters.

4. Touch the  key to close the window.

Recording a NIBP Trend Table

You can record the NIBP trend table of the selected time period with the optional recorder.

1. Touch the PRINT key. The PRINT window appears.



2. Set the RECORD START TIME and RECORD END TIME with the  or  key or time slider.

3. Check the number of pages and touch the RECORD key in <RECORDER> box.

To stop recording, press the  [Record] key.

4. Touch the  key to close the window.

Recording example


BED-001 JOHN SMITH		2008-03-04 09:33						
03-03-2008		18:29	18:30	18:33	18:34	18:35	18:38	18:42
NIBP-SYS	(mmHg)	134	110	119	112	103	103	85
NIBP-DIA	(mmHg)	57	66	75	73	64	66	61
NIBP-MAP	(mmHg)	100	93	95	91	89	70	71
NIBP-PR	(min)	45	49	52	53	54	54	55
HR	(bpm)	80	80	80	80	80	80	80
PR	(min)	80	80	80	80	80	80	80
VPC	(min)	0	0	0	0	0	0	0
ST-II	(uV)	007	007	007	007	007	007	007
RR	(min)	21	21	21	21	21	21	21
SpO2	(%)							
ART-SYS	(mmHg)	123	123	123	123	123	123	123
ART-DIA	(mmHg)	81	81	81	81	81	81	81
ART-MEAN	(mmHg)	96	96	96	96	96	96	96
CVP-MEAN	(mmHg)	4	4	4	4	4	4	4
TEMP	(°C)	37.0	37.0	37.0	37.0	37.0	37.0	37.0
NIBP TREND								

6

Printing a NIBP Trend Table

You can print the NIBP trend table of the selected time period with a network printer.

1. Touch the PRINT key. The PRINT window appears.



2. Set the RECORD START TIME and RECORD END TIME with the ◀ or ▶ key or time slider.
3. Check the number of pages and touch the RECORD key in <PRINTER> box. The “PRINTING” message appears on the screen and the table is printed.
4. Touch the ✕ key to close the window.

Printing example

4-9-2010 16:50

Bed ID	BSM-TR	Name	JOHN SMITH		Gender	Not Specified	
Patient ID	123456789				Blood Type	Not Specified	
Date of Birth	7-1-1970	Age	39	Height	170.0cm	Weight	60.0kg

4-9-2010	16:48	16:49	16:49	16:50	16:50					
NIBP-SYS	(mmHg)	119	122	109	98	103				
NIBP-DIA	(mmHg)	72	74	64	62	65				
NIBP-MAP	(mmHg)	80	83	76	76	79				
NIBP-PR	(mmHg)	83	87	72	80	83				
HR	(b/min)	58	53	56	60	48				
PR	(mmHg)	56	53	36	44	44				
VPC	(b/min)	0	0	3	7	5				
ST-II	(mV)	+0.01	+0.01	+0.01	+0.01	+0.01				
RR	(b/min)	14	13	15	14	12				
SpO ₂	(%)	---	---	---	---	---				
ART-SYS	(mmHg)	174	173	180	181	182				
ART-DIA	(mmHg)	80	78	65	72	72				
ART-MEAN	(mmHg)	114	113	107	111	112				
CVP-MEAN	(mmHg)	6	6	5	5	6				
T1	(V)	---	---	---	---	---				



HEMO Page

The hemodynamics table can be created when CO or CCO* is monitored and the acquired data is registered to this table. To register the acquired CO data to the hemodynamics table, refer to “Registering the Acquired Data to the Hemodynamics List Window” in User’s Guide Part II, Section 9.

Up to 512 data can be registered to the hemodynamics table. If more than 512 measurements are made, the oldest measurement data is deleted.

With the optional QM-601P memory card, data of up to 1,024 files can be saved.

The hemodynamics table of selected time period can be recorded on the optional recorder or printed on the network printer.


* CCO is monitored only when an Edwards Lifesciences Vigilance CCO/ $\text{S}\bar{\text{v}}\text{O}_2$ monitor is connected to the bedside monitor via the optional QF-903P interface.

NOTE

- When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.
- Do not disconnect the power cord while the monitor power is on. Data may be lost.


Displaying the HEMO Page

1. Press the [Menu] key to display the MENU window.



2. Touch the TREND key. The TREND window appears.

6. REVIEW WINDOWS



3. Touch the HEMO tab. The HEMO page appears.

When HEMO is assigned to one of the function keys at the upper left of the screen or one of the function keys on the remote control keys, the HEMO page can be displayed by touching the HEMO function key. Refer to “KEYS Window” in Administrator’s Guide, Section 3 to assign a function to the function key.

For details on the event bar, refer to the previous “EVENT BAR” section.

To return to the home screen, press the [Home] key.

Scrolling the Hemodynamics Table

Use the vertical scroll bar on the window to scroll the hemodynamic table.

The hemodynamics table can be scrolled by touching the ▲ or ▼ key on the scroll bar.

Explanation of the Hemodynamics Table


Label	Name	Unit	Explanation and Equation
HR	Heart rate	beats/min	Heart rate at the time the CO is measured.
CO	Cardiac output	L/min	—
CI	Cardiac index	L/min/m ²	CI = CO/BSA
ARTsys	Arterial systolic pressure	mmHg, kPa	Values registered at the time the CO is measured.
ARTdia	Arterial diastolic pressure		
ARTmean	Arterial mean pressure		
PAPsys	Pulmonary arterial systolic pressure		
PAPdia	Pulmonary arterial diastolic pressure		
PAPmean	Pulmonary arterial mean pressure		
PCWP	Pulmonary capillary wedge pressure	—	
PCWP TIME	Pulmonary capillary wedge pressure measurement time		
CVP	Central venous pressure mean	mmHg, kPa	
SV	Stroke volume	mL	$SV = (CO \times 1000)/HR$
LVSW*	Left ventricular stroke work	g•m	$LSW = \{SV \times (AMP - PCWP)\} \times 0.0136$
SVR	Systemic vascular resistance	dyn•s/cm ⁵	$SVR = \{(AMP - CVP) \times 80\}/CO$
PVR*	Pulmonary vascular resistance		$PVR = \{(PAMP - PCWP) \times 80\}/CO$
RVSW	Right ventricular stroke work	g•m	$RSW = \{13.6 \times CO \times (PAMP - CVP)\}/HR$
SVI	Stroke volume index	mL/m ²	$SVI = (CI \times 1000)/HR$
LVSWI*	Left ventricular stroke work index	g•m/m ²	$LSWI = \{SVI \times (AMP - PCWP)\} \times 0.0136$
SVRI	Systemic vascular resistance index	dyn•s•m ² /cm ⁵ ,	$SVRI = \{(AMP - CVP) \times 80\}/CI$
PVRI	Pulmonary vascular resistance index	kPa•s•m ² /L	$PVRI = \{(PAMP - PCWP) \times 80\}/CI$
RVSWI	Right ventricular stroke work index	g•m/m ²	$RSWI = \{13.6 \times CO \times (PAMP - CVP)\}/(HR \times BSA)$

* When PCWP is not measured, “- -” appears.

Recording a Hemodynamics Table

You can record the hemodynamics table of the selected time period with the optional recorder.

- 1. Touch the PRINT key. The PRINT window appears.



- 2. Set the RECORD START TIME and RECORD END TIME with the ◀ or ▶ key or time slider.
- 3. Check the number of pages and touch the RECORD key in <RECORDER> box.

To stop recording, press the ⏏ [Record] key.

- 4. Touch the ✕ key to close the window.

Recording example

BED-001 JOHN SMITH		2008-03-04 10:08						
	04-03-2008	09:47	09:50	09:53	09:55	10:01	10:03	10:08
HR	[bpm]	80	80	80	80	82	96	82
CO	[L/min]	306	309	309	311	312	312	312
CI	[L/min/m ²]	1.68	1.70	1.70	1.71	1.72	1.72	1.72
ART-MEAN	[mmHg]	96	96	96	---	96	96	97
PAP-MEAN	[mmHg]	26	26	26	---	26	26	26
PCWP	[mmHg]	---	---	---	---	---	---	---
PCWP TIME		---	---	---	---	---	---	---
CVP	[mmHg]	10	10	10	---	10	11	10
SV	[ml]	38	38	38	38	38	32	38
SVI	[ml/m ²]	21	21	21	21	21	17	21
LVSF	[g/s]	---	---	---	---	---	---	---
LVSFI	[g/m ² /s]	---	---	---	---	---	---	---

HEMODYNAMICS TREND

GE Healthcare FQW50-3-100

K37Z01

LUNG TREND Page

The lung trend table can be created when patient's respiration dynamics are calculated on the LUNG FUNCTION window. The files of up to 128 data can be registered to the lung trend table.


The lung trend table of selected time period can be recorded on the optional recorder.

NOTE

- When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.
- Do not disconnect the power cord while the monitor power is on. Data may be lost.


Displaying the LUNG TREND Page

1. Press the [Menu] key to display the MENU window.



2. Touch the TREND key. The TREND window appears.
3. Touch the LUNG TREND tab. The LUNG TREND page appears.

When LUNG TREND is assigned to one of the function keys at the upper left of the screen or one of the function keys on the remote control keys, the LUNG TREND page can be displayed by touching the LUNG TREND function key. Refer to “KEYS Window” in Administrator’s Guide, Section 3 to assign a function to the function key.



For details on the event bar, refer to the previous “EVENT BAR” section.

To return to the home screen, press the [Home] key.

To add the calculation results to the lung trend table, refer to “Adding the Calculation Result to the LUNG TREND Table” in Section 8.


Explanation of the Lung Trend Table

Label	Name	Unit
BSA	Body surface area	m ²
CI	Cardiac index	L/min/m ²
AaDO ₂	Alveolar arterial oxygen tension difference	mmHg
CaO ₂	Arterial oxygen content	mL/dL
DO ₂	Oxygen delivery	mL/min
DO ₂ I	Oxygen delivery index	mL/min/m ²
CvO ₂	Venous oxygen content	mL/dL
avDO ₂	Arteriovenous oxygen difference	mL/dL
VO ₂	Oxygen consumption	mL/min
VO ₂ I	Oxygen consumption index	mL/min/m ²
O ₂ ER	Oxygen extraction ratio	%
PaO ₂ /O ₂	Oxygenation ratio	mmHg
Qs/Qt	Shunt fraction	%

Recording the Lung Trend Table

You can record the lung trend table of the selected time period with the optional recorder.

- 1. Touch the PRINT key. The PRINT window appears.



- 2. Set the RECORD START TIME and RECORD END TIME with the ◀ or ▶ key or time slider.
- 3. Check the number of pages and touch the RECORD key in <RECORDER> box.

To stop recording, press the ⏏ [Record] key.

- 4. Touch the ✕ key to close the window.

Recording example

ICU-001 JOHN SMITH		2008-03-07 13:32	
CALCULATION RESULTS		DATA ENTRY	
BSA	1.81 [m²]	HEIGHT	170.0 [cm]
CI	2.87 [L/min/m²]	WEIGHT	70.0 [kg]
AaDO₂	-380.07 [mmHg]	CO	5.20 [L/min]
CaO₂	33.76 [ml/dL]	O₂	21 [%]
VO₂	1755.52 [ml/min]	ATM	350 [mmHg]
DO₂I	970.06 [ml/min/m²]	PaCO₂	120 [mmHg]
CrO₂	26.96 [ml/dL]	Hb	25.0 [g/dL]
awO₂	6.81 [ml/dL]	PaO₂	300 [mmHg]
VO₂	353.86 [ml/min]	SpO₂	98 [%]
VO₂I	195.53 [ml/min/m²]	PvO₂	50 [mmHg]
O₂ER	20.16 [%]	SvO₂	80 [%]
PaO₂/O₂	1428.57 [mmHg]		
QS/Qt	-8.07 [%]		

LUNG FUNCTION

GEOMED FQW50-3-100

K37701

Arrhythmia Recall Window

General

An ECG waveform of 4 seconds before and 4 seconds after the arrhythmia detection is saved as an arrhythmia recall file. Up to 8,192 files can be created. When more than 8,192 files are created, the oldest file is automatically deleted.

With the optional QM-601P memory card, data of up to 16,384 files can be saved.

To create arrhythmia recall files:

- <ARRHYTHMIA ANALYSIS> on the ECG window must be set to ON. Refer to “Monitoring Arrhythmia” in User’s Guide Part II, Section 1.
- The type of arrhythmias you want to save as files must be selected on the ARRHYTHMIA EVENT SETUP window. Refer to “Selecting the Arrhythmia Types to be Saved as a Recall File” section.

NOTE

- When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.
- Do not disconnect the power cord while the monitor power is on. Data may be lost.
- When transporting data between BSM-9101 and BSM-6000 series bedside monitors, the arrhythmia recall waveforms cannot be displayed on the destination monitor unless ECG is saved for full disclosure on the original monitor.

The Arrhythmia Recall window displays the recall files. Up to 8 files can be displayed on one page. The actual size arrhythmia waveform can be displayed by touching a recall file.

Arrhythmia List

The arrhythmias are listed in the priority of highest to lowest. When several arrhythmias occur at the same time, only the arrhythmia of the highest priority is saved as the recall file.

Arrhythmia name	Description
ASYSTOLE	Longer than 3 to 10 seconds (selectable) with no QRS complex.
VF	Ventricular fibrillation longer than 4 seconds.
VT	Ventricular tachycardia. 3 to 9 (selectable) or more consecutive VPCs when heart rate exceeding the VT heart rate limit (16 to 300 beats/min selectable).
EXT TACHY* ¹	Extreme tachycardia exceeding the EXTREME TACHY limit.

Arrhythmia name	Description
EXT BRADY* ¹	Extreme bradycardia dropping below the EXTREME BRADY limit.
VPC RUN	VPC short run. 3 to 8 (selectable) consecutive VPCs when heart rate exceeding the VPC RUN heart rate limit (16 to 300 beats/min selectable).
V BRADY* ¹	Ventricular bradycardia. 3 or more consecutive VPCs when heart rate dropping below V BRADY heart rate limit (15 to 299 beats/min selectable).
SV TACHY* ¹	Supraventricular tachycardia. 3 to 9 (selectable) or more consecutive normal QRS of regular R-R interval when heart rate exceeding the SV TACHY heart rate limit (16 to 300 beats/min selectable).
TACHYCARDIA	Heart rate above the upper heart rate limit.
BRADYCARDIA	Heart rate below the lower heart rate limit.
PAUSE* ¹	1 to 3 seconds (selectable) with no QRS.
COUPLET	VPC couplet (paired VPCs). 2 consecutive VPCs.
EARLY VPC	Early VPC including R-on-T type. VPC with a time interval from the preceding normal QRS complex of less than approximately one-third of the normal R-R interval, at heart rate dropping below 120* ² beats/min.
MULTIFORM* ¹	Two different shaped VPCs within the last 3 minutes.
V RHYTHM* ¹	Ventricular rhythm. 3 or more consecutive VPCs.
BIGEMINY	Ventricular bigeminy. 3 or more consecutive pairs of VPC and normal QRS. A dominant rhythm of N-V-N-V-N-V (N = normal beat, V = ventricular beat)
TRIGEMINY* ¹	Ventricular trigeminy. A dominant rhythm of N-N-V-N-N-V.
FREQ VPC	Frequent VPCs. VPC rate (VPCs/min) reaching or exceeding the preset limit of 1 to 99 VPCs/min (selectable).
VPC	Ventricular premature contraction.
IRREGULAR RR* ¹	Consistently irregular R-R intervals.
PROLONGED RR* ¹	R-R interval 1.75 times longer than the dominant R-R interval.
NO PACER PULSE* ¹ * ³	No QRS and pacing pulse within the bradycardia limit. Oversensing.
PACER NON-CAPTURE* ¹ * ³	No QRS from the preceding pacing pulse for the preset time interval (40 to 480 ms selectable). Non-capture.


*¹ These arrhythmias become available when “EXTENDED” is selected for <ARRHYTHMIA TYPE> on the SYSTEM SETUP window. The arrhythmia type setting is not available on the BSM-6000A series. For BSM-6000A series, arrhythmia type is STANDARD only.

*² 120 beats/min when <QRS DETECTION TYPE> is set to ADULT, 150 beats/min when <QRS DETECTION TYPE> is set to CHILD or NEONATE.

*³ Available only when DETECT in the <PACING> box is set to ON.


Displaying the Arrhythmia Recall Window

1. Press the [Menu] key to display the MENU window.



2. Touch the RECALL key to display the Arrhythmia Recall window.

When RECALL is assigned to one of the function keys at the upper left of the screen or one of the function keys on the remote control keys, the ARRHYTHM HISTORY page can be displayed by touching the RECALL function key. Refer to “KEYS Window” in Administrator’s Guide, Section 3 to assign a function to the function key.



When there is no recall file, the “NO DATA” message is displayed.

For details on the event bar, refer to the previous “EVENT BAR” section.

To return to the home screen, press the [Home] key.


Selecting the Arrhythmia Types to be Saved as a Recall File

Select the arrhythmia types to create files for. You can select individual arrhythmia types separately or select all arrhythmia types together.


For BSM-6000A series, the arrhythmia type cannot be selected. There is only one pattern of arrhythmia analysis, STANDARD.

For BSM-6000K series, there are 2 patterns of arrhythmia analysis, EXTENDED or STANDARD. Select the arrhythmia type in the SYSTEM SETUP window. Refer to Administrator's guide, Section 3.

1. Touch the EVENTS key on the ARRHYTH HISTORY page. ARRHYTHMIA EVENT SETUP window appears.



When ARRHYTHMIA TYPE is STANDARD



When ARRHYTHMIA TYPE is EXTENDED

2. Select the arrhythmia type individually.

To set all arrhythmia types together, touch the ALL key.

3. Touch the  key to close the window.


Scrolling the Arrhythmia Recall Files

Use the vertical scroll bar on the window to scroll the arrhythmia recall file. The arrhythmia recall file can be scrolled by touching the  or  key on the scroll bar.

Displaying the Actual Size Waveform of the Selected Arrhythmia Recall File

The ARRHYTH HISTORY window displays the actual size ECG of the selected recall file with the ECG of one before and one after the selected file.

1. Touch the  or  key to select the arrhythmia recall waveform which you want to display in actual size.
2. Touch the center key. The arrhythmia waveform is displayed in the actual size.



Arrhythmia Waveform Annotation

Each beat of a stored arrhythmia waveform is automatically classified and annotated as follows.


QRS Annotation	Description
N	Normal QRS complex
P	Paced QRS
V	Ventricular premature contraction
?	Impossible to classify or during learning.
—	Impossible to classify due to noise interference.

Recording or Printing the Arrhythmia Recall Waveform


The selected arrhythmia waveform can be recorded by the optional recorder or connected network printer. The recording can be performed on both the file window and waveform window.

Recording on the ARRHYTH HISTORY Window

1. Select the arrhythmia recall file you want to record.



2. Touch the PRINT key. The PRINT window appears.



- Touch the RECORD PAGE key in <RECORDER> box. Recording starts.

To stop recording, press the  [Record] key.

4. Touch the  key to close the window.


The arrhythmia waveform is recorded as displayed on the ARRHYTHM HISTORY page.

Recording example




Printing on the ARRHYTHM HISTORY Window

1. Select the arrhythmia recall waveform you want to print.




2. Touch the PRINT key. The PRINT window appears.



3. Touch the PRINT PAGE key in <PRINTER> box. Printing starts.
4. Touch the  key to close the window.


The arrhythmia waveform is printed as displayed on the ARRHYTHM HISTORY page.

Printing example




Recording on the Actual Size ECG Waveform Window

1. Select the arrhythmia recall waveform you want to record.



2. Touch the PRINT key. The window opens.



3. Touch the RECORD PAGE key. Recording starts.


To stop recording the table, press the  [Record] key.

4. Touch the  key to close the window.


The 12 seconds of arrhythmia waveforms can be recorded.

Printing on the Actual Size ECG Waveform Window

1. Select the arrhythmia recall waveform you want to record.



2. Touch the PRINT key. The PRINT window opens.



3. Select the PRINT PAGE key. Printing starts.
4. Touch the  key to close the window.

The 8 seconds of selected arrhythmia waveform and the previous and the next waveforms are printed.

Alarm History Window

Alarm data can be listed on the ALARM HISTORY window. Up to 8,192 files can be saved and up to 8 data can be displayed on the ALARM HISTORY window. The alarm history is created anytime when an alarm occurs.

With the optional QM-601P memory card, data of up to 16,384 files can be saved.

When the FULL DISC window is displayed from the ALARM HISTORY window, the waveforms of the selected alarm file on the ALARM HISTORY window can be displayed.


The alarm history file displayed on the ALARM HISTORY window can be recorded on the optional recorder or printed on the network printer.

NOTE

- When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.
- Do not disconnect the power cord while the monitor power is on. Data may be lost.

Displaying the ALARM HISTORY Window


1. Press the [Menu] key to display the MENU window.



2. Touch the ALARM HISTORY key to display the ALARM HISTORY window.

6. REVIEW WINDOWS

When ALARM HISTORY is assigned to one of the function keys at the upper left of the screen or one of the function keys on the remote control keys, the ALARM HISTORY window can be displayed by touching the ALARM HISTORY function key. Refer to “KEYS Window” in Administrator’s Guide, Section 3 to assign a function to the function key.



For details on the event bar, refer to the previous “EVENT BAR” section.

To return to the home screen, press the [Home] key.


Scrolling the Alarm History Files

Use the vertical scroll bar on the window to scroll the alarm history file. The alarm history file can be scrolled by touching the ▲ or ▼ key on the scroll bar.

Recording the Alarm History File

You can record the alarm history file of the selected time period with the optional recorder.

1. Touch the PRINT key. The PRINT window appears.



- Set the RECORD START TIME and RECORD END TIME with the  or  key or time slider.
- Check the number of pages and touch the RECORD key in <RECORDER> box.

To stop recording, press the  [Record] key.

- Touch the  key to close the window.

Recording example

BED-001 JOHN SMITH		2008-03-04 09:39	
04-03-2008 09:18:53	ECG	ARRHYTHMIA:	VPC RUN
04-03-2008 09:18:55	ECG	ARRHYTHMIA:	TACHYCARDIA
04-03-2008 09:18:55	ECG	ARRHYTHMIA:	VF
04-03-2008 09:18:55	ECG	ARRHYTHMIA:	VT
04-03-2008 09:18:55	ECG	ARRHYTHMIA:	FREQ VPC
04-03-2008 09:18:55	ECG	HR	ALARM ≥ 140
04-03-2008 09:18:55	ECG	VPC	ALARM ≥ 10
04-03-2008 09:18:53	CO ₂	CHECK SENSOR	

ALARM HISTORY 

Full Disclosure Window

ECG and up to 4 other parameter full disclosure of 24 hours can be saved. With the optional QM-601P memory card, data of past 72 hours can be saved.

The full disclosure waveforms can be reviewed, scrolled and recorded, in either compressed or expanded form.


NOTE

- When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.
- Do not disconnect the power cord while the monitor power is on. Data may be lost.
- When using a transport function, select the same parameters for the waveforms to be saved on both the original monitor and the destination monitor to display data on the full disclosure window.

The FULL DISC window displays one minute full disclosure waveform on each line. The 12 second actual size waveform selected by the cursor on the full disclosure is displayed on the actual size ECG window.

Displaying the FULL DISC Window


1. Press the [Menu] key to display the MENU window.



2. Touch the FULL DISC key to display the FULL DISC window.

When FULL DISC is assigned to one of the function keys at the upper left of the screen or one of the function keys on the remote control keys, the FULL DISC page can be displayed by touching the FULL DISC function key.

Refer to “KEYS Window” in Administrator’s Guide, Section 3 to assign a function to the function key.



For details on the event bar, refer to the previous “EVENT BAR” section.

To return to the home screen, press the [Home] key.

NOTE

It may take some time for the data to be displayed.

When there is no full disclosure waveform, the “NO DATA” message is displayed.

The full disclosure is refreshed every minute.


When the FULL DISC window is called up from the ARRHYTHM RECALL window, the full disclosure is displayed with the time of the ARRHYTHM RECALL window.

When the FULL DISC window is called up from the ALARM HISTORY window, the full disclosure is displayed with the time of the file selected on the ALARM HISTORY window.

To display the enlarged waveform of the compressed waveform, touch the part on the FULL DISC window where you want to see the enlarged waveform and touch the ZOOM IN key. To return to the compressed waveform window, press the ZOOM OUT key.


Touch the waveforms to display the 6 seconds of enlarged waveforms. Touch again to restore the previous display.

6. REVIEW WINDOWS



Scrolling the Full Disclosure Waveform

Use the vertical scroll bar on the window to scroll the full disclosure waveform. The full disclosure waveform can be scrolled by touching the ▲ or ▼ key on the scroll bar. The cursor can also be dragged with your finger.




Selecting the Parameters to be Saved for Full Disclosure

ECG and up to 4 other parameters can be saved for the full disclosure. You can select the parameters to be displayed on the FULL DISC window from the saving parameters.


NOTE

- When the saved parameters are changed, the data for the parameter which is no longer saved is deleted.
- The IBP parameters must be correctly labeled. Otherwise, the IBP waveform may distort.
- This setting is independent from the setting on the central monitor or network server. Even when a parameter is selected to be saved on the bedside monitor, that parameter must also be selected to be saved on the central monitor/server. Otherwise the full disclosure for that parameter cannot be displayed on the central monitor.

1. Touch the SETTINGS key to display the SETTINGS window.



2. Touch the WAVEFORMS tab. The WAVEFORM window appears.
3. Select the parameters you want to save the full disclosure data for.



6. REVIEW WINDOWS

- To select the parameters to be displayed on the FULL DISC window, touch the DISPLAY/SAVE tab.




- Select the position from <DISPLAYED WAVES> box and select the parameter to save from <SAVED WAVES> box. Use the NONE key to unselect the parameter.
- Repeat step 4 to select other parameters.
- Touch the  key to close the window.

Recording or Printing the Full Disclosure Waveform


The displayed or saved full disclosure waveform can be recorded on the optional recorder and connected network printer.

Recording the Full Disclosure Waveform

- Display the full disclosure waveform you want to record.



2. Touch the PRINT key. The PRINT window appears.




3. Touch the RECORD PAGE key in <RECORDER> box. Recording starts.

To stop recording, press the [⏏] [Record] key.


4. Touch the [X] key to close the window.

Recording example




Printing the Full Disclosure Waveform

1. Display the full disclosure waveform you want to print.



2. Touch the PRINT key. The PRINT window appears.




3. Touch the PRINT PAGE key in <PRINTER> box.

6. REVIEW WINDOWS

4. Touch the  key to close the window.

Printing example



Recording or Printing the Enlarged ECG Waveform


The displayed enlarged waveform can be recorded or printed on the optional recorder or connected network printer.

Recording the Enlarged ECG Waveform

1. Display the enlarged waveform you want to record by touching the ZOOM IN key.



2. Touch the PRINT key. The PRINT window appears.



3. Touch the RECORD PAGE key in <RECORDER> box. Recording starts.

To stop recording, press the [⏏] [Record] key.

4. Touch the [X] key to close the window.

6. REVIEW WINDOWS

Recording example




Printing the Enlarged ECG Waveform

1. Display the enlarged waveform you want to print by touching the ZOOM IN key.




2. Touch the PRINT key. The PRINT window appears.



3. Touch the PRINT PAGE key in <PRINTER> box. Printing starts.
4. Touch the  key to close the window.

Printing example



ST Level Recall Window

The ST recall waveform and ST level of all monitoring ECG leads for up to 24 hours can be saved. With the optional QM-601P memory card, data of past 72 hours can be saved.

The ST recall window displays 3 files of ST level recall waveforms.

The ST level recall can be printed when the monitor is connected to a network printer.

The ST level alarm limits can be set on the ST ALARM page of the ECG window. Refer to “Changing the ST Alarm Limits” in User’s Guide Part II, Section 1. You can set all alarms, including the ST of all leads alarm limits, on the ALARM LIMITS window. Refer to Section 5 in this manual.


The ST level unit (mV or mm) can be set on the SYSTEM CONFIGURATION screen. Refer to “UNITS Window” in Administrator’s Guide, Section 2.

NOTE

- The ST window is not available when <ST MEASUREMENT> on the PARAMETERS window of the SYSTEM SETUP window is set to OFF.
- Although the ST algorithm has been tested for accuracy of the ST analysis result, the significance of the ST level changes need to be determined only by a physician.
- When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.
- Do not disconnect the power cord while the monitor power is on. Data may be lost.


Displaying the ST Window

1. Press the [Menu] key to display the MENU window.



2. Touch the ST key to display the ST DISPLAY window.

When ST TREND is assigned to one of the function keys at the upper left of the screen or one of the function keys on the remote control keys, the ST INTERVAL page can be displayed by touching the ST function key. Refer to “KEYS Window” in Administrator’s Guide, Section 3 to assign a function to the function key.



When there is no ST level recall waveforms, the “NO DATA” message is displayed.

For details on the event bar, refer to the previous “EVENT BAR” section.
To return to the home screen, press the [Home] key.

Scrolling the ST Level Recall File

Use the vertical scroll bar on the window to scroll the ST level recall file.

The ST level recall file can be scrolled by touching the ▲ or ▼ key on the scroll bar.


Displaying the ST Point

When the ST point setting is set to ON, the ST point can be displayed on the ST level recall waveform.

1. Touch the SETTINGS key on the ST window to display the SETTINGS window.



2. Touch the ON or OFF key in the <ST POINT> box to select on or off.




3. Touch the ✕ key to close the window.


Displaying the ST Recall Waveform on the Home Screen

The ST recall waveform and ST level of selected monitoring ECG leads are displayed on the home screen. Up to 3 waveforms can be displayed.

1. Touch the SETTINGS key on the ST window to display the SETTINGS window.



2. Touch the ON or OFF key in the <ST WAVE ON HOME SCREEN> box to select on or off.



When set to ON, select the lead for each of the 3 ST recall waveforms on the home screen.

3. Touch the  key to close the window.


Saving as Reference ST Recall File

Save the file used as the reference ST waveforms.

1. Select a file to save as a reference file and touch the SAVE AS REF key. A “SAVE AS REFERENCE?” message appears.



2. Touch the YES key to save it as a reference.



To not save it as a reference file, touch the NO key.

3. Touch the  key to close the window.


Displaying the Reference ST Recall Waveform on the Home Screen

When <ST WAVE ON HOME SCREEN> is set to ON, the ST level and up to 3 waveforms saved as reference ST recall waveforms can be displayed on the home screen.

1. Touch the SETTINGS key on the ST window to display the SETTINGS window.



2. Touch the ON or OFF key in the <ST REF WAVE ON HOME SCREEN> box.



When set to ON, select the lead for each of the 3 reference ST recall waveforms on the home screen.

3. Touch the  key to close the window.


Printing the ST Level Recall File

The displayed ST recall files and the previous three ST recall files can be printed when the monitor is connected to a network printer.

1. Touch the PRINT key. The PRINT window appears.




2. Touch the PRINT PAGE key in the <PRINTER> box. Printing starts.



3. Touch the  key to close the window.

Printing example



OCRG Window

The OCRG window displays heart rate and SpO₂ acquired every 1 minute for the trendgraph and compressed respiration waveform of the past 24 hours. With the optional QM-601P memory card, data of past 72 hours can be saved.

NOTE


- When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.
- Do not disconnect the power cord while the monitor power is on. Data may be lost.
- The OCRG window is available only when the site mode is NICU. Refer to “SITE Window” in Administrator’s Guide, Section 2 to change the site.

The following table shows the available trend parameters, screen displays and scales.

Parameter	Description	Vertical Scale Range
HR	Heart rate (beats/min)	210-60, 160-80, 220-100
SpO ₂	Saturated oxygen from pulse oximeter (%SpO ₂)	100-60, 100-80
RESP (IMP)	Respiration measured by impedance method	×1/4, ×1/2, ×1, ×2, ×4


Displaying the OCRG Window

1. Press the [Menu] key to display the MENU window.



2. Touch the OCRG key to display the OCRG window.

When OCRG is assigned to one of the function keys at the upper left of the screen or one of the function keys on the remote control keys, the OCRG page can be displayed by touching the OCRG function key. Refer to “KEYS Window” in Administrator’s Guide, Section 3 to assign a function to the function key.



For details on the event bar, refer to the previous “EVENT BAR” section.


To return to the home screen, press the [Home] key.

Selecting the OCRG Trendgraph Type


Select the OCRG trendgraph type displayed on the home screen.

1. Touch the SETTINGS key on the OCRG window to display the SETTINGS window.

6. REVIEW WINDOWS



2. Select the 1 cm/min or 3 cm/min key in the <SETTINGS> box.




1 cm/min: OCRG display with the horizontal scale 1 cm/min


3 cm/min: OCRG display with the horizontal scale 3 cm/min

Changing the Trendgraph Scale for Heart Rate and SpO₂

You can change the trendgraph scale for heart rate and SpO₂.



1. Touch the SCALE key on the OCRG window to display the SCALE SETUP window.




2. Touch the HR, SpO₂ or RESP(IMP) key on the left and select the desired scale on the right.
3. Touch the  key to close the window.

Recording or Printing the OCRG Trend


Recording the OCRG Trend

The OCRG trend displayed on the OCRG page can be recorded or printed on the optional recorder or connected network printer.

1. Display the OCRG trend you want to record on the OCRG page.



2. Touch the PRINT key. The PRINT window appears.
3. Touch the RECORD PAGE key in the <RECORDER> box. Recording starts.




6. REVIEW WINDOWS

To stop recording, press the [Record] key.

The OCRG trend is recorded as displayed on the OCRG page.


- 4. Touch the [X] key to close the window.

Recording example




Printing the OCRG Trend

- 1. Display the OCRG trend you want to print on the OCRG page.




- 2. Touch the PRINT key. The PRINT window appears.
- 3. Touch the PRINT PAGE key in the <PRINTER> box. Printing starts.



The OCRG trend is printed as displayed on the OCRG page.

- 4. Touch the [X] key to close the window.

Printing example



Section 7 12 Lead Analysis/12 Lead Windows

12 Lead Analysis Window.....	7.2
Preparation Flowchart	7.2
Displaying the 12 LEAD ANALYSIS Window	7.3
Entering the Patient's Date of Birth and Gender	7.4
Displaying the PATIENT INFO Window	7.4
Entering the Date of Birth and Age	7.4
Entering the Gender.....	7.4
Performing 12 Lead ECG Interpretation.....	7.5
Recording or Printing the 12 Lead ECG Waveform.....	7.6
Recording the 12 Lead ECG Waveforms	7.6
Printing the 12 Lead ECG Waveforms	7.7
12 LEAD Window.....	7.9
Displaying the 12 LEAD Window	7.9
12 LEAD Page.....	7.10
Scrolling the 12 Lead Data File	7.10
Recording the 12 Lead Data	7.10
ANALYSIS WAVE Page	7.11
Recording or Printing the 12 Lead Waveform.....	7.12
Recording the 12 Lead Waveform	7.12
Printing the 12 Lead Waveform	7.13
REPORT Page	7.14
Recording or Printing the 12 Lead Interpretation Results	7.14
Recording the 12 Lead Interpretation Results	7.14
Printing the 12 Lead Interpretation Results.....	7.15
AVERAGE WAVE Page	7.16
Printing the Averaged ECGs	7.16

12 Lead Analysis Window

NOTE

- The 12 LEAD ANALYSIS window is not available when an AY-660P input unit is used.
- The 12 LEAD ANALYSIS window is only available when the site mode is ICU or OR. Refer to “SITE Window” in Administrator’s Guide, Section 2.

When ECG is monitored with 10 electrodes, simultaneous 12 lead ECG can be displayed on the 12 LEAD ANALYSIS window. When ECG is monitored with 6 electrodes, simultaneous 8 lead ECG can be displayed.

The ECG waveforms on the 12 LEAD ANALYSIS window can be analyzed by the 12 lead ECG interpretation program (ECAPS 12C) and analysis result and clinical findings can be displayed on the screen. For details about the analysis and the clinical findings, refer to the ECAPS 12C program user’s guide. Up to 6 lead ECG interpretation result can be saved on the monitor.

ECG waveforms displayed on the 12 LEAD ANALYSIS window, 12 LEAD page, ANALYSIS WAVE page and REPORT page in 12 LEAD window can be recorded on the recorder.

When the monitor is connected to the CNS-9300 series, CNS-9601 or CNS-9701 central monitor network, the ECG waveforms displayed on the 12 LEAD ANALYSIS window, the 12 lead ECG interpretation result and the averaged ECG can be sent to the central monitor and printed on the central monitor printer.

When the monitor is connected to the CNS-9601 central monitor with QP-964P program kit or CNS-9701 central monitor with QP-974P program kit, the 12 lead ECG interpretation result and ECG waveforms are automatically sent to the central monitor and can be reviewed and printed on the central monitor.

When the monitor is connected to a network printer, the ECG waveforms displayed on the 12 LEAD ANALYSIS window can be printed on the network printer.


Preparation Flowchart

1. Display the PATIENT INFO window on the 12 LEAD ANALYSIS window and check that the age and gender are correct. To correct the age and gender, refer to “Entering the Patient’s Date of Birth and Gender” section.
2. Check that the electrodes are attached to the patient and leads are connected appropriately.
3. Display the 12 LEAD ANALYSIS window and check that ECGs on the


window are stable. Refer to “Displaying the 12 LEAD ANALYSIS Window” section.

Displaying the 12 LEAD ANALYSIS Window

1. Press the [Menu] key. The MENU window appears.



2. Touch the 12 LEAD ANALYSIS key. The 12 LEAD ANALYSIS window appears.



You can change the sensitivity of the ECG waveforms

Starts analysis

Displays 12 LEAD window

Patient's gender

Patient's age

You can change the patient's date of birth and gender

Prints the displayed ECGs on the WS-671P recorder module or connected network printer

3. Press the [Home] key to return to the home screen.

Entering the Patient's Date of Birth and Gender

Displaying the PATIENT INFO Window

1. Touch the PATIENT INFO key on the 12 LEAD ANALYSIS window. The PATIENT INFORMATION window appears.

2. Touch the close button (X), to close the window.

Entering the Date of Birth and Age

CAUTION

When the date of birth or age is not entered, 12 lead ECG interpretation is performed with the patient as 35 years old.

1. Touch the YEAR, MONTH and DAY key to enter year, month and day respectively.
2. Enter the numbers by using the numeric keypad, then touch the ENT key.
3. Touch the SET key. When the year, month and day are entered, age is automatically calculated and appears in the age area.

Entering the Gender

CAUTION

When the gender is not specified, 12 lead ECG interpretation is performed with the patient as male.

Touch the MALE, FEMALE or - (Unknown) key in <GENDER> box.

Performing 12 Lead ECG Interpretation

WARNING

Do not use 12 lead ECG interpretation results and measured values from the Mason-Likar modification for diagnosis because the limb electrode placement is not the same as the standard 12 lead ECG. This may cause wrong diagnosis since 12 lead ECG interpretation of this monitor is based on the standard 12 lead ECG.

CAUTION

- The 12 lead ECG interpretation is performed for acquired ECG waveforms only and does not reflect all conditions of the patient. The results of the analysis might not correspond to the judgement of a physician.
- Overall judgement must be performed by the physician, referring to the analysis result, clinical findings and other examination results. After the physician's overall judgement, the analysis results should be signed or initialed by the physician.

CAUTION

When the gender is not specified, 12 lead ECG interpretation is performed with the patient as male.


CAUTION

When the date of birth or age is not entered, 12 lead ECG interpretation is performed with the patient as 35 years old.

NOTE

- When electrodes are not attached to the limbs, the analysis result concerning the ECG axis (such as axis deviation) may differ from the analysis with electrodes attached to limbs.
- Noise is rejected from the analyzed waveforms by the 50/60 Hz filter, but noise other than these frequencies might not be rejected.

1. Touch the START key to start analyzing ECGs. The "SAVING. PLEASE WAIT" message appears and 10 second ECG of all leads are acquired and analyzed.






When analyzing is complete, the “ANALYZING. PLEASE WAIT” message disappears and the 12 LEAD window is displayed.

Recording or Printing the 12 Lead ECG Waveform

Recording the 12 Lead ECG Waveforms

10 second ECG waveform used for analysis can be recorded on the optional recorder.

1. Touch the PRINT key. The window appears.



2. Touch the RECORDER key. Recording starts.

To stop recording, press the  [Record] key.

3. Touch the  key to close the window.

Recording example




7

Printing the 12 Lead ECG Waveforms


10 second 12 lead ECG waveform used for analysis can be printed when the monitor is connected to a network printer or the monitor is connected to a CNS-9300 series or CNS-9601, CNS-9701 central monitor network.

1. Touch the PRINT key. The window appears.



2. Touch the PRINTER key. Printing starts.
3. Touch the  key to close the window.

Printing example



12 LEAD Window

NOTE

The 12 LEAD window is only available when the site mode is ICU or OR. Refer to “SITE Window” in Administrator’s Guide, Section 2.

The 12 LEAD window has the following pages related to 12 LEAD ANALYSIS window.

- 12 LEAD page for displaying the 12 lead analysis result data
- ANALYSIS WAVE page for displaying ECG waveforms used for analysis
- REPORT page for displaying clinical findings
- AVERAGE WAVE page for displaying averaged ECG waveforms


NOTE

When <AUTO ADMIT> in the SYSTEM CONFIGURATION screen is set to ON, the stored data in the monitor will be deleted if the power is turned off for more than 30 minutes. When <AUTO ADMIT> is set to OFF, you can select whether to save the settings or initialize the master settings.

7

Displaying the 12 LEAD Window


1. Press the [Menu] key to display the MENU window.



2. Touch the 12 LEAD key. The 12 LEAD window appears.
3. Press the [Home] key to return to the home screen.

12 LEAD Page

To see the 12 lead analysis result data, touch the 12 LEAD tab. Up to 6 files can be saved and up to 4 files can be displayed on the 12 LEAD page.



When 12 LEAD is assigned to one of the function keys at the upper left of the screen, the 12 LEAD page can be displayed by touching the 12 LEAD function key. Refer to “KEYS Window” in Administrator’s Guide, Section 3 to assign a function to the function key.

For the event bar description, refer to “Event Bar” in Section 6.

Scrolling the 12 Lead Data File

The 12 lead analysis result data table can be scrolled by touching the ▲ or ▼ key on the vertical scroll bar.

Recording the 12 Lead Data

The displayed 12 lead data can be recorded on the optional recorder.

1. Display the 12 lead data you want to record.

	19-12-2008 17:55:18	19-12-2008 17:55:49	19-12-2008 17:56:18	19-12-2008 17:56:54
■ GENDER: MALE				
■ AGE: 038				
HR	79	79	79	79
PR INTERVAL	160	160	160	160
QRS DURATION	104	104	104	104
QT/QTc	412/ 447	412/ 447	412/ 447	412/ 447
P/QRS/T	90/ 40/ 56	90/ 40/ 56	90/ 40/ 56	90/ 40/ 56
RV5/SV1	1.150/0.680	1.150/0.680	1.150/0.680	1.150/0.680
RV5+SV1	1.830	1.830	1.830	1.830
ST-I	0.03	0.03	0.03	0.03
ST-II	0.06	0.06	0.06	0.06
ST-III	0.03	0.03	0.03	0.03
ST-aVR	-0.05	-0.05	-0.05	-0.05
ST-aVL	0.01	0.01	0.01	0.01

19-12-2008 17:56


ARRHYTHMIA
TECHNICAL

:00 15:00 16:00 17:00

4 h

PRINT

2. Touch the PRINT key. The window appears.



3. Touch the RECORD PAGE key. Recording starts.
4. Touch the key to close the window.


Recording example

ICU-001 JOHN SMITH 2008-03-07 13:35					ICU-001 JOHN SMITH 2008-03-07 13:35				
■ GENDER: MALE	07-03-2008 13:33:55	07-03-2008 13:34:32	07-03-2008 13:34:53	07-03-2008 13:35:09	ST-aVR	-005	-005	-005	-005
■ AGE: 038					ST-aVL	001	001	001	001
HR	79	79	79	79	ST-aVF	004	004	004	004
PR INTERVAL	160	160	160	160	ST-V1	010	010	010	010
QRS DURATION	104	104	104	104	ST-V2	021	021	021	021
QT/QTc	412/ 447	412/ 447	412/ 447	412/ 447	ST-V3	035	035	035	035
P/QRS/T	90/ 40/ 56	90/ 40/ 56	90/ 40/ 56	90/ 40/ 56	ST-V4	022	022	022	022
RV5/SV1	1.150/0.680	1.150/0.680	1.150/0.680	1.150/0.680	ST-V5	007	007	007	007
RV5+SV1	1.830	1.830	1.830	1.830	ST-V6	005	005	005	005
ST-I	0.03	0.03	0.03	0.03					
ST-II	0.06	0.06	0.06	0.06					
ST-III	0.03	0.03	0.03	0.03					

ANALYSIS WAVE Page

To see the 12 lead analysis result, touch the ANALYSIS WAVE tab. About 2.5 seconds of the ECG of each lead and 10 seconds of rhythm waveform (lead II) used for the analysis are displayed.

7. 12 LEAD ANALYSIS/12 LEAD WINDOWS




Recording or Printing the 12 Lead Waveform

Recording the 12 Lead Waveform

Analyzed 10 second ECG waveform can be recorded on the optional recorder. The rhythm waveform cannot be recorded.

1. Touch the PRINT key. The PRINT window appears.




2. Touch the RECORD PAGE key in <RECORDER> box. Recording starts.

To stop recording, press the [Record] key.

3. Touch the key to close the window.


Recording example



Printing the 12 Lead Waveform


Analyzed 10 second 12 lead ECG waveform used for analysis can be printed when the monitor is connected to a network printer.

1. Touch the PRINT key. The PRINT window appears.



2. Touch the PRINT PAGE key in <PRINTER> box. Printing starts.
3. Touch the  key to close the window.

Printing example




REPORT Page

To see analysis results, touch the REPORT tab. The REPORT page appears. For details about the findings, refer to the ECAPS 12C program user's guide.

When the analysis result on the REPORT window is recorded or printed, the recorded/printed data must be examined by a physician. After the physician's overall judgement, the "UNCONFIRMED REPORT" message on the recording/printing paper must be crossed out and signed by the physician.

Up to six analysis results can be saved in the monitor. When another analysis is performed, the older data is deleted. If necessary, record or print the analysis result before performing another analysis on the 12 LEAD ANALYSIS window.




When the analysis is not performed, "NO DATA" message appears.

Recording or Printing the 12 Lead Interpretation Results

Recording the 12 Lead Interpretation Results

The 12 lead interpretation results are recorded as display on the REPORT page.

1. Touch the PRINT key. The PRINT window appears.




2. Touch the RECORD PAGE key in <RECORDER> box. Recording starts.

To stop recording, press the  [Record] key.

3. Touch the  key to close the window.

Recording example



OR-001 JOHN SMITH 2008-03-11 11:33


DATE: 11-03-2008 11:04:44 GENDER: MALE AGE: 038
 HR 79 [bpm] P/QRS/T 90/ 48/ 56 [deg]
 PR INTERVAL 160 [ms] RV5/SV1 1,150/0,680 [mV]
 QRS DURATION 104 [ms] RV5+SV1 1,830 [mV]
 QT/QTc 412/ 447 [ms]
 1100 Sinus rhythm
 9110 ** normal ECG **

(02-45) UNCONFIRMED REPORT
 REVIEWED BY

12 LEAD Evergreen FQW50-3-100

Printing the 12 Lead Interpretation Results

1. Touch the PRINT key. The PRINT window appears.



PRINT

RECORDER PRINTER


RECORD PAGE PRINT PAGE

2. Touch the PRINT PAGE key in <PRINTER> box. Printing starts.

To stop printing, press the  [Record] key.


3. Touch the  key to close the window.

Printing example



AVERAGE WAVE Page


To see the averaged ECGs, touch the AVERAGE WAVE tab. The cursors appear to indicate the P wave start and end points, QRS start and end points and T wave end points. The averaged ECGs can only be printed on the network printer.



Printing the Averaged ECGs


The averaged ECGs, analysis results and findings are printed.

1. Touch the PRINT key. The PRINT window appears.



2. Touch the PRINT PAGE key in <PRINTER> box. Printing starts.
3. Touch the  key to close the window.

Printing example



Section 8 Drug/Lung Function Windows

DRUG Window	8.2
Drug Titration Initial Settings	8.3
Flow Rate Equations	8.4
Displaying the DRUG Window	8.6
Selecting the Drug	8.9
Assigning a Drug Name and Dosage Unit to DRUG A to D	8.10
Changing the Settings	8.12
Changing the Drug Amount, Solution Amount, Dosage, Flow Rate and Weight	8.12
Changing the Dose Step	8.13
Unit and Setting Range	8.13
Drug Amount, Dosage and Step	8.13
Solution Amount, Flow Rate and Weight	8.14
LUNG FUNCTION Window	8.15
Displaying the LUNG FUNCTION Window	8.15
Entering the Data	8.17
Explanation of the DATA ENTRY Items	8.17
Checking the Calculation Results	8.18
Explanation of the CALCULATION RESULTS	8.18
Adding the Calculation Results to the LUNG TREND Table	8.18
Displaying the LUNG TREND Table	8.19
Recording the Calculation Results and Entered Data	8.20

DRUG Window

On the DRUG window, you can calculate the flow rates and dosages for medication titrations. The flow rate is calculated from the following equation. The dosage can also be calculated when the flow rate is known.

$$\text{Flow rate} = \frac{\text{Dosage} \times \text{Patient Weight} \times \text{Solution Amount}}{\text{Drug Amount}}$$

There are three windows for the drug calculation. On the DOSE window, you can see the table of the selected drug titration. The drug name and unit are selected on the DRUG window. On the SETTING window, you can change drug amount (AMOUNT), solution amount (VOLUME), dosage (DOSE), flow rate (SAMPLE RATE), patient weight and dose step. The settings on the DRUG and SETTING windows are used for the drug calculation and you can see the calculation result on the DOSE window. The dosage and flow rate calculated from the setting on the SETTING window are highlighted in blue.

The screenshot shows the DRUG window interface. On the left, there are input fields for drug settings: DRUG NAME (AMRINONE), DRUG AMOUNT (500.00 mg), BASE VOLUME (250 mL), CONCENTRATION (2), DOSE (20.00 mcg/kg/min), SAMPLE RATE (42.0 mL/h), WEIGHT (70.0 kg), and DOSE STEP (0.01). On the right, there is a titration table with columns for DOSE and SAMPLE RATE. The table shows a range of values from 19.91 to 20.10 for DOSE and 41.8 to 42.2 for SAMPLE RATE. The values 20.00 and 42.0 are highlighted in blue. Below the table, there are buttons for selecting the dose step (0.01, 0.05, 0.10, 1.00, 10.00) and a PRINT button. Annotations point to various elements: 'Drug name selected on the DRUG window' points to the DRUG NAME field; 'Value calculated from the settings on the SETTING window' points to the DOSE field; 'Set on the SETTING window' points to the DOSE STEP field; 'Select the dose step' points to the dose step buttons; 'Prints the titration table and the drug on the recorder or network printer' points to the PRINT button; and 'Titration table' points to the table of values.

Drug name selected on the DRUG window

Value calculated from the settings on the SETTING window

Set on the SETTING window

Select the dose step

Prints the titration table and the drug on the recorder or network printer

Titration table

DOSE	SAMPLE RATE	DOSE	SAMPLE RATE
19.91	41.8	20.01	42.0
19.92	41.8	20.02	42.0
19.93	41.9	20.03	42.1
19.94	41.9	20.04	42.1
19.95	41.9	20.05	42.1
19.96	41.9	20.06	42.1
19.97	41.9	20.07	42.1
19.98	42.0	20.08	42.2
19.99	42.0	20.09	42.2
20.00	42.0	20.10	42.2

NOTE

- When using the DRUG window for the first time after shipment or after settings are initialized, you must set the drug names and other settings.
- When the patient weight is changed on the ADMIT window, the titration is automatically recalculated with the new weight.

17 drugs and drug amount, solution amount, dosage and dose step for each drug are preset on the monitor. The dosage and flow rate are calculated from the equations listed in the “Flow Rate Equations” section. You can set four other drugs on the DRUG window and change the settings on the EDIT window.

Drug Titration Initial Settings

Drug Name	Drug Amount	Solution Amount	Dosage	Step
AMRINONE	500 mg	250 mL	5.00 µg/kg/min	0.10
AMINOPHYLLINE	500 mg	250 mL	0.50 mg/h	0.10
BRETYLIUM	2000 mg	250 mL	1.00 mg/min	0.10
DOBUTAMINE	250 mg	250 mL	2.50 µg/kg/min	0.10
DOPAMINE	800 mg	250 mL	2.00 µg/kg/min	0.10
EPINEPHRINE	4 mg	250 mL	1.00 µg/min	0.10
HEPARIN	25000 units	250 mL	1000 units/h	50
INSULIN	100 units	100 mL	1.00 units/h	0.10
ISOPROTERENOL	2 mg	250 mL	1.00 µg/kg/min	0.10
LIDOCAINE	2000 mg	250 mL	2.00 mg/min	0.10
NITROGLYCERIN	50 mg	250 mL	100 µg/min	0.10
NITROPRUSSIDE	50 mg	250 mL	0.50 µg/kg/min	0.10
NOREPINEPHRINE	4 mg	250 mL	2.00 µg/min	0.10
PHENYLEPHRINE	300 mg	250 mL	100 µg/min	0.10
PROCAINAMIDE	2000 mg	250 mL	2.00 mg/min	0.10
STREPTOKINASE	750000 IU	250 mL	30000 IU/h	5000
TPA	100 mg	200 mL	20.00 mg/h	0.10
DRUG A to D	500 mg	250 mL	1.00 µg/kg/min	0.01

Flow Rate Equations

Dosage Unit	Drug Name	Equation
mg/h	AMINOPHYLLINE TPA	$\text{Flow rate (mL/h)} = \frac{\text{Dosage (mg/h)} \times \text{Solution amount (mL)}}{\text{Drug amount (mg)}}$
mg/min	BRETYLIUM LIDOCAINE PROCAINAMIDE	$\text{Flow rate (mL/h)} = \frac{\text{Dosage (mg/min)} \times \text{Solution amount (mL)} \times 60}{\text{Drug amount (mg)}}$
µg/min	EPINEPHRINE ISOPROTERENOL NOREPINEPHRINE PHENYLEPHRINE	$\text{Flow rate (mL/h)} = \frac{\text{Dosage (µg/min)} \times \text{Solution amount (mL)} \times 60}{\text{Drug amount (mg)} \times 1000}$
µg/kg/min	AMRINONE DOPAMINE DOBUTAMINE NITROGLYCERINE NITROPRUSSIDE	$\text{Flow rate (mL/h)} = \frac{\text{Dosage (µg/kg/min)} \times \text{Weight (kg)} \times \text{Solution amount (mL)} \times 60}{\text{Drug amount (mg)} \times 1000}$
units/h	HEPARIN INSULIN	$\text{Flow rate (mL/h)} = \frac{\text{Dosage (units/h)} \times \text{Solution amount (mL)}}{\text{Drug amount (units)}}$
IU/h	STREPTOKINASE	$\text{Flow rate (mL/h)} = \frac{\text{Dosage (IU/h)} \times \text{Solution amount (mL)}}{\text{Drug amount (IU)}}$


For DRUG A to D, when using the same dosage unit as above, the same equation is used. When using other units, refer to the table below.

Dosage Unit	Equation
mg/kg/min	$\text{Flow rate (mL/h)} = \frac{\text{Dosage (mg/kg/min)} \times \text{Weight (kg)} \times \text{Solution amount (mL)} \times 60}{\text{Drug amount (mg)}}$
mg/kg/h	$\text{Flow rate (mL/h)} = \frac{\text{Dosage (mg/kg/h)} \times \text{Weight (kg)} \times \text{Solution amount (mL)}}{\text{Drug amount (mg)}}$
µg/h	$\text{Flow rate (mL/h)} = \frac{\text{Dosage (µg/h)} \times \text{Solution amount (mL)}}{\text{Drug amount (mg)} \times 1000}$
µg/kg/h	$\text{Flow rate (mL/h)} = \frac{\text{Dosage (µg/kg/h)} \times \text{Weight (kg)} \times \text{Solution amount (mL)}}{\text{Drug amount (mg)} \times 1000}$

Dosage Unit	Equation
units/kg/h	$\text{Flow rate (mL/h)} = \frac{\text{Dose speed (units/kg/h)} \times \text{Weight (kg)} \times \text{Base amount (mL)}}{\text{Drug amount (units)}}$
IU/kg/h	$\text{Flow rate (mL/h)} = \frac{\text{Dose speed (IU/kg/h)} \times \text{Weight (kg)} \times \text{Base amount (mL)}}{\text{Drug amount (IU)}}$

Displaying the DRUG Window

- 1. Press the [MENU] key to display the MENU window.



- 2. Touch the DRUG key. The DRUG window appears.



Touching the PRINT key prints the titration table and the drug data on the left.

Recording example

ICU-001 JOHN SMITH 2008-03-07 13:30

DRUG NAME AMRINONE	DOSE 19.10	SAMPLE RATE 40.1	DOSE 20.10	SAMPLE RATE 42.2
DRUG AMOUNT 500.00 mg	19.20	40.3	20.20	42.4
BASE VOLUME 250 mL	19.30	40.5	20.30	42.6
CONCENTRATION 2	19.40	40.7	20.40	42.8
DOSE 20.00 mcg/kg/min	19.50	41.0	20.50	43.0
SAMPLE RATE 42.0 mL/h	19.60	41.2	20.60	43.3
WEIGHT 70.0 kg	19.70	41.4	20.70	43.5
DOSE STEP 0.10	19.80	41.6	20.80	43.7
	19.90	41.8	20.90	43.9
	20.00	42.0	21.00	44.1

DRUG *Amrinone* FGWS0-3-100 K37Z01

3. To display the DRUG window, touch the DRUG tab.

DRUG SETTINGS DOSE

Select drug

DRUG NAME
DOPAMINE

DRUG AMOUNT
800.00 mg

BASE VOLUME
250 mL

CONCENTRATION
3.200

DOSE
2.00 mcg/kg/min

SAMPLE RATE
2.6 mL/h

WEIGHT
70.0 kg

DOSE STEP
0.10

AMRINONE

AMINOPHYLLINE

BRETYLIUM

DOBUTAMINE

DOPAMINE

EPINEPHRINE

HEPARIN

INSULIN

ISOPROTERENOL

LIDOCAINE

NITROGLYCERIN

NITROPRUSSIDE

NOREPINEPHRINE

PHENYLEPHRINE

PROCAINAMIDE

STREPTOKINASE

tPA

DRUG A

DRUG B

DRUG C

DRUG D

EDIT

Displays EDIT window for entering drug name and dose unit

To display the SETTINGS window, touch the SETTINGS tab.

8. DRUG/LUNG FUNCTION WINDOWS

Touch key to enter value.

Parameter	Value	Range
DRUG NAME	AMRINONE	
DRUG AMOUNT	500.00 mg	(0.01 - 2000.00)
BASE VOLUME	250 mL	(1 - 1000)
CONCENTRATION	2	(0.01 - 500.00)
DOSE	20.00 mcg/kg/min	(0.1 - 600.0)
SAMPLE RATE	42.0 mL/h	(0.1 - 449.9)
WEIGHT	70.0 kg	
DOSE STEP	0.01	

Use the numeric keypad to enter value. Touch the ENT key to register the entered value.

4. Press the [Home] key to return to the home screen.

Selecting the Drug

1. Display the DRUG window.

Press the [Menu] key → DRUG key → DRUG tab.

Selected drug name →

The screenshot shows the 'DRUG' window with three tabs: DRUG, SETTINGS, and DOSE. The DRUG tab is active. On the left, there is a list of fields: DRUG NAME (DOPAMINE), DRUG AMOUNT (800.00 mg), BASE VOLUME (250 mL), CONCENTRATION (3.200), DOSE (2.00 mcg/kg/min), SAMPLE RATE (2.6 mL/h), WEIGHT (70.0 kg), and DOSE STEP (0.10). An arrow points from the text 'Selected drug name' to the 'DOPAMINE' entry in the DRUG NAME field. On the right, there is a grid of drug selection buttons: AMRINONE, AMINOPHYLLINE, BRETYLIUM, DOBUTAMINE, DOPAMINE (highlighted in blue), EPINEPHRINE, HEPARIN, INSULIN, ISOPROTERENOL, LIDOCAINE, NITROGLYCERIN, NITROPRUSSIDE, NOREPINEPHRINE, PHENYLEPHRINE, PROCAINAMIDE, STREPTOKINASE, tPA, DRUG A, DRUG B, DRUG C, and DRUG D. An 'EDIT' button is located at the bottom right of the grid.

2. Select the drug by touching the drug name key. When the drug is selected, drug amount, solution amount (BASE VOLUME), dosage (DOSE) and step (DOSE STEP) set for that drug and concentration and flow rate (SAMPLE RATE) which are automatically calculated appear on the window.

NOTE

- DOPAMINE, DOBUTAMINE, NITROGLYCERIN and NITROPRUSSIDE need patient weight to calculate the flow rate. For these drugs, enter the patient weight on the ADMIT window or the SETTINGS window of the DRUG window.
- For the DRUG A to D, assign the drug name and set the unit on the DRUG window and set the drug amount, solution amount, dosage and step on the SETTINGS window.

Assigning a Drug Name and Dosage Unit to DRUG A to D

When using a drug other than the 17 preset drugs, you can assign a drug name and dosage unit to DRUG A to D. When the dosage unit is set, the flow rate unit is automatically set. When using this function, you must also set the drug amount, solution amount (BASE VOLUME), dosage (DOSE) and step (DOSE STEP) so that the dosage and flow rate (SAMPLE RATE) can be calculated.

1. Display the DRUG NAME window.

Press the [Menu] key → DRUG key → DRUG tab.

2. Select DRUG A, B, C or D key to assign a drug name.

3. Touch the EDIT key. The keyboard for entering drug name appears.

4. Enter the drug name. Up to 16 alphanumeric characters can be entered. Touch the ENT key to register the entered name.

5. Select the unit. When the dosage unit is set, the flow rate unit is automatically set as follows.

Dosage Unit	Drug Amount Unit
mg/h	mg
mg/min	
mg/kg/h	
mg/kg/min	
µg/h	
µg/min	
µg/kg/h	
µg/kg/min	
units/h	units
IU/h	IU

Changing the Settings

The following items can be changed for the drug calculation. When the settings are changed, the dosage and flow rate are automatically recalculated.


- Drug amount
- Solution amount (Base volume)
- Dosage (Dose)
- Flow rate (Sample rate)
- Weight
- Step (Dose step)

NOTE

- Enter the data in the units displayed on the window.
- When using the drug which is assigned to DRUG A to D, you must set the unit on the DRUG window before changing the setting on the SETTINGS window.

Changing the Drug Amount, Solution Amount, Dosage, Flow Rate and Weight

1. Display the SETTINGS window.
Press the [Menu] key → DRUG key → SETTINGS tab.



2. Select the item you want to change the setting for by touching the item name key.
3. Change the setting.
Use the numeric keypad on the window, then touch the ENT key.

Changing the Dose Step

1. Display the DOSE window.
Press the [Menu] key → DRUG key → DOSE tab.

DOSE	SAMPLE RATE	DOSE	SAMPLE RATE
19.91	41.8	20.01	42.0
19.92	41.8	20.02	42.0
19.93	41.9	20.03	42.1
19.94	41.9	20.04	42.1
19.95	41.9	20.05	42.1
19.96	41.9	20.06	42.1
19.97	41.9	20.07	42.1
19.98	42.0	20.08	42.2
19.99	42.0	20.09	42.2
20.00	42.0	20.10	42.2

DOSE STEP: 0.01, 0.05, 0.10, 1.00, 10.00, PRINT

2. Select the setting from <DOSE STEP> box.

Unit and Setting Range

Drug Amount, Dosage and Step

Drug Name	Drug Amount		Dosage		Step
	Unit	Setting Range	Unit	Setting Range	Setting Range
AMRINONE	mg	0.01 to 1500000	µg/kg/min	0.01 to 1500000	0.01, 0.05, 0.10, 1.00, 10.00
AMINOPHYLLINE			mg/h		
BRETYLIUM			mg/min		
DOBUTAMINE			µg/kg/min		
DOPAMINE			µg/kg/min		
EPINEPHRINE			µg/min		
HEPARIN	units		units/h		10, 50, 100, 500
INSULIN			units/kg/h		
ISOPROTERENOL	mg		µg/min		0.01, 0.05, 0.10, 1.00, 10.00
LIDOCAINE			mg/min		
NITROGLYCERIN	mg		µg/kg/min		
NITROPRUSSIDE			µg/kg/min		
NOREPINEPHRINE			µg/min		
PHENYLEPHRINE			µg/min		
PROCAINAMIDE			mg/min		
ISOPROTERENOL					
STREPTOKINASE	IU		IU/h		5000, 10000, 50000
			IU/kg/h		
TPA	mg		mg/h		0.01, 0.05, 0.10, 1.00, 10.00

8. DRUG/LUNG FUNCTION WINDOWS

For DRUG A to D

Dosage		Drug Amount		Step
Unit	Setting Range	Unit	Setting Range	Setting Range
mg/h	0.01 to 1500000	mg	0.01 to 1500000	0.01, 0.05, 0.10, 1.00, 10.00
mg/min				
mg/kg/h				
mg/kg/min				
µg/h				
µg/min				
µg/kg/h				
µg/kg/min				
units/h		units	0.01 to 1500000	10, 50, 100, 500
units/kg/h				
IU/h		IU		5000, 10000, 50000
IU/kg/h				

Solution Amount, Flow Rate and Weight

Item	Unit	Drug Amount Unit
Solution Amount	mL	1 to 1000
Flow Rate	mL/h	0.1 to 1000
Weight	kg	0 to 449.9

LUNG FUNCTION Window

There are two windows in the LUNG FUNCTION window. The DATA ENTRY window calculates the patient's respiration dynamics and the LUNG FUNCTION window displays the calculation result. The following data required for this calculation is automatically acquired from the monitoring parameters when the window is opened.


- Patient's height and weight entered on the ADMIT window
- CCO value (When CCO is measured, the CCO value is used as the CO value)
- O₂ when O₂ or anesthetic gas is monitored

The calculation result displayed on the LUNG FUNCTION page can be recorded on the optional recorder.

8

Displaying the LUNG FUNCTION Window

1. Press the [Menu] key to display the MENU window.



2. Touch the DATA ENTRY tab. THE DATA ENTRY page appears.

8. DRUG/LUNG FUNCTION WINDOWS

The screenshot shows the 'DATA ENTRY' window with two tabs: 'DATA ENTRY' and 'LUNG FUNCTION'. The 'DATA ENTRY' tab is active, displaying a list of parameters with their values and units. A numeric keypad is visible on the right side of the screen.

Parameter	Value	Unit
HEIGHT	170.0	[cm]
WEIGHT	70.0	[kg]
CO	5.20	[L/min]
O ₂	21	[%]
ATM	760	[mmHg]
PaCO ₂	40	[mmHg]
Hb	15.0	[g/dL]
PaO ₂	100	[mmHg]
SaO ₂	98	[%]
PvO ₂	50	[mmHg]
SvO ₂	80	[%]

The numeric keypad contains the following buttons: 7, 8, 9, BS, 4, 5, 6, 1, 2, 3, ENT, 0, .

Setting items

Use the numeric keypad to change the values on the DATA ENTRY window.

3. Touch the LUNG FUNCTION tab. The LUNG FUNCTION page appears.

The screenshot shows the 'LUNG FUNCTION' window with two tabs: 'DATA ENTRY' and 'LUNG FUNCTION'. The 'LUNG FUNCTION' tab is active, displaying a table of calculation results and a 'DATA ENTRY' section. There are also buttons for 'ADD TO LUNG TREND', 'SHOW LUNG TREND', and 'RECORD'.

CALCULATION RESULTS	
BSA	1.81 [m ²]
CI	2.87 [L/min/m ²]
AaDO ₂	1.83 [mmHg]
CaO ₂	20.01 [mL/dL]
DO ₂	1040.42 [mL/min]
DO ₂ I	574.91 [mL/min/m ²]
CvO ₂	16.24 [mL/dL]
avDO ₂	3.77 [mL/dL]
VO ₂	196.20 [mL/min]
VO ₂ I	108.41 [mL/min/m ²]
O ₂ ER	18.86 [%]
PaO ₂ /O ₂	476.19 [mmHg]
QS/Qt	9.75 [%]

DATA ENTRY	
HEIGHT	170.0 [cm]
WEIGHT	70.0 [kg]
CO	5.20 [L/min]
O ₂	21 [%]
ATM	760 [mmHg]
PaCO ₂	40 [mmHg]
Hb	15.0 [g/dL]
PaO ₂	100 [mmHg]
SaO ₂	98 [%]
PvO ₂	50 [mmHg]
SvO ₂	80 [%]

Buttons: ADD TO LUNG TREND (ADD), SHOW LUNG TREND (SHOW), RECORD.

The values in this column are automatically calculated according to the values in the DATA ENTRY column.

The values in this column can be changed on the DATA ENTRY window.

Adds the values on the window to the LUNG TREND page in the TREND window.

Shows the LUNG TREND page in the TREND window.

Records the displayed data on the WS-671P recorder module.

4. Press the [Home] key to return to the home screen.


Entering the Data

Explanation of the DATA ENTRY Items

Item Name	Unit	Setting Range
Height	cm/inch	0.1 to 299.9
Weight	kg/pound	0.1 to 449.9
CO	L/min	0.01 to 20.0
O ₂	%	1 to 100
Atmospheric pressure	mmHg/kPa	235 to 795
PaCO ₂	mmHg/kPa	0 to 200
Hb	g/dL, mmol/L	0.1 to 50.0
PaO ₂	mmHg/kPa	0 to 800
SaO ₂	%	1 to 100
PvO ₂	mmHg/kPa	1 to 100
SvO ₂	%	0 to 99

1. Display the DATA ENTRY page.

Press the [Menu] key → LUNG FUNCTION key → DATA ENTRY tab.



Numeric keypad

2. If necessary, change values using the numeric keypad. Select the item you want to change the settings by touching the item name key.
3. Change the value using the numeric keypad on the window, then touch the ENT key.
4. Repeat step 2 and 3 to select other parameters.

When height or weight is changed, the same setting on the ADMIT window and windows which use height and weight are also changed. The respiration dynamics are recalculated according to the entered values.

Checking the Calculation Results

1. Display the LUNG FUNCTION page.
Press the [Menu] key → LUNG FUNCTION key → LUNG FUNCTION tab.
Check the calculation results.

The screenshot shows the LUNG FUNCTION page with two main sections: CALCULATION RESULTS and DATA ENTRY. The CALCULATION RESULTS section displays various physiological parameters and their values. The DATA ENTRY section allows for input of patient-specific data. There are also buttons for 'ADD TO LUNG TREND', 'SHOW LUNG TREND', and 'RECORD'.

CALCULATION RESULTS		DATA ENTRY	
BSA	1.81 [m ²]	HEIGHT	170.0 [cm]
CI	2.87 [L/min/m ²]	WEIGHT	70.0 [kg]
AaDO ₂	1.83 [mmHg]	CO	5.20 [L/min]
CaO ₂	20.01 [mL/dL]	O ₂	21 [%]
DO ₂	1040.42 [mL/min]	ATM	760 [mmHg]
DO ₂ I	574.91 [mL/min/m ²]	PaCO ₂	40 [mmHg]
CvO ₂	16.24 [mL/dL]	Hb	15.0 [g/dL]
avDO ₂	3.77 [mL/dL]	PaO ₂	100 [mmHg]
VO ₂	196.20 [mL/min]	SaO ₂	98 [%]
VO ₂ I	108.41 [mL/min/m ²]	PrO ₂	50 [mmHg]
O ₂ ER	18.86 [%]	SvO ₂	80 [%]
PaO ₂ /O ₂	476.19 [mmHg]		
Qs/Qt	9.75 [%]		

Buttons: ADD TO LUNG TREND (ADD), SHOW LUNG TREND (SHOW), RECORD.

Explanation of the CALCULATION RESULTS

Label	Name	Unit
BSA	Body surface area	m ²
CI	Cardiac index	L/min/m ²
AaDO ₂	Alveolar arterial oxygen tension difference	mmHg, kPa
CaO ₂	Arterial oxygen content	mL/dL
DO ₂	Oxygen delivery	mL/min
DO ₂ I	Oxygen delivery index	mL/min/m ²
CvO ₂	Venous oxygen content	mL/dL
avDO ₂	Arteriovenous oxygen difference	mL/dL
VO ₂	Oxygen consumption	mL/min
VO ₂ I	Oxygen consumption index	mL/min/m ²
O ₂ ER	Oxygen extraction ratio	%
PaO ₂ /O ₂	Oxygenation ratio	mmHg, kPa
Qs/Qt	Shunt fraction	%

Adding the Calculation Results to the LUNG TREND Table

1. Display the LUNG FUNCTION page.
Press the [Menu] key → LUNG FUNCTION key → LUNG FUNCTION tab.

The screenshot shows the 'LUNG FUNCTION' window with two main tables: 'CALCULATION RESULTS' and 'DATA ENTRY'. The 'CALCULATION RESULTS' table contains 14 rows of physiological data. The 'DATA ENTRY' table contains 10 rows of patient and environmental data. To the right of the 'DATA ENTRY' table are three buttons: 'ADD TO LUNG TREND', 'SHOW LUNG TREND', and 'RECORD'.

CALCULATION RESULTS		DATA ENTRY	
BSA	1.81 [m ²]	HEIGHT	170.0 [cm]
CI	2.87 [L/min/m ²]	WEIGHT	70.0 [kg]
AaDO ₂	1.83 [mmHg]	CO	5.20 [L/min]
CaO ₂	20.01 [mL/dL]	O ₂	21 [%]
DO ₂	1040.42 [mL/min]	ATM	760 [mmHg]
DO ₂ I	574.91 [mL/min/m ²]	PaCO ₂	40 [mmHg]
CvO ₂	16.24 [mL/dL]	Hb	15.0 [g/dL]
avDO ₂	3.77 [mL/dL]	PaO ₂	100 [mmHg]
VO ₂	196.20 [mL/min]	SaO ₂	98 [%]
VO ₂ I	108.41 [mL/min/m ²]	PvO ₂	50 [mmHg]
O ₂ ER	18.86 [%]	SvO ₂	80 [%]
PaO ₂ /O ₂	476.19 [mmHg]		
QS/Q _t	9.75 [%]		

Buttons: ADD TO LUNG TREND (ADD), SHOW LUNG TREND (SHOW), RECORD

2. Touch the ADD key on the LUNG FUNCTION page to add the calculation results to the table on the LUNG TREND page in the TREND window.

Displaying the LUNG TREND Table

1. Display the LUNG FUNCTION page.
Press the [Menu] key → LUNG FUNCTION key → LUNG FUNCTION tab.

This screenshot is identical to the one above, showing the 'LUNG FUNCTION' window with the 'CALCULATION RESULTS' and 'DATA ENTRY' tables, and the 'ADD TO LUNG TREND', 'SHOW LUNG TREND', and 'RECORD' buttons.

2. Touch the SHOW key on the LUNG FUNCTION window to display the table on the LUNG TREND page in the TREND window.

Recording the Calculation Results and Entered Data

The calculation results and entered data displayed on the LUNG FUNCTION page can be recorded on the optional recorder.

1. Display the LUNG FUNCTION page.

Press the [Menu] key → LUNG FUNCTION key → LUNG FUNCTION tab.

The screenshot shows the LUNG FUNCTION screen with two main sections: CALCULATION RESULTS and DATA ENTRY. The screen also features buttons for 'ADD TO LUNG TREND', 'SHOW LUNG TREND', and 'RECORD'.

CALCULATION RESULTS		DATA ENTRY	
BSA	1.81 [m ²]	HEIGHT	170.0 [cm]
CI	2.87 [L/min/m ²]	WEIGHT	70.0 [kg]
AaDO ₂	1.83 [mmHg]	CO	5.20 [L/min]
CaO ₂	20.01 [mL/dL]	O ₂	21 [%]
DO ₂	1040.42 [mL/min]	ATM	760 [mmHg]
DO ₂ I	574.91 [mL/min/m ²]	PaCO ₂	40 [mmHg]
CvO ₂	16.24 [mL/dL]	Hb	15.0 [g/dL]
avDO ₂	3.77 [mL/dL]	PaO ₂	100 [mmHg]
VO ₂	196.20 [mL/min]	SaO ₂	98 [%]
VO ₂ I	108.41 [mL/min/m ²]	PvO ₂	50 [mmHg]
O ₂ ER	18.86 [%]	SvO ₂	80 [%]
PaO ₂ /O ₂	476.19 [mmHg]		
QS/Qt	9.75 [%]		

Buttons: ADD TO LUNG TREND, ADD, SHOW LUNG TREND, SHOW, RECORD

2. Touch the RECORD key. The recording starts.

To stop recording the table, press the [Record] key.

3. Touch the key to close the window.

Recording example

The screenshot shows the LUNG FUNCTION screen with patient information at the top: ICU-001 JOHN SMITH, 2008-03-07 13:32. The screen displays the same calculation results and data entry fields as the previous screenshot.

CALCULATION RESULTS		DATA ENTRY	
BSA	1.81 [m ²]	HEIGHT	170.0 [cm]
CI	2.87 [L/min/m ²]	WEIGHT	70.0 [kg]
AaDO ₂	-380.07 [mmHg]	CO	5.20 [L/min]
CaO ₂	33.76 [mL/dL]	O ₂	21 [%]
DO ₂	1756.52 [mL/min]	ATM	350 [mmHg]
DO ₂ I	970.06 [mL/min/m ²]	PaCO ₂	120 [mmHg]
CvO ₂	26.96 [mL/dL]	Hb	25.0 [g/dL]
avDO ₂	6.81 [mL/dL]	PaO ₂	300 [mmHg]
VO ₂	353.86 [mL/min]	SaO ₂	98 [%]
VO ₂ I	195.53 [mL/min/m ²]	PvO ₂	50 [mmHg]
O ₂ ER	20.16 [%]	SvO ₂	80 [%]
PaO ₂ /O ₂	1428.57 [mmHg]		
QS/Qt	-8.07 [%]		

Buttons: ADD TO LUNG TREND, ADD, SHOW LUNG TREND, SHOW, RECORD

Footer: LUNG FUNCTION, GE Healthcare FQW50-3-100, K377.01

Section 9 Interbed Window

Registering Interbed Beds	9.3
Removing an Interbed Bed.....	9.3
Displaying the Numeric Data of All Interbed Beds.....	9.4
Displaying the Interbed Bed Data.....	9.5
Interbed Alarm.....	9.7
Settings Related to Interbed Alarm	9.8

9. INTERBED WINDOW

When the bedside monitor is connected to a central monitor network, the bedside monitor data can be sent to the central monitor. The bedside monitor can display monitoring data of up to 16 other beds in the network on the INTERBED window. When an alarm occurs at an interbed bed, the “ALARM bed name” of the alarmed interbed appears on the home screen of this bedside monitor if you have previously registered the other bed as an interbed bed on the INTERBED window.

To use the interbed function, the following settings must be set.

- Register the beds to be managed by the interbed function on this monitor
- Set <INTERBED ALARM> on the SETTINGS window of the INTERBED window to ON
- Set <AUTO INTERBED DISPLAY> on the SETTINGS window of the INTERBED window to ON to automatically display the VIEW OTHER BEDS window of the alarmed bed when an alarm occurs on that bed

NOTE

The monitor must be connected to a network to use the interbed function.

Registering Interbed Beds

To view another bed, you must register the bed as an interbed bed. Only registered beds can be viewed. You can register up to 16 interbed beds. Any bed in the monitor network can be registered as an interbed bed.

When registering an interbed bed, the power of the bedside monitor to be registered must be turned on.

- 1. Display the SELECT BEDS window.
Press the [Menu] key → INTERBED key → SELECT BEDS tab.



- 2. In <SELECTED BEDS> box, select the position to register the interbed bed.
- 3. Touch the GROUP key to select the group to which the desired bed belongs and select the bed from the bed list. The beds which are already registered as interbed beds cannot be selected.
- 4. Check that the selected bed appears in <SELECTED BEDS> box.

Removing an Interbed Bed

- 1. In <SELECTED BEDS> box, select the interbed bed to be removed.
- 2. Touch the VACANT key.

Displaying the Numeric Data of All Interbed Beds

The numeric data of all registered interbed beds can be displayed on the Multiple Beds window. The parameters that can be displayed are: heart rate and SpO₂.

Display the VIEW OTHER BEDS window.
Press the [Menu] key → INTERBED key → VIEW OTHER BEDS tab.

VIEW OTHER BEDS		SETTINGS		SELECT BEDS	
BSM-9100		MH-95012		ORG013X5	
TONY ARNOL		PETER BROW		MARY HOLME	
HR		HR		HR	
75		80		70	
		SpO ₂ 98		SpO ₂ 97	
				HR	
				92	

Displaying the Interbed Bed Data

On the individual bed window of the INTERBED window, heart rate and ECG waveform of the first trace are always displayed. Other numerical data and one waveform from the following list can be displayed. Other parameters cannot be displayed.

Numeric Data

- Heart rate
- VPC
- ST
- Respiration rate
- CO₂
- SpO₂
- NIBP
- T1
- T2
- O₂
- P1
- P2
- P3


Waveform

- Respiration/CO₂/FLOW
- SpO₂
- P1
- P2
- P3

1. Display the VIEW OTHER BEDS window.

Press [Menu] key → INTERBED key → VIEW OTHER BEDS tab.

9. INTERBED WINDOW



2. Touch the desired bed to display the individual bed window.
To change beds, touch the  key to close the window and select the desired bed.

To change the second waveform, touch the numeric data of the parameter you want to display for the waveform in the numeric display area.

To not display the second waveform, touch the numeric value of the second parameter in the waveform display area.

You can also change the waveform sensitivity or scale by using the  and  keys.

Interbed Alarm

When an alarm occurs on an interbed bed, a highlighted bed name appears at the top right corner of the home screen. This interbed alarm message does not indicate the type of alarm. The VIEW OTHER BEDS window can be automatically displayed when an alarm occurs and <AUTO INTERBED DISPLAY> is set to on.

Only one interbed ID can be displayed at a time on the home screen. When more than one interbed alarm occurs, the alarm message appears and the alarming interbed IDs are alternately displayed one at a time.

On the INTERBED window, the bed ID and patient name of the alarmed bed is highlighted.

NOTE

The interbed alarm for another bed is lower level than any other alarm for this bed. Therefore, the interbed alarm might not be indicated during an alarm for this bed.

The interbed alarm can be set to on or off. When set to ON, the highlighted bed name in the alarm level color is displayed on the upper right corner of the home screen when an interbed alarm occurs. When set to OFF, only the non-highlighted message is displayed.

You can also silence the interbed alarm by touching the  key on the individual bed window of the INTERBED window. Silencing the interbed alarm on this monitor also silences the alarm on the alarmed bed itself. The alarm silence indication on the alarmed bed depends on the alarmed bed specifications. The alarm silence time depends on the setting on the alarmed bed.

NOTE

When several interbed alarms occur, all interbed alarms are silenced by touching the  key on the individual bed window of the INTERBED window.


The interbed alarm can only be suspended on the alarmed bed.

Settings Related to Interbed Alarm

CAUTION

The interbed window only appears on the home screen when an interbed alarm occurs and <AUTO INTERBED DISPLAY> is set to On.

1. Display the SETTINGS window.
Press the [Menu] key → INTERBED key → SETTINGS tab.



2. Select interbed alarm ON or OFF in <INTERBED ALARM> box.
When this is set to ON, alarm sound occurs on the monitor and the bed ID is highlighted in the alarm level color.

Select auto interbed display ON or OFF in <AUTO INTERBED DISPLAY> box. When this is set to ON, the multiple beds window is automatically displayed when an alarm occurs.

3. Press the [Home] key return to the home screen.

Section 10 Recording

Overview of Recording	10.2
Recording Modes	10.3
Manual Waveform Recording/Printing	10.5
Recording/Printing on the 12 LEAD ANALYSIS Window	10.5
Recording/Printing on the Review Windows other than 12 Lead Window	10.5
Recording/Printing on the 12 LEAD Window	10.5
Recording on the LUNG FUNCTION Window	10.5
Recording/Printing PWTT Trendgraph	10.6
Recording/Printing OCRG	10.6
Recording on the CO Window	10.6
Recording on the TOF Window	10.6
Recording on the CCO Window	10.6
Recording on the FLOW Window	10.6
Recording on the EEG Window	10.7
Periodic Recording	10.8
Alarm Recording	10.9
Recording Mode Annotations	10.11
Recording Priority	10.12
Recording Sensitivity	10.12
Recording Speed	10.12
Recording Related Message	10.12
Recorded/Printed Data	10.13
Changing the Recording Speed	10.14
Changing the Recording Pattern	10.15
Manually Recording/Printing Waveforms	10.16
Recording Waveforms on the Optional Recorder	10.16
Recording Waveforms on the Bedside Monitor with No Recorder	10.17
Manual Printing on the Network Printer	10.17
Setting Periodic Recording	10.18
Changing Settings for Automatic Periodic Recording	10.19
Printing on a Network Printer	10.20

Overview of Recording

A variety of waveforms and data can be recorded by the optional recorder.

When the bedside monitor with no recorder is connected to a central monitor network, waveforms and data of the bedside monitor can be recorded manually on the central monitor recorder from the bedside monitor.

When the bedside monitor is connected to a network printer, real-time waveforms, data on the review windows and 12 lead ECG interpretation and analyzed waveforms can be printed. Refer to the “Printing on a Network Printer” section.

This section provides an overview of recording.

The “Changing the Recording Pattern” section explains how to change the recording pattern for all recordings except for the review data recordings.

The “Manually Recording/Printing Waveforms” section explains how to manually record waveforms at any time.

The “Setting Periodic Recording” section explains necessary settings for performing automatic periodic recording.

Some recording procedures are explained in other sections.

- To record trendgraphs and tables, see Section 6.
- To record arrhythmia recall files, see Section 6.
- To record alarm history, see Section 6.
- To record full disclosure, see Section 6.
- To record ST level recall files, see Section 6.
- To record 12 lead ECG interpretation result, see Section 7.
- To record 12 lead analysis waveform, see Section 7.
- For alarm recording, see Section 5.
- To record CO data on the CO window, see Section 9, User’s Guide Part II.
- To record TOF measurement results on the TOF window, see Section 13, User’s Guide Part II.
- To record AP waveform on the CCO window, see Section 14, User’s Guide Part II.
- To record FLOW data and loops on the FLOW window, see Section 15, User’s Guide Part II.
- To record EEG waveforms with the numeric values on the EEG window, see Section 16, User’s Guide Part II.

To load recording paper, see “Loading Recording Paper” in Section 2.

Recording Modes

The following recording modes are available.

Recording mode	Recorded data	Length/time of recorded data	Operations/conditions/settings for recording	Recorded annotation
Real time/delayed waveform recording*	Up to three waveforms selected on the RECORD window with numerical data	Time set at <MANUAL RECORD TIME> on the SYSTEM SETUP window	[Record] key is pressed Select second and third parameters for waveform recording on the RECORD window	MANUAL
Trend graph recording	Trendgraph on the window	Trendgraph displayed on the window	RECORD PAGE key on the PRINT window of the GRAPH 1, 2 or 3 window is touched	TREND GRAPH
Trend table recording	Table on the window	Data of selected time period	RECORD key on the PRINT window of the TABLE 1, 2 or 3 window is touched	TREND DATA
NIBP trend recording	Table on the window	Data of selected time period	RECORD key on the PRINT window of the NIBP TREND window is touched	NIBP TREND
Hemo trend recording	Table on the window	Data of selected time period	RECORD key on the PRINT window of the HEMO TREND window is touched	HEMO-DYNAMICS TREND
Lung trend recording	Table on the window	Data of selected time period	RECORD key on the PRINT window of the LUNG TREND window is touched	LUNG TREND
Arrhythmia recall recording	Acquired arrhythmia waveform	12 seconds	RECORD PAGE key on the PRINT window of the RECALL window is touched	RECALL
	Arrhythmia waveform on the window	Data displayed on the window		
Alarm history recording	Alarm history on the window	Data of selected time period	RECORD key on the PRINT window of the ALARM HISTORY window is touched	ALARM HISTORY
Full disclosure recording	Full disclosure data on the window	Full disclosure waveform on the window	RECORD PAGE key on the PRINT window of the FULL DISC window is touched	FULL DISC-LOSURE
	Actual size waveform on the window (when ZOOM IN key is touched)	12 seconds		
OCRG recording	OCRG on the window	Data displayed on the window	RECORD PAGE key on the PRINT window of the OCRG window is touched	OCRG
Recording on the 12 LEAD ANALYSIS WAVE page	ECG waveforms on the 12 LEAD ANALYSIS window	10 seconds	RECORDER key on the PRINT window of the 12 LEAD ANALYSIS window is touched	12 LEAD ECG
Recording on the 12 LEAD window	Table on the 12 LEAD window	Data displayed on the window	RECORD PAGE key on the PRINT window of the 12 LEAD window is touched	12 LEAD
	ECG waveforms on the ANALYSIS WAVE page	10 seconds of ECG waveforms	RECORD PAGE key on the PRINT window of the 12 LEAD window is touched	
	Analysis result on the REPORT page	Data displayed on the window	RECORD PAGE key on the PRINT window of the 12 LEAD window is touched	
Recording on the LUNG FUNCTION window**	CALCULATION RESULTS and DATA ENTRY data on the window	Data displayed on the window or all saved data	RECORD key on the LUNG FUNCTION window is touched	LUNG FUNCTION

10. RECORDING

Recording mode	Recorded data	Length/time of recorded data	Operations/conditions/settings for recording	Recorded annotation
Recording on the CO window**	Up to 5 CO data on the window	Data displayed on the window	RECORD key on the CO window is touched	CO TABLE
Recording on the TOF window	TOF measurement results on the TOF window	Data displayed on the window	RECORD key on the TOF window is touched	TOF
Recording on the CCO window	AP waveform on the CCO window	1 page	RECORD WAVE key on the CCO window is touched	CCO
Recording on the FLOW window	FLOW data and loops on the FLOW window	1 page	RECORD key on the FLOW window is touched	P-V LOOP or F-V LOOP
Recording on the EEG window	EEG waveforms and numeric values on the EEG window	1 page	RECORD key or RECORD ALL WAVES key on the EEG window is touched	EEG
Recording on the DOSE window	The table and settings displayed on the DOSE window	Data displayed on the window	RECORDER key on the PRINT DRUG CALC window of the DOSE window is touched	DRUG
Recording PWTT trendgraph**	PWTT trendgraph on the home screen	1 page	RECORD PWTT function key on the home screen is touched	PWTT
Recording OCRG	OCRG on the home screen	1 page	RECORD OCRG function key on the home screen is touched	OCRG
Vital signs alarm recording	Up to three waveforms selected on the RECORD window and vital sign data at an alarm occurrence	From 8 seconds before to 12 seconds after alarm occurrence	<ALARM RECORDING> on the RECORD window must be set to ON	ALARM
			Alarm for vital signs parameter must be turned on	
			Select second and third parameters for waveform recording on the RECORD window	
Arrhythmia alarm recording	Up to three waveforms selected on the RECORD window and vital sign data at an alarm occurrence	From 8 seconds before to 12 seconds after alarm occurrence	<ALARM RECORDING> on the RECORD window must be set to ON	
			Alarm for arrhythmia must be turned on	
			<ARRHYTHMIA ANALYSIS> on the ECG window must be set to ON	
Periodic recording	Up to three waveforms selected on the RECORD window with numerical data	10 seconds	<PERIODIC REC INTERVAL> on the RECORD window must be set to a time interval (FREE, 30, 60 or 120) Select second and third parameters for waveform recording on the RECORD window	TIMER
	PWTT trendgraph**	1 page	<PERIODIC REC INTERVAL> on the RECORD window must be set to 30 (PWTT)	PWTT
	OCRG trendgraph (HR, SpO ₂ and compressed respiration waveform)	2 pages	<PERIODIC REC INTERVAL> on the RECORD window must be set to either 5 (OCRG) or 15 (OCRG)	OCRG

- * Real time or delayed recording can be selected on the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3. When the bedside monitor with no optional recorder is connected to a central monitor network, waveforms and data of the bedside monitor can be recorded manually from the bedside monitor on the central monitor recorder. In this case, only real time recording is available.
- ** PWTT trendgraph, CO data and lung function data recording is only available on the optional WS-671P recorder module.

Manual Waveform Recording/Printing

Up to three waveforms selected on the RECORD window are recorded. For details, refer to the "Manually Recording/Printing Waveforms" section.

With recorder: Recorded on the optional recorder whenever the  [Record] key is touched.

No recorder: Not available.

Bedside monitor connected to central monitor network:

Recorded on the central monitor recorder whenever the  [Record] key on the bedside monitor is touched. In this case, ECG and the parameter selected for the second waveform are recorded.

Bedside monitor connected to a network printer:

Printed on the network printer whenever the PRINTER key on PRINT window is touched.

Recording/Printing on the 12 LEAD ANALYSIS Window

12 lead ECG waveforms on the 12 LEAD window can be recorded. For details, refer to "12 LEAD ANALYSIS Window" in Section 7.

With recorder: Recorded on the optional recorder when the RECORDER key on the PRINT window of the 12 LEAD ANALYSIS window is touched.

No recorder: Not available.

Bedside monitor connected to a CNS-9300 series, CNS-9601 or CNS-9701 central monitor:

Printed on the central monitor printer when the PRINTER key on the PRINT window of the 12 LEAD ANALYSIS window is touched.

Bedside monitor connected to a network printer:

Printed on the network printer when the PRINTER key on the PRINT window of the 12 LEAD ANALYSIS window is touched.

Recording/Printing on the Review Windows other than 12 Lead Window

For details, refer to Section 6.

Recording/Printing on the 12 LEAD Window

For details, refer to Section 7.

Recording on the LUNG FUNCTION Window

The lung function data displayed on the LUNG FUNCTION window can be recorded on the optional WS-671P recorder module. For details, refer to "Recording the Calculation Results and Entered Data" in Section 8.

Recording/Printing PWTT Trendgraph

PWTT trendgraph on the home screen can be recorded. Periodic PWTT trendgraph recording is also available. See the “Periodic Recording” section below.

With recorder: Recorded on the optional recorder when the RECORD PWTT function key on the home screen is touched.

No recorder: Not available.

Bedside monitor connected to a network printer:

Printed on the network printer when the PRINT PWTT key on the home screen is touched.

Recording/Printing OCRG

OCRG on the home screen can be recorded. Periodic OCRG recording is also available. See the “Periodic Recording” section below.

With recorder: Recorded on the optional recorder when the RECORD OCRG function key on the home screen is touched.

No recorder: Not available.

Bedside monitor connected to a network printer:

Printed on the network printer when the PRINT OCRG key on the home screen is touched.

Recording on the CO Window

The CO data displayed on the CO window can be recorded on the optional WS-671P recorder module. Recording starts after a few seconds and a blinking  mark appears on the upper right corner of the screen. CO can only be recorded on the optional recorder. For details, refer to Section 9 of User’s Guide Part II.

Recording on the TOF Window

Measurement results displayed on the TOF window can be recorded on the optional WS-671P recorder module. For details, refer to Section 13 of User’s Guide Part II.

With recorder: Recorded on the optional recorder when the RECORD key on the TOF window is touched.

No recorder: Not available.

Recording on the CCO Window

The AP waveform displayed on the CCO window can be recorded on the optional WS-671P recorder module. For details, refer to Section 14 of User’s Guide Part II.

With recorder: Recorded on the optional recorder when the RECORD WAVE key on the CCO window is touched.

No recorder: Not available

Recording on the FLOW Window

The FLOW data and loops can be recorded on the optional WS-671P recorder module. For details, refer to Section 15 of User’s Guide Part II.

With recorder: Recorded on the optional recorder when the RECORD key on the FLOW window is touched.

No recorder: Not available.

Recording on the EEG Window

The EEG waveforms with the numeric values can be recorded on the optional WS-671P recorder module. For details, refer to Section 16 of User's Guide Part II.

With recorder: Recorded on the optional recorder when the RECORD key or RECORD ALL WAVES key on the EEG window is touched.

No recorder: Not available.

Periodic Recording

There are three types of recording data for periodic recording.



- Up to three waveforms with numerical data:
Up to three waveforms selected on the RECORD window and vital signs data are recorded automatically at the set interval.
- PWTT trendgraph:
PWTT trendgraph on the home screen is recorded at 30 minute intervals.
- OCRG:
The trendgraphs of HR and SpO₂ and compressed respiration waveform are recorded at 5 or 15 minute intervals.

Periodic recording is only available on the optional recorder.


Set the following items on the RECORD window.

- Periodic recording time interval. When OFF is selected, periodic recording is turned off.
To periodically record PWTT trendgraph, select the 30 (PWTT).
To periodically record OCRG, select either the 5 (OCRG) or 15 (OCRG).
- Recording pattern (not necessary when recording the PWTT trendgraph or OCRG)

Recording examples



OCRG recording



10.10

User's Guide Part I BSM-6000



Recording Mode Annotations

One of the following annotations is recorded on each page of the recording paper as shown below.


TIMER:	Automatic periodic recording. Refer to the “Setting Periodic Recording” section.
ALARM:	Automatic recording at a vital sign or arrhythmia alarm occurrence. Refer to “Turning Automatic Alarm Recording On/Off” in Section 5.
TREND GRAPH:	Trendgraph recording. Refer to “Trend Window” in Section 6.
TREND DATA:	Trend table recording. Refer to “Trend Window” in Section 6.
NIBP TREND:	NIBP trend recording. Refer to “Trend Window” in Section 6.
HEMO TREND:	Hemo trend recording. Refer to “Trend Window” in Section 6.
LUNG TREND:	Lung trend recording. Refer to “Trend Window” in Section 6.
RECALL:	Arrhythmia waveform recording. Refer to “Arrhythmia Recall Window” in Section 6.
ALARM HISTORY:	Alarm history recording. Refer to “Alarm History Window” in Section 6.
FULL DISCLOSURE:	Full disclosure recording. Refer to “Full Disclosure Window” in Section 6.
ST:	ST level recall recording. Refer to “ST Level Recall Window” in Section 6.
OCRG:	OCRG recording on the OCRG window. Refer to “OCRG Window” in Section 6. OCRG recording on the home screen.
12 LEAD ECG:	ECG waveforms displayed on the ANALYSIS WAVE page of the 12 LEAD window are recorded. Refer to “12 LEAD Window” in Section 6.
DRUG:	Titration table and settings displayed on the DOSE window is recorded. Refer to “DRUG Window” in Section 8.
LUNG FUNCTION:	Calculation results and entered data displayed on the LUNG FUNCTION page are recorded. Refer to “LUNG FUNCTION Window” in Section 8.
MANUAL:	Manual recording.
PWTT:	PWTT trendgraph recording.
CO TABLE:	Hemodynamics data and thermodilution curves table on the CO window are recorded. Refer to “Cardiac Output Monitoring” in Section 9, User’s Guide Part II.
TOF:	Measurement results displayed on the TOF window is recorded. Refer to “TOF Monitoring” in Section 13, User’s Guide Part II.
CCO:	AP waveform recording. Refer to “CCO Monitoring” in Section 14, User’s Guide Part II.

10. RECORDING

- P-V LOOP, F-V LOOP: FLOW data and loops displayed on the FLOW window is recorded. Refer to “FLOW/Paw Monitoring” in Section 15, User’s Guide Part II.
- EEG: EEG waveform recording. Refer to “EEG Monitoring” in Section 16, User’s Guide Part II.

Recording Priority

If more than one recording mode is activated at the same time, only the highest priority mode is used.



During alarm recording, if a higher priority alarm occurs, the current recording is canceled and the higher priority alarm is recorded for 20 seconds.

During any type of recording, if a lower or equal priority alarm recording or any other type of recording occurs, the lower or equal priority recording is not performed; only the current recording is performed.

Recording Sensitivity

The sensitivity of the waveforms recorded on the recording paper is the same as the sensitivity of the waveforms displayed on the screen.

To change the sensitivity, change the sensitivity setting on the parameter setting window as described in Operator’s Manual, Part II.

Recording Speed

The recording speed can be set at <RECORDING SPEED> on the RECORD window. Refer to “Changing the Recording Speed” in this section.

Recording Related Message

The following messages appears in the following conditions.

When out of recording paper



When the recorder door is open



Recorded/Printed Data

The following data can be printed.

Printed Items	Example
Patient name	John Smith
Bed ID	BED-001
Date and time	2002/07/11 10:30
Reason for recording	TIMER, ALARM, etc.
Sensitivity	×2
Paper speed	25 mm/s
ECG related message	MONITOR* ¹
Heart rate (beats/min)	HR: 100
ECG lead	II
Number of VPCs	VPC: 10/min
ST level	−0.04 mV
Pulse rate (beats/min)	PR: 80
SpO ₂ (%)	SpO ₂ : 98
NIBP: SYS/DIA (MEAN) (mmHg), measurement time	NIBP: 132/61 (80) mmHg 17:24
Respiration rate (resp/min)	RR: 14
CO ₂ (mmHg)	CO ₂ : 40
IBP: SYS/DIA (MEAN) (mmHg)	ART: 132/61 (80) mmHg
Temperature (°C/°F)	Tskin: 36.4°C
O ₂ (%)	O ₂ : 12
Anesthetic gas	FiISO: 3.0
Arrhythmia name	COUPLET
Waveform annotation* ²	N, V, P etc.

*¹Selected setting for FILTERS on the ECG window is recorded. Refer to User's Guide, Part II. When the "CHECK ELECTRODES" alarm occurs, "CHECK ELECTRODES" is recorded instead of the FILTERS setting.

*²Recorded when the recording mode is MANUAL, ALARM or RECALL and <ARRHYTHMIA ANALYSIS> on the ECG window is set to ON.


Changing the Recording Speed

Recording speed can be selected from 12.5, 25 or 50 mm/s for recording with the optional recorder.

Recording speed and waveform sweep speed on the screen can be set separately.

1. Display the OTHER page.

Press the [Menu] key → RECORD key → OTHER tab.



2. Select the speed by touching the speed key in <RECORDING SPEED> box.
3. Press the [Home] key to return to the home screen.


Changing the Recording Pattern

Up to two parameter waveforms can be selected for a recording pattern.

The selected recording pattern applies to all recording except recording on the review windows, CO window, OCRG and PWTT trendgraph. ECG (TRACE 1) is the default setting.

1. Display the REC PARAMS page.

Press the [Menu] key → RECORD key → REC PARAMS tab.



FLOW, Paw and VOL are not available for BSM-6000A series.

2. Select the trace in the <TRACES> box and select the parameter by touching the parameter key in the <SELECTABLE PARAMETERS> box. Select the NONE key to not assign any parameter.
3. Press the [Home] key to return to the home screen.

Manually Recording/Printing Waveforms


Recording Waveforms on the Optional Recorder

Waveforms and data can be recorded manually on the recorder module.


There are four settings:

- Recording pattern: This setting determines which of the measured parameter waveforms is recorded. See the “Changing the Recording Pattern” in this section.
- Real-time or delay mode: In DELAY mode, recording begins with the waveforms acquired 8 seconds before recording starts. In REAL TIME mode, recording begins with the waveforms acquired when recording starts. To select real-time or delayed manual recording mode, refer to “RECORD window” in Administrator’s Guide, Section 3.
- Recording length: CONTINUOUS, 10, 20 or 30 seconds can be selected for the recording length on the SYSTEM SETUP window. Refer to “RECORD window” in Administrator’s Guide, Section 3.
- Recording speed: The recording speed is set at <RECORDING SPEED> on the RECORD window.

1. If necessary, select the recording pattern on the RECORD window. Refer to the “Changing the Recording Pattern” in this section.
2. To start recording, press the [Record] key.
3. To stop recording, press the [Record] key again.




Recording example



Recording Waveforms on the Bedside Monitor with No Recorder

When the bedside monitor with no optional recorder is connected to a central monitor network, waveforms and data can be recorded manually from the bedside monitor on the central monitor recorder. Three waveforms selected for the TRACE 1, TRACE 2 and TRACE 3 are recorded with the recording length selected on the bedside monitor. When CONTINUOUS is selected for the recording length, 30 seconds is automatically selected.



1. If necessary, select the recording pattern on the RECORD window. Refer to the “Changing the Recording Pattern” in this section.
2. To start recording, press the  [Record] key.

Manual Printing on the Network Printer

When the bedside monitor is connected to a network printer, all monitoring waveforms and numeric data can be printed on the network printer. The waveforms from 7 seconds before to 3 seconds after PRINT key on the window is touched are printed.

The PWTT trendgraph and OCRG can also be printed on the network printer. The PWTT trendgraph or OCRG displayed on the home screen can be printed when the PRINT PWTT or PRINT OCRG function key is touched.

To print the PWTT trendgraph and OCRG, the print function must be assigned to one of the function keys in the upper left corner of the screen. Refer to “KEYS Window” in Administrator’s Guide, Section 3.



For details about printing on the network printer, refer to the “Printing on a Network Printer” in this section.

Setting Periodic Recording

You can select one of the three types of recording data:

- Up to three waveforms with numerical data
- OCRG
- PWTT trendgraph

From the bedside monitor, automatic periodic recording cannot be performed on the central monitor recorder.

Up to three waveforms with numerical data

A 10 second waveform can be automatically recorded at preset intervals of 30, 60, 120 minutes or a free interval that you can set to any length.

Recording starts at the nearest half-hour for 30 min interval, at the nearest hour for 60 or 120 min interval and at the next FREE interval for FREE recording.

For example, if you start automatic periodic recording at 9:20 with a 30 min interval, periodic recording will be performed at 9:30, 10:00, 10:30 and so on. If you start at 9:20 with a 120 min interval, periodic recording will be performed at 10:00, 12:00, 14:00 and so on. If you start at 9:20 with a FREE interval of 65 min, periodic recording will be performed at 10:25, 11:30, 12:35 and so on.

OCRG

The trendgraphs of HR and SpO₂ and compressed respiration waveform are recorded. The OCRG is recorded every 5 minutes when the 5 (OCRG) is selected in <PERIODIC REC INTERVAL> box on the RECORD window, and every 15 minutes when the 15 (OCRG) is selected. To select the 5 (OCRG) or the 15 (OCRG), OCRG must be selected for <CURRENT TREND> on the SYSTEM window of the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3.

The OCRG recording has two pages. The first page contains HR and SpO₂ trendgraphs and the second page contains compressed respiration waveform.

PWTT Trendgraph

The PWTT trendgraph is recorded. The PWTT trendgraph is recorded every 30 minutes when the 30 (PWTT) is selected at <PERIODIC REC INTERVAL> box on the RECORD window. To select the 30 (PWTT), PWTT must be selected for <CURRENT TREND> on the SYSTEM window. Refer to Administrator's Guide, Section 3.

Changing Settings for Automatic Periodic Recording

There are two settings:

- Periodic recording on/off: Recording interval must be selected on the RECORD window to automatically record waveform and data at periodic interval.
To record OCRG or PWTT, select the 5 (OCRG) or the 15 (OCRG) when recording OCRG and select the 30 (PWTT) when recording PWTT.
- Free time interval: You can set the desired interval for automatic periodic recording at <PERIODIC FREE INTERVAL> on the SYSTEM SETUP window. FREE selection is from 1 to 120 minutes (1 min/step). Default setting is 15 min. See “RECORD Window” in Administrator’s Guide, Section 3.

1. Display the OTHER page.

Press the [Menu] key → RECORD key → OTHER tab.



2. Select the recording interval at <PERIODIC REC INTERVAL> box. Select the OFF key when not performing periodic recording.

To record OCRG every 5 minutes, select the 5 (OCRG) key. To record OCRG every 15 minutes, select the 15 (OCRG) key.

To record PWTT trendgraph every 30 minutes, select the 30 (PWTT) key.

3. Press the [Home] key to return to the home screen.

Printing on a Network Printer

When the bedside monitor is connected to a network printer, the following printing is available. To print on the network printer, the printer properties (IP address, printer type and paper size) must be set on the RECORD window of the SYSTEM SETUP window. Refer to Administrator's Guide, Section 3.

NOTE

Printing cannot be canceled once it is started.

- Real-time waveform printing:
Prints the waveforms from 7 seconds before to 3 seconds after the PRINT PAGE key on the PRINT window is touched. Refer to the "Manually Recording/Printing Waveforms" in this section.
- Printing data on the review windows:
Prints the displayed trendgraphs when the PRINT PAGE key on the PRINT window of the TREND GRAPH page is touched.

The data of selected time period can be printed when RECORD key on the PRINT window of the TREND TABLE, NIBP TREND, HEMO TREND or LUNG TREND page is touched.

The displayed 8 seconds of arrhythmia recall waveform and the one file before and after of arrhythmia recall waveform is printed when the PRINT PAGE key on the PRINT window of the RECALL window is touched.

The compressed or actual size full disclosure waveform selected by the cursor can be printed when the PRINT PAGE key on the PRINT window of the FULL DISC window is touched.

The displayed ST recall files and the previous three ST recall files are printed when the PRINT PAGE key on the PRINT window of the ST window is touched.

- Printing on the 12 LEAD ANALYSIS window:
When <RECORDING SPEED> on the RECORD window is set to 25 mm/s, 10 seconds of 12 lead ECG on the 12 LEAD ANALYSIS window can be printed when the PRINTER key on the PRINT window is touched.

When <RECORDING SPEED> on the RECORD window is set to 50 mm/s, 2 pages of 12 lead ECG on the 12 LEAD ANALYSIS window can be printed when the PRINTER key on the PRINT window is touched.

- Printing on the 12 LEAD window:
10 seconds of 12 lead ECG on the ANALYSIS WAVE page, 2.2 second ECG, 10 second rhythm waveform and analysis report on the REPORT page and averaged waveforms on the AVERAGE WAVE page can be printed when the

PRINT PAGE key on the PRINT window of the 12 LEAD window is touched.

- Printing OCRG on the OCRG window:
The displayed OCRG on the OCRG window can be printed when the PRINT PAGE key on the PRINT window is touched.
- Printing on the DRUG window:
The titration table and drug data on the DOSE window can be printed when the PRINTER key on the PRINT window of the DOSE window is touched.
- Printing OCRG on the home screen:
When the PRINT OCRG is assigned to one of the function keys, the OCRG on the home screen can be printed on the network printer.
- Printing PWTT trendgraph on the home screen:
When the PRINT PWTT is assigned to one of the function keys, the PWTT trendgraph on the home screen can be printed on the network printer.

Section 11 Reference

Clock Accuracy 11.2

Periodical Replacement Schedule..... 11.3

Repair Parts Availability Policy 11.3

Clock Accuracy

At an operating temperature of 25°C, the accuracy of the clock IC of this monitor is about ± 2 min 30 s per month.

At storage temperatures between –20 and +60°C, the accuracy of the clock IC of this monitor is about ± 6 min per month.

Periodically check that the time in the upper right corner of the monitor screen is correct.

To change the time setting, refer to “Changing Date and Time” in Section 4.

NOTE

When the date or time is changed during monitoring, the date and time of all stored data is also changed and may not match the date and time on the printout.

When the monitor is connected to a network

The time on this monitor is automatically adjusted to match the time of the network as long as the monitor is connected to the network. The date and time on all monitors in the network are set to the same setting.

Periodical Replacement Schedule

To maintain the performance of the instrument, the following parts must be periodically replaced.

Description	NK Code No./ Supply Code No.	Expected Life Span
MU-631R/MU-651R/MU-671R Main Unit		
Battery pack (option)	SB-671P	Approx. 1 year
WS-671P Recorder Module (option)		
Thermal array head, AJ048-8E802	662311A	Approx. 370 stacks of recording paper After 370 stacks of recording paper, the thermal array head is deteriorated and the recording becomes thin.
Motor Assy (Paper drive motor)	CD-0004	Approx. 9,000 stacks of recording paper (continuous recording) After 9,000 stacks of recording paper, the paper drive motor is deteriorated and cannot feed the recording paper.
Platen roller, Ø 8	6114-135436C	Approx. 6 years When the platen roller is deteriorated, the paper cannot be fed.
Retainer ring, G-3	675369	Must be replaced with a new one when the platen roller is replaced.

Repair Parts Availability Policy

Nihon Kohden Corporation (NKC) shall stock repair parts (parts necessary to maintain the performance of the instrument) for a period of 8 years from the date of delivery. In that period NKC or its authorized agents will repair the instrument. This period may be shorter than 8 years if the board or part necessary for the faulty section is not available.



Manufacturer

NIHON KOHDEN CORPORATION

1-31-4 Nishiochiai, Shinjuku-ku
Tokyo 161-8560, Japan
Phone +81 (3) 5996-8036
Fax +81 (3) 5996-8100



European Representative

NIHON KOHDEN EUROPE GmbH

Raiffeisenstrasse 10
61191 Rosbach v.d.H., Germany
Phone +49 6003 827-0
Fax +49 6003 827-599

NIHON KOHDEN ITALIA S.r.l.

Via San Tomaso 78
24121 Bergamo, Italy
Phone +39 035 219543
Fax +39 035 232546

NIHON KOHDEN IBERICA S.L.

C/Ulises 75A
28043 Madrid, Spain
Phone +34 917 161 080
Fax +34 913 004 676

NIHON KOHDEN TRADING (SHANGHAI) CO., LTD

5F Hui Jin Business Mansion
No. 259 Wuzhong Road, Shanghai 201103, China
Phone +86 (21) 6270-0909
Fax +86 (21) 6270-9700

Beijing Branch

Room 1501, East Ocean Centre
No. 24A JianGuoMenWai Street, Beijing, 100004
Phone 010-6515-5750
Fax 010-6515-5758

Guangzhou Branch

Room 2514, Yian Plaza
No. 33 Jian She Liu Ma Road, Guangzhou, 510060
Phone 020-8363-3737
Fax 020-8363-3807

NIHON KOHDEN AMERICA, INC.

90 Icon Street, Foothill Ranch, CA 92610, USA
Phone +1 (949) 580-1555
Fax +1 (949) 580-1550

NIHON KOHDEN FRANCE SARL

8, rue Francois Delage, 94230 Cachan, France
Phone +33 1 49 08 05 50
Fax +33 1 49 08 93 32

NIHON KOHDEN FIRENZE S.r.l.

Via Torta 72/74
50019 Sesto Fiorentino (FI), Italy
Phone +39 055 3045 1
Fax +39 055 308548

NIHON KOHDEN SINGAPORE PTE LTD

1 Maritime Square, #10-34 (Lobby C), Harbour Front Centre
Singapore 099253
Phone +65 6376-2210
Fax +65 6376-2264

NIHON KOHDEN KOREA, INC.

Hannam Tower Annex Bldg. Suite 203
730 Hannam-dong, Yongsan-gu, Seoul, Korea 141-210
Phone +82 (2) 3273-2310
Fax +82 (2) 3273-2352

The model and serial number of your instrument are identified on the rear or bottom of the unit.

Write the model and serial number in the spaces provided below. Whenever you call your distributor concerning this instrument, mention these two pieces of information for quick and accurate service.

Model _____

Serial number _____

Your Distributor